



BP PINS:  
 1. Capacitors need to close as possible  
 2. PCB as 4-layer PCB, BP pads need to use 10 ohm impedance (check trace width).

Title		
Size	Number	Revision
0xalC		
Date:	26-Sep-2018	Sheet of
File:	ECU_17_2018_01_PCH10038_0_00110_006600101	