



System Diagram

Ground Auto Tracker Antenna



Aircraft



★ Tracker Antenna manually or automatically switches either between omni or directional antenna.