



# System Diagram

## Ground Auto Tracker Antenna



## Aircraft



★ Tracker Antenna automatically switches either between omni or directional antenna.