


Pentastar Aviation Ramp -
Latitude: 42°39'47.09"N,
Longitude: 83°25'35.64"W

Run Up Pad -
Latitude: 42°39'46.15"N
Longitude: 83°24'50.83"W



Google earth

feet
meters

