




NB

All remote terminal vessel CPE are to the starboard side of the base station equipped vessel. In reciprocal line heading they are on the port side.

All distances indicate nominal antenna separations. Due to the fact the installations is on ships underway at sea, the actual antenna separations will vary slightly.



