



蓝牙耳机



前言

尊敬的用户,感谢您选购本公司产品。为了您能更进一步的了解产品,使用前请仔细阅读本说明书。祝你体验愉快。


产品介绍



产品参数

产 品 型 号	X3	传 输 距 离	≥10M
芯 片 版 本	V5.3	充 电 时 长	1-2小时
喇 叭 尺 寸	φ16	续 航 时 长	6-7小时
频 率 响 应	20Hz-20kHz	待 机 时 长	100天
充电仓电池容量	400mah	耳机电池容量	50mah

功能操作



音乐播放

播放/暂停音乐:双击

上一曲:三击左耳

下一曲:三击右耳

音量减:单击左耳

声音加:单击右耳

通话管理

来电双击:接听电话/挂断电话

拒接电话:来电时长按2秒

辅助功能

游戏/音乐:长按右耳 2 秒

语音助手:长按左耳 2 秒进入语音助手

切换语言:开机后连击 4 次切换中英文,需要有中英文提示音

LED指示灯

充电状态:耳机充电指示白灯常亮,充满灯灭。

配对状态:白色指示灯闪烁。

未连接手机状态:主耳指示灯闪烁,副耳指示灯灭。

音乐状态:手机连接成功,指示灯灭。

通话状态:指示灯灭。

游戏模式:白色指示灯呼吸灯效

低电量模式:白色指示灯闪烁,语音提示。

首次使用

首次使用前,请先确认两个耳机和充电仓的电量是满的,电量不足时请使用本产品配带的数据线进行充电,并选择正规厂家生产的经过国家CCC认证的充电设备。

若产品超过2个星期未使用,建议使用前先对产品进行充电。

开/关机

自动开机:充电仓开盖后,取出耳机自动开机。

自动关机:将耳机放回充电仓中,耳机会断开蓝牙连接并自动关机。

手动开关机:长按触控 3S。

蓝牙配对连接

蓝牙配对:耳机开机进入配对状态,蓝牙设备搜索耳机配对名称“X3”点击连接配对完成。(如果搜索不到蓝牙请关闭再打开手机蓝牙重新连接)

连接成功:会有语音提示音。

自动回连:首次连接成功后,开机默认连接最后配对的设备。

耳机电量和充电

耳机电量显示

手机状态栏可显示耳机设备电量信息(需手机版本支持此功能)

耳机充电状态

耳机充电过程中,指示灯会有充电提示,充满后指示灯熄灭。

耳机低电量提醒

当耳机处于低电量状态时,耳机会有语音提示音提示电量不足,请及时将耳机放入充电仓充电。

充电仓电量和充电

充电仓电量显示

打开充电仓内部数显显示实时电量。

充电仓充电

建议使用标准的充电器和随附的充电线对充电仓进行充电。

充电仓低电量提醒

当充电仓数显显示电量过低时,请及时给充电仓充电


注意事项

1. 请勿以任何理由拆开、维修或改装耳机,否则可能会导致起火、电子击穿甚至彻底损坏本产品。
2. 请勿将产品置于温度过低或过高(0℃以下或45℃以上)的环境下。
3. 请勿在雷雨天气使用本设备,雷雨天气可能会导致设备故障或电击危险。
4. 请勿使用烈性化学制品、清洗剂或强洗涤剂清洁设备或其配件。
5. 请勿将设备靠近热源或裸露的火源,如电暖器、微波炉、烤箱、热水器、炉火蜡烛或其他可能产生高温的地方。
6. 请勿长时间大音量听音乐会造听力损害,使用该设备时请调整到适当音量。
7. 请勿自行更换电池,本设备配有不可拆卸的内置电池,以免损坏电池或设备。不建议私自更换。
8. 清洁和维护前,请停止使用本设备,关闭所有应用,并断开与其他设备的所有连接或线缆。

警告!

1. 禁止拆解、撞击、挤压电池或投入火中、插入异物,以免引起电池漏液过热、起火或爆炸。
2. 本设备并非玩具,儿童应在成人监护下使用本设备配件要求。
3. 若出现严重鼓胀禁止继续使用。
4. 禁止置于高温环境中,远离火源。
5. 电池浸水或其它液体中后禁止使用。


BLUETOOTH HEADSET



INTRODUCTION

Dear users, thank you for purchasing our products. In order to better understand the product, please read this manual carefully before use. Have a good experience.

PRODUCT INTRODUCTION



PRODUCT PARAMETER

Product model	X3	Transmission distance	≥10M
Chip version	V5.3	Charging time	1-2 hours
Horn size	φ16	Endurance time	6-7hours
Frequency response	50Hz-20kHz	Standby time	100 days
Charging bay battery capacity	400mah	Headphone battery capacity	50mah

FUNCTIONAL OPERATION

Music playback

Play/Pause music: Double click

Previous: Three blows to the left ear

Next: Three strikes on the right ear

Volume minus: Click left ear

Sound Plus: Click the right ear

Call management

Call Double-click: Answer the call or hang up the call

Reject a call: Hold down a call for 2 seconds

Auxiliary function

Game/Music: Press and hold right ear for 2 seconds

Voice Assistant: Press and hold the left ear for 2 seconds to access the voice assistant

Language switch: After starting up, click 4 times to switch between Chinese and English, and you need to have an English and Chinese prompt tone

LED INDICATOR

Charging status: headset charging indicator white light is steady on, full light is off.

Pairing status: The white indicator is blinking.

Disconnected phone status: The main ear indicator is blinking, and the secondary ear indicator is off.

Music status: The phone is connected successfully, and the indicator is off.

Call status: The indicator is off.

Game mode: White light breathing light effect

Low battery mode: The white indicator blinks and the voice prompts.

FIRST USE

Before using for the first time, please confirm that the power of the two earphones and the charging compartment is full. If the power is insufficient, please use the data cable equipped with this product to charge, and choose the charging equipment produced by the regular manufacturer through the national CCC certification. If the product has not been used for more than 2 weeks, it is recommended to charge the product before use.

ON/OFF

Automatic power on: After opening the cover of the charging compartment, take out the headset and turn on automatically.

Automatic shutdown: Put the earphones back in the charging compartment, and the earphones will disconnect the Bluetooth connection and automatically shut down.

BLUETOOTH PAIRING CONNECTION

Bluetooth pairing: The headset starts to enter the pairing state, and the Bluetooth device searches for the headset pairing name "X3" and clicks the connection pairing completion. (If you can't find Bluetooth, turn it off and turn it on to reconnect) If the connection is successful, an announcement is played.

Automatic connect back: After the first connection is successful, the last device is connected by default.

EARPHONE POWER AND CHARGING

Earphone battery display

Mobile phone status bar can display headset device battery information (the mobile phone version needs to support this function)

Earphone charging state

During the charging process of the headset, the indicator light will have a charging reminder, and the indicator light will be turned off after it is full.

Headset low battery reminder

When the earphone is in the low battery state, the earphone will have an announcement indicating that the battery is low. Please put the earphone into the charging bay to charge it in time.

CHARGING BIN POWER AND CHARGING

Charging bin power display

Turn on the digital display inside the charging bin to display real-time power

Bin charging

It is recommended to use a standard charger and the included charging cable to charge the charging bay.

Charging bin low power reminder

When the charging bin digital display shows that the power is too low, please charge the charging bin in time

MATTERS NEEDING ATTENTION

1. Do not disassemble, repair or modify the headset for any reason, otherwise it may cause fire, electronic breakdown or even complete damage to the product.
2. Do not place the product in an environment where the temperature is too low or too high (below 0°C or above 45°C).
3. Do not use the device during thunderstorms. This may cause device failure or electric shock.
4. Do not use strong chemicals, cleaning agents or strong detergents to clean the equipment or its accessories.
5. Do not place the device near heat sources or exposed fire sources, such as electric heaters, microwaves, ovens, water heaters, candles, or other places that may produce high temperatures.
6. Do not listen to music at a high volume for a long time to cause hearing damage. Please adjust the volume when using the device.
7. Do not replace the battery by yourself. This device is equipped with a non-removable built-in battery to avoid damage to the battery or device. Private replacement is not recommended.
8. Before cleaning and maintenance, stop using the device, close all applications, and disconnect all connections or cables from other devices.

WARNING!

1. Do not disassemble, impact, squeeze the battery or put it into the fire or insert foreign bodies to avoid overheating, fire or explosion of battery leakage.
2. This device is not a toy, and children should use this device under adult supervision.
3. If there is serious swelling, do not continue to use.
4. Do not place in high temperature environment, away from fire source.
5. Do not use the battery after it is immersed in water or other liquids.

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna.

.Increase the separation between the equipment and receiver.

.Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

.Consult the dealer or an experienced radio/TV technician for help. Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

RF Exposure Information

The device was evaluated to meet general RF exposure requirements. This equipment should be installed and used with a minimum distance of 0 mm between the radiator and your body.