

Care Tip: If the speaker needs cleaning, wipe it using a soft dry cloth. Never use any abrasive cleaning agents. Periodically wipe off accumulated dust.

- Features

 Wirelessly connects to any Bluetooth® compatible device for playing all your favorite tunes

 Touch LED illumination changes colors and light modes when the speaker grills present flash, fate, dimmer control and

 Multiple modes for constaint, fate, fate, dimmer control and control integrated microphone for hands-free calls and voice service control

 USB rechargeable battery

 Builtin TF memory card reader, track control panel, mini plug auxillary input and utility hanging book

Before First Use
We recommended fully charging the battery upon purchase of your new speaker before using for the first time.





- Charging the Speaker

 1. Plug the included USB cable into the micro USB charging port located on the bottom back side of the speaker.

 2. Plug the other end of the USB cable into any other USB power source and allow to charge for several hour. The power light LED will illuminate red allow to charge for several hour. The power light LED will illuminate red unring the charging phase. Unplug the speaker when it is ready for use.


Note: The speaker can also be used while plugged into the USB power cord for long lasting use without draining the battery.





Control Panel Functions


The speaker features an integrated control panel to control your music right from the speaker. See below for control functions.



MODE: Changes from Bluetooth, AUX, USB and Micro SD card inputs. The Button Can also be used to enter Bluetooth pairing more to connect to your device.

Track Back and Volume Down-Press to go back to the previous music track and hold to turn the volume down.

Play/Stop/Answer-Press to piley and pause your music track or enswer a call. Track Foreward and Volume Up-Press to go forward to the next music track and hold to turn the volume up.



Using Alternatio Inputs

1. To use the auxiliary or USB inputs on the speaker, plug the cord into the back of the speaker and connect to your device to play music into the back of the speaker and connect to your device to play music.

2. To use the memory card input. Insert a compatible SD memory card with music incito the slot. Use the controls on the speaker to control playbact the music. Press mode to go back to AUX, USB or Bluetooth input opto "leaves ring upda end do convenience also ended." "20 memory and in extendi



- WARNING! IMPORTANT CARE AND SAFEGUARDS
 Failure to follow the safety instructions can lead to fire, electrical shock, personal injury or properly diamage and damage to this product.

 1 you have an electrical device, such as a pacemaker, consult a physician or layer to the product of the prod

The Text Continues of the Continues of t

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment