


UNIWA

BORN FOR LOVE




V1000

User Manual V1.0

Thank you for choosing UNIWA V1000 4G senior phone, it mainly support American 4G bands, not support European 4G bands currently. But it supports 2G(GSM) /3G(WCDMA) global bands.

It is unlocked (SIM free) and take single Nano SIM card. If any question during use, please email us, we will try our best to help you.

Our after-sales email:
2850699288@qq.com

Safety instructions

This phone is not water-resistant, keep it dry.

To prevent possible hearing damage, do not listen at high volume level for long time. Exercise caution when holding your device.

Table of Contents

▶ External features01

▶ Install SIM card02

▶ Install the battery02

▶ Turn on/off the phone.....03

▶ Unlock keypad03

▶ Charging03

▶ Save contact04

▶ Make call04

▶ Answer call05

▶ Send and receive SMS05

▶ Multimedia Settings06

▶ Bluetooth/Application.....07

▶ Settings07


▶ Speed Dial10

▶ SOS Settings.....10

▶ Torch Light.....11

▶ Product specifications.....11

External features



① LED indicator

② Earpiece

③ Torch

④ Volume +/-

⑤ Torch button

⑥ Menu key

⑦ Dial key

⑧ OK key

⑨ Navigation key

⑩ Charging indicator

⑪ Charging dock

⑫ Hang up key

⑬ Keypad unlock button

⑭ Return key

⑮ SOS button

⑯ Camera

⑰ Speaker


⑱ Headphone port

⑲ Micro USB

⑳ Dock connector


Install SIM card

Open the back cover from the bottom right corner of the phone (see figure1) and insert your SIM card (see figure 2).




Install the battery

Before starting up, please tear off the insulating sticker on the battery contacts, then install the battery and cover the back cover, please see the figure below:




Turn on/off the phone

Long press  for 5 seconds, the phone will turn on/off.


Unlock keypad


Unlock button is on the right side of the phone, you can slide it up to unlock keypad. If the unlock button is already at unlocked state, you can slide it again to unlock.



Charging

When the battery is low, please charge the phone in time. There are 2 ways for charging:

1 Charge the device via the charger directly.

2 Charge the phone by charging dock.

Save contact

For frequent contacts, you can save their phone number in the contact list by step:

Input his/her number on keypad

Options

Add to contacts

15989344683

Options

Delete

Call

Add to contacts


Write message


Call logs


OK

Back



Make call

Enter the phone number on keypad, and then press  to dial.

You can press  to turn on “handsfree” mode. See figure on the right:





Answer call


When coming call, press  key to answer or press  to hang up.


If there is a missed call or unread text message, the indicator on the phone will light up, you can see call history through “Call logs” menu.

Send and receive SMS

You can press  button to write SMS under “Message” menu. When you receive SMS, please view it in the “Inbox”. Under “Message” menu, you can set “Broadcast message” and “Voice mail server”. See figure below:













Multimedia Settings (Radio and Camera)

In “Multimedia” menu, you can see submenu “Camera, DV, Audio, Video, FM radio”, see figure on the right:




You can use   to move the cursor and press  key to enter photo mode. And then press  key to take photo. Using the same steps, you can use DV, Video, Audio functions.

Regarding FM radio, when you enter the menu, need use “auto search and save” in the Options menu to find out nearby radio stations. See figure below:



Bluetooth/Application


Under “Application” menu, you can see submenu “Calendar, Calculator, Recorder, Clock, STK, Unit conversion, Bluetooth, Internet, My files”.


Regards “Bluetooth” function, you can press  key to activate it and then select “ Paired device” to search for nearby Bluetooth device. See figure below:


Bluetooth

Bluetooth

Paired device







Settings

In “Settings” menu, you can see submenu “ Phone settings, Call settings, Profiles, Display, Security, Connections”

Settings

Phone settings

Call settings

Profiles

Display

OK

Back

Settings

Profiles

Display

Security

Connections

OK

Back

Phone settings

Time& date, language settings, shortcut settings, auto power on/off, restore factory settings”.

In “Phone settings” menu, you can restore the phone to factory settings. **Please backup your data before restore factory setting, the data will be lost after restore factory. The default restore factory password is “0000”**

Call settings

Call divert

Call waiting



Call barred

Hide ID

OK


Back

Profiles

Normal, Silent, Meeting, Indoor, Outdoor. If you want to change “Profiles” setting, press  key to enter “Options” menu, and then press  key to select “Customize”. You will see “Rename, Ring settings, Adjust volume, Ring type, Other alert rings” See figure below:



Speed Dial

For some frequent contacts, “Speed dial” can dial them quickly. Key 2~9 can be set as speed dial keys. See figure below:



After the frequent contact is set, press the corresponding key for 5 seconds, the phone will call the corresponding person automatically.

SOS Settings

When user is in an emergency, he/she can press  button on the back of the phone to call and send SMS to pre-set emergency contacts by pressing  button for 5 seconds. You can pre-set 5 contacts and 1 SOS message. See figure below:

SOS Setting

SOS Turn On/off

Set SOS Numbers

SOS Message

Emergency! I Need help!!!

Cancel

Back

Set SOS Numbers

NO.1:

15989344683

NO.2:

NO.3:

Select

Back


SOS Message

Emergency! I Need help!!!

Clear

Torch light

You can slide up/down key on left side of the phone to turn on/off torch light.



Product specifications

Model No.	UNIWA V1000
Dimensions	122.5*56.3*15.1mm
Weight	114g (include battery)
Material	Plastic
Style	Bar
Service	Unlocked
SIM	Single Nano SIM card single standby
Band	2G: GSM 850/900/1800/1900MHz
	3G: WCDMA 850/900/1700/1900/2100MHz
	4G: FDD-LTE B2/B4/B5/B7/B12/B13/B17/B66

Phonebook Number	1000
LED Indicator	RGB
Message	SMS/MMS
USB Port	Micro USB
Earphone Port	3.5mm audio jack
Speaker	2030 BOX loudspeaker
Screen	2.31 inch QVGA TFT display screen,320*240px
Camera	Single camera, 0.3MP back camera
Audio formats	MP3
Video formats	MP4 etc.
Radio	Wireless radio
SOS Function	Support preset 5 SOS emergency contacts and 1 emergency SMS
Torch	One key to turn on/off torch

BT	V3.0
Battery	Removable 1800mAh li-ion battery
Languages	English, Arabic, French, Hindi, Indonesian, Malayu, Portuguese, Russian, Spanish, Thai,
	Vietnamese, Italian, Turkish, Deutsch, Greek, Hebrew, Czech, Polish, Swedish, Ukrainian, Dutch, Simplified/Traditional Chinese.
Accessories	1 * Battery
	1 * Charger
	1 * Charging dock
	1 * User manual

EC


REP

Prolinx GmbH
Brehmstr.56,40239 Duesseldorf
Germany

CE

FC

RoHS



- 06

- 07

- 08

- 09

- 10

- 11

- 12

- 05

~~AAA~~ FCC Caution:

~~AAA~~ Any Changes or modifications not expressly approved by the party responsible for
~~AAA~~ compliance could void the user's authority to operate the equipment.

~~AAA~~ This device complies with part 15 of the FCC Rules. Operation is subject to the following
~~AAA~~ two conditions: (1) This device may not cause harmful interference, and (2) this device

~~AAA~~ must accept any interference received, including interference that may cause undesired operation

~~AAA~~ Note: This equipment has been tested and found to comply with the limits for a Class B digital
~~AAA~~ device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable

~~AAA~~ protection against harmful interference in a residential installation. This equipment generates,
~~AAA~~ uses and can radiate radio frequency energy and, if not installed and used in accordance with

~~AAA~~ the instructions, may cause harmful interference to radio communications. However, there is
~~AAA~~ no guarantee that interference will not occur in a particular installation. If this equipment does

~~AAA~~ cause harmful interference to radio or television reception, which can be determined by turning

~~AAA~~ the equipment off and on, the user is encouraged to try to correct the interference by one or

~~AAA~~ more of the following measures

~~AAA~~ Reorient or relocate the receiving antenna

~~AAA~~ Increase the separation between the equipment and receiver.

~~AAA~~ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

~~AAA~~ Consult the dealer or an experienced radio/TV technician for help.

~~AAA~~ Specific Absorption Rate (SAR) information

~~AAA~~ SAR tests are conducted using standard operating positions accepted by
~~AAA~~ the FCC with the phone transmitting at its highest certified power level in all tested
~~AAA~~ frequency bands, although the SAR is determined at the highest certified power level,
~~AAA~~ the actual SAR level of the phone while operating can be well below the maximum value. Before
~~AAA~~ a new model phone is available for sale to the public, it must be tested and certified to
~~AAA~~ the FCC that it does not exceed the exposure limit established by the FCC,

~~AAA~~ tests for each phone are performed in positions and locations as required by the FCC.

~~AAA~~ For body worn operation, this model phone has been tested and meets the FCC RF
~~AAA~~ exposure guidelines when used with an accessory designated for this product or
~~AAA~~ when used with an accessory that contains no metal and that positions the handset a
~~AAA~~ minimum of 5 mm from the body. Non-compliance with the above restrictions may result in
~~AAA~~ violation of RF exposure guidelines.