



### Product Specifications

Product name	Bluetooth earbuds
Bluetooth version	V 5.2 (QCC3040)B
Bluetooth distance	10M
Bluetooth name	W2
Input	DC 5V
Working time	Approx 6hrs single time
Battery capacity	2*30mAh
Charging case capacity	200mAh
IPX Rating	IPX4 (sweatproof)
Bluetooth protocol	A2DP/HFP/HSP/AVRCP
Decoding format	SBC/APT-X
Frequency response	20Hz-20KHz
Sensitive	108±3db
Impedance	16Ω
Charging case size	56.3*40.7*24.3mm
N.W	34.1g
Earbuds size	20.8*19.3*21.5mm
N.W	3.9g

### Using Guide

#### Bluetooth Connection

1. Open the charging case, the red and green light flash alternately.
2. Turn on Bluetooth on your device and select B2, click the connection to pairing. After the phone is connected, a "beep" sound prompt can be heard in about 5 seconds, the indicator light is off. (keep a distance of less than 20 cm between the left and right earbuds, and the earbuds can't link another device at the same time).
3. Use it again for the same device, the earbuds will remember and automatically connect back to the previous devices.

### Kindly Reminder

1. Single ear use supported. If you want to use just one bud, either of earbuds are ok. But please make sure both earbuds should be connected with your device successfully after first pairing.
2. When the earbuds are working normally, put them into the charging case to charge and power off automatically.
3. For first time use after unpacking, charge the case and earphones using the USB cable at least 10 minutes. Do not take the earbuds out during this time if the earbuds are at low battery.

### Operations

	Left	Right
Play/pause (▶)	x1	or x1
Next song (▶▶)		x2
Previous song (◀◀)	x2	
Volume control (▲) +		Hold & long press
Volume control (▼) -		Hold & long press
Voice activation (🗣️)		x3
Gaming mode (🎮)	x4	or x4
Exit gaming mode (🎮)	x4	or x4
Incoming call (📞)	x1	or x1
Reject call (📞)	x2	or x2
End call (📞)	x2	or x2
Power on/off Bluetooth pairing	Automatic	
Reset	Press L and R button quickly for 5 times at the same time in the charging case, restore the factory settings.	

### Power Display

Device	Light	Indicator
Charging case	Orange light	1%-20% Low battery
	Green light	20%-99% Breathes when charging
	Green light	100% Always on when fully charged
Earbuds	Flashes red	Low battery
	Red light	Charging (Inside case)
	Green light	Fully charged (Inside case)
	Red and green light cross flashing	Pairing
	Flashes green	Phone call

\*To charge the earbuds, place them in the charging case and close the lid.  
 \*To charge the charging case use the provided USB cable and plug it into a USB power supply.  
 \*A fully charged case provides 3 extra earbuds charges when on-the-go.

### Trouble Shooting

1. Make sure charging case has enough power.
2. Put the earbuds into the case and recharge for a while.
3. Take out both earbuds from charge case, waiting until the earbuds LED flashes red and green. This method only applies for right and left earbuds being not able to pair.
4. Failure to connect, check whether the earbuds are in searching status. Turn off other Bluetooth devices.
5. Small or distorted sound, test the volume of the device and adjust the volume to the suitable position.
6. The earbuds should be correctly and professionally used according to the requirements. Pay attention to the influence of the use environment on the earbuds. To ensure the smooth connection, it is recommended that the distance between the Bluetooth device and the earbuds be within 10M.

### Care and Maintenance

1. Earbuds should be stored in a dry and ventilated environment to avoid contact with oil, water vapor, steam, moisture and dust, so as not to affect product performance.
2. Charge the earbuds at least once every 6 months.
3. Do not use chemicals or detergents to clean the earbuds.
4. Do not drop or knock your earbuds on hard surfaces.
5. Do not scrape the surface with sharp objects.
6. If the earbuds is not connected or the communication is not smooth, etc., please do not try to take the product apart, otherwise it will not be guaranteed.
7. Please use the standard car charger or the charger specified by the company.

### Product Overview

**FCC Caution:**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.