
128g铜版纸



Warning Please follow the above safety instructions otherwise it

will cause fire, electric shock, damage and other damage.

1.Power Button

3. Battery Level Indicator

2.USB-C Port