

绿色虚线:是折痕 不用印出来

280 mm

100 mm

Instruction Manual



Introduction

Thank you for purchasing and using our products. Please read this manual carefully before using the product and keep it in a safe place for future reference.

Scenes to be used

This product has vibration, head rotation, internal and external stimulation at the same time, wearable functions in use, Turn on the vibration and experience different stimulation and pleasure.

product properties

product name	Massager	Item No.	MMA-031
Product Size	Length : 96 *135*33mm	Power supply	Polymer battery
Product material	ABS+silicone	Rated Voltage	≤3.7V
Noise figure	≤ 50 decibels	Battery Capacity	≤400mAh
Charging Mode	Magnetic charging	Color	
Product function	9 frequency rotating vibration/invisible wear		
Executive	Q/MM01-2020	Warranty	24 months
For the crowd	Adults		

Package Contents


Massager *1 Manual *1 Charging cable *1

USAGE NOTICE

1. Please read this product manual carefully before use. Follow the instructions in the instruction manual to the use.
2. Please charge the product for the first use.
3. This product is forbidden to be used by minors under 18 years of age.
4. Please keep the product clean after use. This product is a silicone product, please do not use corrosive cleaners to clean it

PRODUCT ICON



② MMA-031



① Long press the power button for 1.5 seconds to turn on/off. After turning on, short press to switch vibration Frequency, 9 frequencies

② Charging Port

③ Adjustable tightness



Remote control instructions

- ④ Power button, short press pause
- ⑤ Shake button, short press to switch vibration frequency, a total of 9 frequency

Remote control uses battery

1. Power supply is 1 section (3V, CR2032 battery)
2. Slow light when the power is not enough (prompt changing the battery)

Tip: The product charging indicator "breathing light" is always on when fully charged, it cannot be turned on when charging, and when the product is low in power, The indicator light flashes quickly to prompt charging

Charging instructions

1. This product is charged by USB power supply. Input voltage: 3.7V, input current 400mA
2. Connect the bSB cable to a USB power adapter (excluding this accessory) or USB port, You can use any USB power adapter for charging.
4. Please use the charger that match the parameter matching to avoid affecting the service life of the battery and the product destruction
5. In order to extend the battery life to ensure the charging effect, we recommend that you charge it before the appliance is reduced.

PRECAUTIONS

1. The inner polymer battery of this product, the battery cannot be disassembled by itself, please do not disassemble it yourself to avoid Destruction of the product.
2. After the product is used, it should be placed in a dry and ventilated place to avoid children's contact.
3. If you have discomfort during use, please stop this product. It is necessary to regularly check whether the product is damaged and discovered when it is damaged.
4. Built-in battery in the product, please do not discard it at will when you don't use it. Pay attention to protect the environment.
5. Do not let the battery come into contact with metal objects (including coins) to avoid short circuit and discharge of batteries. Heat or leakage.

70 mm

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

The devices has been evaluated to meet general RF exposure requirement , the device can be used in portable exposure condition without restriction