

VIVITAR[®]
CREATOR SERIES

Video Voyager
Universal Rig with Built-in Lighting



*Bluetooth
Shutter*



*Built-in
Battery*



*Tunable
Controls*



*Multi-
Device*



User's Manual

Item: VLEDRIG200-NOC

Safety Precautions

Before setting up and using your Video Voyager , basic safety precautions should always be followed including:

1. READ ALL INSTRUCTIONS BEFORE USING YOUR VIDEO VOYAGER.
2. This product is not a toy, do not allow children to play with it. Adult supervision is advised.
3. This product should not be exposed to extreme heat or fire. Do not store in a location with temperatures above 104°F.
4. Do not expose this product to any water, liquids, or excessive humidity.
5. Do not crush, throw or subject this product to extreme physical force.
6. Do not use this product if it appears to be cracked, broken or if the power cable is damaged.
7. Do not use in wet or humid environments. Do not place on wet surfaces.
8. Please recycle or dispose of the product properly based on the laws and rules of your municipality. Contact local recycling facilities and/or the manufacturer of the product for further information.
9. Do not hold the product by the LED Lights. Only handle with the side grips.
10. In order to avoid the risk of electric shock, never attempt to open your light or repair it without the assistance of certified professionals.



CAUTION

BATTERY WARNING:

- The device is equipped with an integrated lithium ion battery. The battery cannot be replaced. Do not attempt to remove the battery from the device.
- Do not dispose of in fire or expose to excessive heat.
- Do not crush, puncture, incinerate, or short circuit external contacts.
- Please recycle or dispose of the battery properly. Contact your local recycling facilities and/or the manufacturer for further information.

Introduction

Thank you for purchasing the Vivitar Video Voyager, item VLEDRIG200-NOC. Please read this manual carefully before using.

Package Contents

- Video Voyager
- Phone Holder
- Cold Shoe Mount Adapter with 1/4" Screw
- Type C Cable
- User's Manual with Warranty Information

Specifications

Power Supply: 1800mAh lithium battery


Number of LED: 200pcs

Product Size: 11.53*8.34*1.5 Inches

Light Colors: White/ Warm/ Warm White

Cable Type: USB-C


A Quick Look at Your Video Voyager



Charging


Connect the USB-C cable end (rounded connector) into the Video Voyager's bottom charging port. Connect the other USB cable end (rectangular connector) to a wall adapter (not included).

While charging an indicator light on the product will illuminate red. When fully charged the indicator light will turn OFF.



Tripod, Stand, Camera, and Phone Mounting



The Video Voyager features built-in side and bottom tripod mounts. These can be used to mount the light to a tripod, light stand, or a camera's cold shoe via the included adapter.



To attach a smartphone device to the Video Voyager, place your smartphone into the included phone holder, ensuring it is securely in place. Once the smartphone is secure, screw the phone holder to the inner mounting screw.

Connecting to Bluetooth

To connect the Video Voyager to your mobile device, press and hold the Bluetooth button for approximately three seconds until an indicator light flashes blue.



Go to the Bluetooth settings menu on your phone. Make sure that Bluetooth is turned on. Connect to the device listed as "VIDEO VOYAGER."

While connected to a device through a Bluetooth connection, press the Bluetooth button to take a photo with the connected Bluetooth device.

NOTE: Certain features may be limited or disabled depending on the connected device.

Using the Video Voyager

Multifunction Button:

-Press the multifunction button to turn the LED panels ON/OFF. Make sure to point the LED Panels away from you before turning ON.

-While ON, press to cycle through the following modes: Warm white, warm light, white, and OFF.

Bluetooth Button:

-Press and hold the Bluetooth button for approximately three seconds to enable a Bluetooth connection.

-While connected to a device through a Bluetooth connection, press the Bluetooth button to take a photo with the connected Bluetooth device.

Brightness Knob:

-Use the knob to adjust the LED Panel's brightness.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Vivitar One Year Warranty

This warranty covers the original consumer purchaser only and is not transferable.

This warranty covers products that fail to function properly UNDER NORMAL USAGE, due to defects in material or workmanship. Your product will be repaired or replaced at no charge for parts or labor for a period of one year.

What Is Not Covered by Warranty

Damages or malfunctions not resulting from defects in material or workmanship and damages or malfunctions from other than normal use, including but limited to, repair by unauthorized parties, tampering, modification or accident.

To Obtain Warranty Service and Troubleshooting Information:

Call 1-800-592-9541 or visit our website at www.vivitar.com.

To receive warranty service along with the name and address of an authorized product service center, the original consumer purchaser must contact us for problem determination and service procedures. Proof of purchase in the form of a bill of sale or receipted invoice, evidencing that the product is within the applicable warranty period(s), MUST be presented in order to obtain the requested service. It is your responsibility to properly package and send any defective products along with a dated copy of proof of purchase, a written explanation of the problem, and a valid return address to the authorized service center at your expense. Do not include any other items or accessories with the defective product. Any products received by the authorized service center that are not covered by warranty will be returned unrepared.

VIVITAR®

©2024 Sakar International
195 Carter Drive
Edison, NJ 08817
Support: 800 592 9541
www.vivitar.com