



I . Product Introduction

1. Packing List



2. Product Buttons Overview



1

II . Direction For Use

1.Buttons Instruction



① ON/OFF Button:

Short press to turn on/off the Product.

NOTE: When the Product is turned on, the bluetooth is also automatically turned on. You can search for the bluetooth name " WH-E22 ", and connect to it to play the music in your cell phone via bluetooth. If the Product has not been connected after 10 minutes, Bluetooth will be automatically turned off.

NOTE: The Product has light memory function which returns to the light effect of last time use (but only when the power is not cutted off).

NOTE: The Product will be turned off automatically after a continual work of 8 hours in order to prolong the life of lamp beads.



② Northern Light Colors & Brightness Switching Button

(a) To switch color of northern lights: Short press this button will switch successively in the following colors order (blue & green mix → yellow → white → gradiently changing colors).

2

(b) To adjust brightness: Long press this button to adjust the brightness of northern lights from low → high → low again in cycle.



③ Built-In Audio Source & Bluetooth Mode Switch Button:

Short press to switch built-in audio source & Bluetooth mode;

When the Bluetooth mode is turned on, the mobile phone searches for the Bluetooth name "WH-E22" to connect to play music.




④ Next Song & Volume+/- Button

(a) To switch songs: Short press to play next piece.

NOTE: If you want to turn off the music, please press the button on the Product to enter into bluetooth mode.










(b) To adjust volume: Long press this button to adjust volume from low → high → low again in cycle.
(When the volume reaches maximum/minimum, there will be a notification tone).









2. Remote Control Instruction



Note:

- Please pull out the insulating strip at the bottom of the remote control before first use.
- Please point the remote directly to the Product within 3 meters to receive signals better.

①		Power on/off
②		Brightness Adjustment: There are 3 levels of brightness. Short press to switch from high brightness - medium - low.
③		Northern Lights Flowing Speeds Switching: There are 3 levels of flowing speeds for the northern lights. Short press to adjust the flowing speeds from fast - slow - static.
④		Turn ON Red Light
⑤		Turn ON Green Light
⑥		Turn ON Blue Light
⑦		Turn ON White Light
⑧		Turn ON Yellow Light
⑨		Multi Colors Gradiently Changing Mode Button: Short press to enter multi colors gradiently changing mode, short press again to fix to the current color.


⑩		Yellow Series Colors Switching: There are 4 yellow series colors, short press to switch from light red - orange - light orange - yellow.
⑪		Green Series Colors Switching: There are 4 green series colors, short press to switch from dark green - light green - blue - dark blue.
⑫		Purple Series Colors Switching: There are 4 purple series colors, short press to switch from light blue - purple - light purple - pink.
⑬		Built-in audio source & Bluetooth mode switching
⑭		previous/next song
⑮		volume +/-
⑯		Auto OFF Cancelling Button: Short press to cancel the auto off function. When the 1/2/4H auto timer has been successfully cancelled, the northern lights will flicker in red for 2 times.
⑰		1/2/4H Auto Off Button: Short press this button, The Product will be turned off automatically after 1/2/4H hrs. When the 1/2/4H auto timer has been successfully set, the northern lights will flicker in green for 2 times.

3. Plug in Instruction

① The product does not has a built-in rechargeable battery and needs to be plugged in to power supply for use. It needs to be connected to a suitable adapter which is plugged in to power supply. Please do not place it in a high-temperature environment.

② Please use an adapter with an output voltage of 5V/2A.

III. Parameter Information

Product Name	INS Style Northern Lights Night Light
Product Model	WH-E22
Product Size	120*120*140mm
Input	5V  2A
Rated Power	10W MAX
Product Specification	Plug-in Remote Blue-tooth

IV.Warning

1. DO NOT disassemble this product by yourself.
2. Please DO NOT use the product in humid and high-temperature environments;
3. The light source contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar qualified person;
4. Please cut off the power when you have not used the Product for a long time;
5. When the Product is in regular use, do not place it on an inclined surface more significant than 6°;
6. Please use an adapter with compliance certification;
7. Children under 14 need to use it properly in the custody of adults.
8. This product contains a light source of energy efficiency class F.

Coin cell battery Warning:

1. Do not ingest battery, Chemical Burn Hazard;

2. The remote control of this product contains a coin / button cell battery. If the coin / button cell battery is swallowed, it can cause severe internal burns in just 2 hours and can lead to death.

3. Keep new and used batteries away from children. If the battery compartment does not close securely, stop using the product and keep it away from children. If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.

FCC warning:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

The equipment complies with FCC Radiation exposure limit set forth for uncontrolled environment. The device shall be operated and installed without restriction.