

FRONT

WIRELESS SPEAKER
ECHO



FCC ID: 2A3E7-S1
For Use with
Bluetooth
enabled devices

USER
MANUAL

YOUR IJOY PRODUCT

Thank you for purchasing and using the IJOY ECHO® wireless Bluetooth® speaker. This product can provide a high quality listening experience for your mobile phone, computer and other media devices. Before using this product, please read the user manual carefully. If you have any questions, please contact your local dealer.

IJOY ECHO Bluetooth® Speaker X1

Cable X1

FCC WARNING: This device with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) The device may not cause harmful interference, and (2) the device must accept any interference received, including interference from authorized radio transmitters that may be co-located with the device. If you experience interference, you should turn the device off and try to identify the source of the interference. If you cannot identify the source of the interference, you should turn the device off and contact your local dealer for help.

CAUTION: This device with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) The device may not cause harmful interference, and (2) the device must accept any interference received, including interference from authorized radio transmitters that may be co-located with the device. If you experience interference, you should turn the device off and try to identify the source of the interference. If you cannot identify the source of the interference, you should turn the device off and contact your local dealer for help.

CAUTION: This device with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) The device may not cause harmful interference, and (2) the device must accept any interference received, including interference from authorized radio transmitters that may be co-located with the device. If you experience interference, you should turn the device off and try to identify the source of the interference. If you cannot identify the source of the interference, you should turn the device off and contact your local dealer for help.

FCC STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) the device must accept any interference received, including interference from authorized radio transmitters that may be co-located with the device. If you experience interference, you should turn the device off and try to identify the source of the interference. If you cannot identify the source of the interference, you should turn the device off and contact your local dealer for help.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the requirements of part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can be affected by radio frequency interference. However, there is no guarantee that interference will not occur under all conditions. If interference does occur, you may need to take the following steps: Turn the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

1. Increase the separation between the equipment and receiver. Connect the equipment to an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

2. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

BATTERY CAUTION

The battery used in this device may present a risk of fire, explosion or chemical burn if used incorrectly. Never use or charge the battery if it appears to be failing, discolored, deformed or in any way abnormal. Never expose the battery to any liquid. Never expose the battery to excessive heat or cold. Always keep the battery out of the reach of infants and small children.

BATTERY DISPOSAL

Please do not attempt to change the battery yourself. If the battery has died, you should follow the disposal instructions listed here. Never dispose of used batteries/electronics in accordance with the prevailing community regulations that apply to the disposal of used batteries/electronics. Please dispose of this device in a waste bin for electronic devices. Many electronics retailers now recycle batteries and other electronic components at no charge.

BACK

INSTRUCTIONS

POWERING ON
To power on the media device with the speaker using the audio line and power cable, turn the power switch to ON. The blue indicator light will turn on and you should hear a sound indicating the device has turned on. Please refer to the media device user manual for more information.

PARKING THE DEVICE
• Enable Bluetooth on the device you want to connect the speaker to. The speaker will start playing from the speaker.

CHARGING
• The charging cable provided with this product and connect it to a power source with output voltage 5V. Do not use high voltage power source. The charging cable will start charging and will go out once charging is complete.

POWERING OFF
• Turn the power switch to OFF to turn off.

LIMITED LIFETIME WARRANTY

Our product is warranted for One (1) year limited warranty from the date of purchase. The warranty is voided on all material defects and workmanship. Guarantee of 12 months does not apply to decrease in the accumulator effective capacity caused by its use or age. Effective capacity of the accumulator will decrease over time. We reserve the right to change technical specifications. For more information please visit: www.goloy.com

Goloy USA, Corp
495 Flatbush Ave.
Brooklyn, NY 11225

© GOLLOY & LOJOY are registered trademarks of Goloy USA, Corp. All other trademarks and trade names are property of their respective owners. One (1) year limited warranty. To activate your product warranty, go to our website www.goloy.com and register this product.

Made in China.

LOT# 18001009

PLEASE FOLD ON THE GREEN LINES AND PRINT DOUBLE SIDED. DO NOT PRINT GREEN LINES