

FOLD

FRONT

WIRELESS CHARGER WITH STAND
CHARGE



USER MANUAL

Thank you for purchasing and using the "IJOY CHARGE" wireless charger with stand. This product can charge any device enabled with wireless charging. Before using this product, carefully read this manual in order to operate at maximum benefit. Please ask your local dealer or call us if you have any questions.

IJOY CHARGE x1
Charging Cable x1
User Manual x1

FCC ID: 2A3E74V2
Model: IJWC2101

Questa USA CORP
495 Flatbush Ave,
Brooklyn, NY 11225

© GoJoy & IJOY are registered trademarks of Quest USA Corp. All other trademarks and brand names are property of their respective owners. Designed by GOJOY & IJOY in New York. All rights reserved. Limited Lifetime warranty. To activate your product warranty, go to our website www.gojoy.com & register this product.

Made in China

• YOUR IJOY PRODUCT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

• FCC STATEMENT

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

• SPECIFICATIONS


Input: 10W
Input: 5V/2A (X1) 5V/7A
Output: 10W, 25W 5W
Charging Distance: ≤8mm
Charging Conversion Rate: ≥76%

BACK

INSTRUCTIONS

- Put the charging pad on the stand.
- Connect the charging cable to the bottom of the charging pad next to the bottom bracket. Put the charging cable in the slot and slot and press it tightly.
- Put on the protective film on the bracket and stand.
- Place your mobile phone in the center of the pad and your device will begin to charge.

After connecting to the power source, the LED indicator will turn red indicating a standard charge. After the device is charged, the LED indicator will turn green. When a foreign object is placed on the charging pad, the FOD (Foreign Object Detection) LED indicator flashes once per second until the foreign object disappears.



• OTHER IMPORTANT SAFETY INFORMATION

To avoid danger of suffocation, keep plastic bag away from babies and children. Do not use this bag in cribs, beds, carriages or playpens. This bag is not a toy. Do not let children play with this bag.

(Applicable in the European Union and other European Countries with separate collection systems). The trash can symbol seen on bottom right of the product indicates that this product must not be disposed of with normal household waste. Instead it shall be handed over to the applicable collection point for recycling of electronic equipment. The recycling of this product in an appropriate way will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste disposal. For more information about this product, please contact your local household waste disposal service or the shop where you purchased this item.



• LIMITED LIFETIME WARRANTY

Our product is warranted for a limited lifetime warranty from the date of purchase. The warranty is provided on all material defects and workmanship. Guarantee of 24 months does not apply to damage in the effective cause of a user error or misuse. WE RESERVE THE RIGHT TO CHANGE TECHNICAL SPECIFICATIONS. For more information please visit www.gojoy.com,

**ATTENTION VENDOR: PLEASE FOLD ON GREEN LINES AND PRINT DOUBLE SIDED
DO NOT PRINT GREEN LINES WITH MANUAL**

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.