

Notice

If the remote controller has no response or you change a new one, the remote controller and walking device need to re-establish communication. Restart the Walking device, at the same time press and hold down the mode switch button on the remote control for 6 seconds, hearing the sound of "Beep" indicates the success of pairing.

FCC ID: 2A3Y6-TMAK101