TURN ON	BLUETOOTH CONNECT	CHARGING		Bluetooth
Take the two earbuds out of the charging case. They will automatically turn on. Once the earbuds have powered up, you should hear a sound indicating that they have automatically connected with one another. TURN OFF Long press the control button until LED turns red to indicate not in use, this will turn off your device. Earbuds will turn off automatically if away from case for more than 5 mins.	 Power the device on. The earbuds will pair with one another automatically when they are turned on. Turn on your device's Bluetooth from the Bluetooth menu and select "MV-EB5580". When paired successfully the device will make a tone to confirm the connection has been made to your device. Remember to turn the earbuds off after each use to ensure longest play time. 	 EARBUDS: Just place the earbuds into the charging case. The earbuds will automatically enter charging mode if the cradle is charged or connected to the power supply. The earbuds will display a red LED light while they are charging, and turn off when they are fully charged. CASE: Use the cable provided to connect the charging case to the power supply. VOICE ASSISTANT To activate the voice assistant (i.g., Siri), quickly press the right earbud's control button. 	 PLAY/STOP MUSIC: When playing music, quickly press either earbud's control button. VOLUME CONTROL: Double press left earbud to increase volume, and right to decrease. ANSWERING CALL: When a call is received, briefly press either earbud's control button. To hang up, briefly press once again. REDIAL: Triple press the left earbud's control button quickly to dial last number on your list. DECLINING CALL: When playing music, press and hold control button for 1.5 seconds*. 	<text><text><text><text></text></text></text></text>

FCC Disclaimer:

This device Complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1- This device may not cause harmful interference, and
- 2- This device must accept any interference received, including Interference that may cause undesired operation. The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off

and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or on experienced radio/TV technician for help or assistance.

RF Exposure Information The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

This device complies with Part 15 of the FCC Rules and Industry Canada license-exempt RS5 standard(s). Operation is subject to the following two conditions;

- 1- This device may not cause harmful interference, and
- 2- This device must accept any interference received, including interference that may cause undesired operation. The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment. Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for

- the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.
- Electronic and electrical devices disposal

 $\lambda \Delta$

This symbol indicates that electrical and electronic device is to be collected separately.

This product is designated for separate collection at an appropriate collection point. Do not dispose of as household waste.

- If the device use batteries, they must be removed from the device and disposed in a appropriate collection center.
- If the batteries cannot be removed, do not attempt to do it yourself since it must be done by a qualified professional.
- Separate collection and recycling helps conserve natural resources and prevent negative consequence for human health and the environment that might result from incorrect disposal.

PARAMETERS

Bluetooth version: v5.1

Frequency: 2.4 - 2.48 GHz

- Battery capacity: 30mAh each
- Total playtime*: 2 hours (16 hours with case)
- Total standby time: 300 hours
- Bluetooth range: Up to 30 ft
- Waterproof rating: IPX4

CHARGING CASE

Battery capacity: 300mAh Charging time: 2 hours Universal micro-USB charging

*Depends on individual use Warning: To prevent possible hearing damage, do not listen at high volume levels for long periods.





INSTRUCTION MANUAL: EB5580

TRUE WIRELESS SPLASHPROOF EARBUDS WITH CHARGING CASE