

ETOE

androidtv



Quick Reference Guide

Please read the user manual before operating the TV box

Safety instructions

- Please keep the product in horizontal position. Do not place anything on the top of the TV box.
- Please use the power adapter provided by the manufacturer, Do not use the power adapter if it is damaged.
- Please avoid to touch the power adapter with wet hands.
- To avoid any potential risk of electrical shock or damage do not disassemble or modify the TV box.
- Please keep the TV box away from any heat sources to avoid damage. The device should be keep in a dry and well-ventilated area away from dust that may cause fire or electric shock
- Please promptly shut down and unplug the device power adapter if it begin emitting smoke or any unpleasant odors.
- Please unplug the device power adapter when not in use for a long periods of time.

Accessory List

Please open the package and check the following accessories:



TV Box x1



User Manual x1



Remote Control x1



Power Adapter x1




USB Cable x1



HDMI Cable x1

Hardware Structure


- Top view




- Bottom view



- Left view



- Right view



- Front view



Micro-USB

- Back view



HDMI

Technical Specifications


CPU	ARM Quad 64-bit Cortex-A53
Operating System	Android™ 11 for Android TV™
Video/Audio output	HDMI
Video format	H.265 10-bit 4K*2K@60fps, VP9 4K*2K @60fps, AVS2-P2 up to 4K*2K@60fps, H.264 AVC 4K*2K@30fps, MPEG1/2/4 ASP,AVS+, RealVideo8/9/10
Audio format	MPEG-1/2/3, MP3, MP4, AAC, etc
Photo format	JPG, BMP, PNG and other photo formats
Network	Wi-Fi 2.4G/5G Hz 802.11a/b/g/n/ac
Operation temperature	0°C~40°C
Power	Input: AC100-240V 50/60Hz
	Output: DC 5V/1A
Power consumption	<5W

Troubleshooting

Issue	Possible reason	Solution
No display after powered on	The power cord is not connected or the outlet is not powered.	Connected the power plug and ensure the voltage of the socket is normal.
TV with images without Voice	TV box in MUTE state	Please press mute button to restore volume
	Volume is too low	Turn up the volume
Fail to connect the network	Wi-Fi closed or the signal is too weak	Please restart the Wi-Fi or adjust the position of Router
Controller failure	Remote is not paired correctly to the TV box	Please re-pairing
	Remote control is with low battery	Please change the batteries
	Remote control is broken	Please send it to the local maintenance station for checking

Google, Android TV and Chromecast built-in are trademarks of Google LLC.

Remote Control




Instructions

- 1.Indicator Light:** Pressed any keys that indicator light will flash; When Low voltage that indicator light will flashes quickly .
- 2.Bluetooth Pairing :** Pressed the "Home" + "Back" keys together on your Remote Control for 10 seconds.
- 3.Google Assistant :** Press the Google Assistant button on your remote to talk to Google.

System Connection

Please refer to below pictures and instructions to connect TV box .

Note: Please turn off all equipment (such as TV box and TV power) before connecting.



Step1 Connection with TV

Connect the HDMI cable to the TV box and the TV .

Step2 Connection with Power

Connect the USB cable to the TV box and the power adapter.

Plug the power adapter into A/C outlet.

If TV has a powered USB port, it can also plug the micro-USB cable directly into the TV port.

Note: Some USB ports don't provide enough continuous power. You need to connect with A/C power outlet through power adapter.

Network Setting

Enter **Settings**→**Network** to turn on Wi-Fi and connect an available Wi-Fi network with correct password.

FCC Warning

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.



MADE IN CHINA