

PN-W27

尺寸:70 * 105 mm


105克铜版纸

折页

彩色印刷

风琴折


Fokimdo
5000mAh
Magnetic Wireless Portable Charger



User Manual PN-W27

Thank you for using our product. In order to provide an easy user experience, we have provided detailed information about the product and instructions for use. Please read the instructions carefully before using this product so that you can use it correctly.

1. Product Details



2. Product Parameters



Light-ning Input	5V/2A
TYPE-C Input	DC5V/2.4A 9V/2A 12V/1.5A
TYPE-C Output	DC5V/3A 9V/2A 12V/1.5A (MAX=18W)
Wireless Output	5W 7.5W 10W
Battery Capacity	5000mAh/3.7V 18.5Wh

3. Package Includes

- 1* Magnetic wireless power bank
- 1* Type-c to Type-c cable
- 1* Instruction

4. Product Features

1. Exclusive design - fashionable and beautiful.
2. Original A-class polymer battery provides safety and stability.
3. Wireless output, compatible with all Qi-enabled phones.
4. The strong magnetic portable design can perfectly absorb the mobile phone (iPhone12 series or later) and is not easy to drop.
5. The fast charging function quickly charges your digital devices.
6. Two-speed adjustable angle bracket design, you can choose horizontally or vertically.


5. Instructions

1) Turn on/off
Press the power button to turn on the power bank. The LED battery indicator lights up. If there is no charging device connected, the power bank will automatically shut down after 30 seconds.

2) Charging the power bank
Plug one end of the cable into the type-c or light-ning port on top of the power bank. Plug the other end into the USB port of the adapter. The LED battery indicator will flash when charging and the LED battery indicator will light up when fully charged.

3) Charging a phone or other digital product
• Wired charging
Press the power button to turn on the power bank. The LED battery indicator lights up. One end is connected with the digital product, and the other end is connected with the output port of the product.


• Wireless charging
Turn on the power switch, and the green indicator light of wireless charging on the back is on. As illustrated below, align the built-in wireless sensing area of the mobile phone (such as the iPhone logo) with the wireless charging area of the product to wirelessly charge the mobile phone



• Notice:
① If you use a wireless charger to charge your mobile phone, the mobile phone protective case must not contain metal materials, and the thickness of the protective case must not exceed 4mm.

6. Product Maintenance

1. Keep it away from wet environments and corrosive substances.
2. Please do not use chemicals to clean the power bank.
3. Please charge the power bank at least every six months, if not using it regularly.



7. Troubleshooting

Q: There is no way to use the wireless charging function when the mobile phone is placed on it

A: Please turn on the power switch after placing the mobile phone, the green indicator light of wireless charging on the back will light up, and it can be charged normally

FCC Statement
Changes or modifications not expressly approved by the party responsible for compliance could void the user authority to operate the product.
NOTE: This equipment has been tested and found to comply with the limits for a wireless power charger, pursuant to Part 18 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

Q: There is no way to absorb the mobile phone or the magnetism is not strong

A: The magnetic suction function only supports iPhone 12/iPhone 13 series and later. Previous devices are not supported.
* Please check whether the phone case of your phone is a magnetic phone case. It is not compatible with non-magnetic phone cases.

Q: When turning on the power bank, only the blue LED battery indicator flashes.

A: Battery power is about to run out. Please charge the power bank immediately.

Q: When turning on the power bank, the wireless charge red LED lights up.

A: Indicates a foreign object detection. Please check whether there is metal in the phone protective case. Please check whether the phone is in the wireless charger area.

Q: Unable to charge the power bank.

A: Replace the adapter and charging cable, then try charging again.

Q: Unable to charge the phone or digital product

A: Please disconnect and then reconnect the charging cable.

Q: Charging for a long time but can not be fully charged

A: Please make sure you are only using the charging cable that came with the product and an adapter that supports 5V/2.1A or more output.

-- Please check whether the button is flexible.

--Please check whether the charging indicator is normal when charging.

--Please check whether the USB input cable is in working condition and whether there are any problems after connecting the power bank.

--Please check whether the USB output cable is in working condition and whether there are any problems when connecting the device that needs to be charged.

--Please check whether there is abnormal noise or odor coming from the product.

--Please do not disassemble or reassemble the power bank. Doing so will negate the warranty.

8. Warranty and After-Sales Service

1. Every fokimdo product is provided with 12 months of warranty from the date of purchase.
2. If you have any problems with our products or services, please contact our dedicated customer service at support@fokimdo.com. We usually get back to you within 24hours during business days.

9. Tips

1. In order to ensure the best magnetic absorption effect, remove the phone case to charge. The phone will be more firmly absorbed.
2. The magnetic function is only available for iPhone 12/iPhone 13 series and later.
3. The wireless charging function may be affected if the phone case is made from metal or glass.
4. You need to turn on the power switch first. When the green indicator light of the wireless charging on the back lights up, it means that the power supply has started. When you want to use the stand function alone, do not turn on the power switch.

please contact our after-sales service department at support@fokimdo.com

Fokimdo
Magnetic Wireless Portable Charger

1

2

3

4

5

6

7

8

9

10

11

12