

RK R65 说明书折页: 128g双铜四色印刷

正面

反面

R65Pro MECHANICAL KEYBOARD

PC: 285X20 88#

FCC WARNINGS

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference that may be received, including interference from authorized radio communication systems.

2. This device has been tested and found to comply with the requirements in Part 15 of the FCC Rules, Section 15.247, Subpart C, for Class B digital devices. The limits are derived from the Commission's rules for protection of residential radio frequency emissions.

WARRANTY STATEMENT

1. This keyboard is warranted to be free from defects in materials and workmanship under normal use for a period of 12 months from the date of purchase.

2. This warranty does not cover damage caused by misuse, accident, or unauthorized repair.

3. For more information, please contact our customer support.

12 MONTHS GUARANTEE

Replacement or Repair (at our discretion)

PRODUCT BASIC

Manual

Size: 122.5x118.5x40.5mm/1:2

Switch and Keycaps Puller

Backlight: Monochrome/RGB

Keyboard

Version: USB2.4G/BT

USB Type-c cable

Layout: 108keys

2.4G Dongle

Switch: Mechanical switches

INDICATOR LIGHTS/KNOB FUNCTION

KNOB FUNCTION

- Clockwise: Volume+
- Anticlockwise: Volume-
- Press: Mute

WIRED MODE

Recommend: Using 5V 1A Rated power to charge keyboard

BT CONNECTIVITY

Place the switch to "B" side.

Short press Fn+Q/W/E to change BT channel.
Long press Fn+Q/W/E entry pairing mode.

Turn on the bluetooth of computer/phone/other devices, find and link to the keyboard whose name on the list shows as R65.

2.4G CONNECTIVITY

Place the switch to "G" side.

Short press Fn+P to change 2.4 channel.

If the P key flickers slowly, it indicates that your device is successfully linked to the computer.
(KINDER REMINDER: The receiver is factory paired and does not need to be paired again.)

BATTERY REMINDER

In BT 2.4G mode, Press and hold Fn+Enter to view the battery level indicator

For Example:

The backlight is bright, indicating that the keyboard is 10% of the power at this time

The backlight is on at the same time, indicating that the keyboard is 20% of the power at this time

Similarly

The backlight is on at the same time, indicating that the keyboard power is 100% at this time

DFU MODE

There are two methods to enter dfu mode (development Firmware upgrade) on the keyboard:

Method 1: Press and hold the switch located under the space bar, and then connect the keyboard to the computer.

Method 2: Connect the keyboard to the computer first, and then simultaneously short press Fn + Right Shift + Esc.

These methods allow you to activate the DFU mode on the keyboard, enabling firmware upgrades and development functionalities.

The keyboard can support VIA drivers: <https://www.via.com.tw/>

R65Pro MECHANICAL KEYBOARD

PC: 285X20 88#

FCC WARNINGS

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference that may be received, including interference from authorized radio communication systems.

2. This device has been tested and found to comply with the requirements in Part 15 of the FCC Rules, Section 15.247, Subpart C, for Class B digital devices. The limits are derived from the Commission's rules for protection of residential radio frequency emissions.

WARRANTY STATEMENT

1. This keyboard is warranted to be free from defects in materials and workmanship under normal use for a period of 12 months from the date of purchase.

2. This warranty does not cover damage caused by misuse, accident, or unauthorized repair.

3. For more information, please contact our customer support.

12 MONTHS GUARANTEE

Replacement or Repair (at our discretion)

BACKLIGHT CONTROL

In USB mode, the backlight brightness is brightest by default. In wireless mode, the backlight is slightly dimmer by default.

Backlight Brightness +	Backlight Speed -	Switch to windows system	PrintSc
Backlight Brightness -	Backlight Speed +	Switch to mac system	Home
Backlight Mode Switching	(RGB version only) Backlight Monochrome Switching	Insert	Scroll
Windows Lock	Switch between six-key rollover and full-key rollover	Pause	~
Press And Hold For Three Seconds To Restore Factory Settings	End		

SECONDARY COMBINATION FUNCTION KEYS

F1	F2	F3	F4	F5	F6
F7	F8	F9	F10	F11	F12

MULTIMEDIA KEYS

Windows system (Fn + A: switch to Windows system) MAC system (Fn + S: switch to Mac system)

Press Fn+Left Ctrl together to switch functions between F(1~F12) and number keys of the first row.

WIN: Computer	WIN: Browser	WIN: Mailbox	WIN: Calculator	WIN: Power	WIN: Sleep
MAC: Screen Brightness -	MAC: Screen Brightness +			MAC: Keyboard Backlight Brightness -	MAC: Keyboard Backlight Brightness +
WIN: Last Song	WIN: Play / Pause	WIN: Next Song	WIN: Mute	WIN: Volume -	WIN: Volume +
MAC: Last Song	MAC: Play / Pause	MAC: Next Song	MAC: Mute	MAC: Volume -	MAC: Volume +

Have an issue with one of our RK products?

Feel free to contact us with any product issues or questions. We will reply as quickly as possible to ensure all your needs are handled. For better technical support, please contact rkgameing@rkgameing.com

File Name: 0827-1408-0210
 Model: R65 Pro www.rkgameing.com
 Download Center Address: www.rkgameing.com/Download/ 156-83081-01