说明书文件

Z677 说明书

折后尺寸: 90*65mm

材质: 70g双胶纸


工艺: 单张单面单色印刷, 风琴折


455 mm


65 mm











HOW TO USE:



Description Multifunction Magnetic Stand 68 x 64 x 24.6 mm Extended length 36 mm

Compatibility

· iPhone 12/13/14 or later models that support MagSafe.

Input: 5V/2A, 9V/2.22A Parameter

ZIKE

ZIKETECH LLC 200 CONTINENTAL DRIVE STE 401 RM434 NEWARK ,DE 19713

ZIKE TECHNOLOGY (HK) CO., LIMITED / 齊客科技(香港)有限公司 ROOM 21 UNIT A, 11/F, TIN WUI INDUSTRIAL BUILDII NO. 3 HING WONG STREET, TUEN MUN, N.T. HK 香港新界屯門聊旺街3號天匯工業大廈11樓A單元21室

GUANGDONG ZIKE TECHNOLOGY CO.,LTD / 广东省齐客科技有限公司 ROOM 903 9TH FLOOR, BLOCK B DATANG TIMES BUILDING, NO. 2203 MEILONG AVENUE, LONGHUA DISTRICT, SHENZHEN 深圳市龙华区梅龙大道2203号大唐时代B座9层903室

⊕ www.ziketech.com ♦ +1(925)639-9430

■ support⊕ziketech.com

F©C€@\\\\

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that to which the

-Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.