


尺寸: 95x105(mm) 2折3页
 材质: 128克 铜版纸
 颜色: 单色印刷


Aroma Diffuser User Manual



Aroma Diffuser

User Manual


This Aroma Diffuser uses Ultrasonic Technology to atomize the water and essential oil in the water tank, and produces a cool, humid and fragrant mist.



Aroma Diffuser

Operation


- Open the top cover. (Fig. 1)
- Connect the DC plug of the adapter to the DC socket of the machine through the wire slot. (Fig. 2)
- Add water to the water tank, do not exceed the maximum water level of 350ML. (Fig. 3)
- Put 3-5 drops of essential oil into the water tank. (Fig. 4)
- Close the cover.
- Insert the adapter plug into the household power outlet.
- Spray button: (Fig. 5)
 - Press it once: one beep, the machine starts to work in small mist mode, which is continuous spray.
 - Press twice: one beep, the machine starts to work in heavy fog mode, which is continuous spray.
 - Press three times: one beep, the machine turns off the spray mode.
 - Press and hold for 2-3 seconds: two beeps, enter the Bluetooth connection mode, the light flashes regularly, after the connection is successful, the indicator lights are all off, and it will automatically exit if there is no connection for 3 minutes.
- Light button: (Fig. 6)
 - Press it once: a beep, the light will change color automatically.
 - Press twice: beep once to lock the current color.
 - Press three times: one beep, turn off the light.
 - Long press: two beeps, turn off the machine.
- When the water tank is short of water, the machine will automatically shut down.



Aroma Diffuser

Tuya App Operation

- Search for "Tuya Smart" in each application market Or scan the following QR code to download and install.
- Turn on the Tuya APP and the Bluetooth function of the mobile phone.
- Press and hold the spray button of the machine for 2-3 seconds, it will beep twice to enter the Bluetooth connection mode, and the light flashes regularly. After the connection is successful, the indicator lights are all off, and it will automatically exit if there is no connection for 3 minutes.
- Click Add Device, the device is discovered and added successfully. (Fig.1)
- Click "U" to open the aroma diffuser and enter the working interface. (Fig. 2)
- Click the spray switch to turn on or off the spray mode. (Fig. 3)
- The spray gear can be selected from 1st gear and 2nd gear.
- Countdown can be selected (cancel, 1h, 3h, 6h) spray work time.
- Click the light switch to turn on or off the light mode.
- Lights can be selected (seven colors, colorful lights, night lights, scenes).
- Click settings to enter "device settings, light name, timing". (Fig. 4)
- Click on the timing to enter the setting (spray/light timing).
- Click on the spray timing, you can set the start working time, Press and hold the left swipe to delete the timing. (Fig. 5)
- Click on the light timing, you can set the start light time, Press and hold the left swipe to delete the timing. (Fig. 6)



Aroma Diffuser

Precautions

Please read below to avoid any malfunction to the unit:


- If you are not a technician do not try to dismantle the diffuser to repair it. Contact the seller if repair is necessary.
- Do not turn power on when the tank is empty.
- Do not touch the atomization plate.
- Clean regularly as per Maintenance instructions to avoid malfunction.
- Always unplug before maintenance.
- For hygiene reasons, after use, pour out the remaining water from the tank and wipe with a clean dry cloth.
- Only use the measuring cup to add water into the tank, do not fill water directly from the sink.
- Do not let mist come in direct contact with furniture, clothing, walls, etc.
- Keep out of direct sunlight.
- Always keep on a hard, stable, flat surface. Do not place on a towel, carpet or any other unstable surface.
- Keep away from electronic equipment, such as TV and Audio equipment.
- Wait 60 minutes between uses to avoid damage to the atomization piece.
- Do not use sparkling water. Only use tap water or mineral water.
- Never move product when it is working.
- Do not touch any part of the product with wet hands.
- Keep away from pets and small children.
- If the power cord is smoking or burning, unplug immediately!

Aroma Diffuser

Maintenance

After using 3 days, please clean the product as follow:

- Unplug the unit and remove cover.
- Pour out any remaining water from the tank.
- Add a small amount of warm kitchen detergent to clean, use swab to wipe it gently, and then use cleaning cloth to dry it lightly.
- Refer to the following pictures, to avoid water flow into the air outlet, pour off water abide by the left picture, not the right one.
- Do not use other acids or enzymes detergent, as this may give off poisonous gas or cause malfunction.



Note: Be sure to use a mild detergent.

Specifications

Dimensions	169x169x202MM
Weight(excluding adaptor)	Approx 510G
Power Input	AC100-240V 50/60Hz
Power Output	DC24V 500mA
Length of cord	Approx 170CM
Power	Approx 12.5W
Working Mode	Continuous
Tank Capacity	350ML
LED light	15PCS
Material	PP/ABS
Accessory	AC Adapter and User manual
Working frequency	2.4GHz 2402-2480MHz

Aroma Diffuser

FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement in portable exposure condition without restriction.