









排版方式 封琴式 双面印刷  
尺寸 宽 5CM 高 8CM

<div>User 's manual</div> <div></div> <div>Quick Operation Guide</div> <div>V2</div>	<div>Safety information</div> <div><ul style="list-style-type: none"><li>This device does not have a power adapter. When charging is required, please use a power adapter that has obtained the CCC certificate and complies with relevant standards.</li><li>Please use this equipment within the temperature range of 0℃~40℃, and store the equipment and accessories within the temperature range of -20℃~+45℃. When the ambient temperature is too high or too low, it may cause equipment failure.</li><li>Do not expose the device to high temperatures or around heating devices, such as sunlight, heaters, microwave ovens, ovens or water heaters, etc.</li><li>When charging is complete or not charging, please disconnect the charger from the device and unplug the charger from the power.</li><li>The device is equipped with a non-removable built-in battery, please do not replace the battery yourself to avoid damage to the device.</li><li>Please dispose of this equipment, batteries and related accessories in accordance with local regulations, and do not dispose of them as domestic waste.</li></ul><p><b>Warning:</b>The battery ( battery pack or assembled battery ) must not be exposed to such as sunlight, fire or similar overheating environment;</p></div> <div>1</div>	<div>Notice: If the battery is improperly replaced, there is a danger of explosion. Only the same type or equivalent type of battery can be used to replace it.</div> <div>Packing list</div> <div><ul style="list-style-type: none"><li>Wireless microphone transmitter 2pcs</li><li>Wireless microphone receiver 1pcs</li><li>User manual (including warranty card) 1pcs</li><li>USB Charging cable 1pcs</li></ul><p>Outline picture (Note: The outline picture is subject to the actual product)</p><div></div><div>2</div></div>	<div>Function Description</div> <div><ul style="list-style-type: none"><li>Windbreak</li><li>Microphone clip (360° rotatable)</li><li>Power Switch</li><li>USB Charging port</li><li>Microphone indicator</li><li>Receiver indicator</li><li>Lightning plug</li><li>Mobile phone charging port</li><li>USB plug</li></ul></div> <div>Indicator light description</div> <div><p><b>Microphone transmitter:</b></p><ul style="list-style-type: none"><li>Power-on but disconnected state: the red light and green light on the front flash alternately;</li><li>Power-on and connected state: the green light on the front is always on;</li><li>Connected but recording paused: the green light on the front flashes and by pressing the button very softly, it will stop flashing and the recording will continue</li><li>Low battery: red light flashes on the front;</li><li>Charging status: the front red light is always on; the front red light is off when fully charged;</li></ul><p><b>Receiver:</b></p><ul style="list-style-type: none"><li>Power-on but disconnected state: green light flashes;</li><li>Power on and connected state: green light is always on</li></ul></div> <div>3</div>	<div>Instructions</div> <div><p>1. Plug the receiver to your device and you'll see the green light flashes.</p><div></div><p>2. Press and hold the power switch of the microphone for about 1 second to turn it on and about 3 seconds to turn it off.</p><div></div><div>4</div></div>	<div><p>3. If the green light for both of the receiver and transmitter always keeps on, it means they paired successfully. Then open the phone camera, live App or other Apps to start recording.</p><div></div><p>4. Upgraded 360° Rotating Clip The back clip is built on the microphone and can be rotated to any direction you want without taking off the clip. The rotating function to a great extent can help to protect the clip from being broken or damaged while recording.</p><div></div><div>5</div></div>
<div><p>Note: In order to ensure the effective use of the connection, there should be no obstacles between the microphone and the receiver. When wearing the microphones for recording or live video broadcasting, it is recommended to face the receiver, otherwise the signal may be interrupted.</p></div> <div>6</div>	<div></div> <div>7</div>	<div>Special Notice to Help Your Recordings:</div> <div><p>1. Please make sure your device is unlocked and the green light flashes after the receiver is plugged to your smart phone.</p><p>2. Press the power switch of the microphone for about 1 second to turn it on. If the green light for both of the receiver and transmitter always keeps on, it means they paired successfully.</p><p>(If it's paired successfully but recording is failed at the first time , please try to re-plug the receiver as there is a setting named "DOCK" would appear automatically.)</p></div> <div></div> <div>8</div>	<div><p>3. To ensure the sound quality, please put the microphone in a proper distance and do not put it too close to your mouth. If you want to hold the microphone in your hand, please hold the bottom of it and do not cover the windbreak on the top.</p><p>4. Press the power switch of the microphone very softly, the green light will keep flashing, which means the recording was paused. By pressing the button again, it will stop flashing and the recording will continue.</p><p>5. Any time when you see the red light &amp; green light flashes alternately, it means the connection is failed and you need to restart.</p><p>6. Press and hold the power switch for about 3 seconds to power off the microphone.</p><p>7. Please unplug the receiver before listening to your recordings.</p><p>PS: Please follow up the instructions step by step and we will always stand by if you have any problems while recording. Should you have any other question, please feel free to contact us.</p><p>Our Customer Service: <a href="mailto:support@PGDLDF.com">support@PGDLDF.com</a></p><p>Our Website: <a href="https://pgdldf.com">https://pgdldf.com</a></p></div> <div>9</div>	<div><p>This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p><p>Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p><p>NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.</p><p>If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following</p></div> <div>10</div>	<div><p>measures:</p><ul style="list-style-type: none"><li>Reorient or relocate the receiving antenna.</li><li>Increase the separation between the equipment and receiver.</li><li>Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.</li><li>Consult the dealer or an experienced radio/TV technician for help.</li></ul><p>The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction</p></div> <div>11</div>