

Quick Reference Guide

Pairing Your TV (English)

1. Press Power key to turn on the TV.
2. Press and hold **VOL (→)** key and **MIC ↴** key for 2 seconds initiate pairing with TV.
3. All paring transaction is behind the scene and no setup is required.

Using Voice search (Voice search supported models only)

For Voice search supported models, the remote control has a built-in microphone. By speaking into the microphone, you can search for content on the Internet.

1 . Press the **MIC ↴ button.**

The LED on the remote control will light up.

2 . Speak into the built-in microphone.

Speech examples may be displayed depending on your model.

When your voice is not being recognized

Confirm the following:

■ The **MIC ↴** button is activated.

To confirm these settings, press the **[HOME]** button, then select **[Settings] — [Voice Remote Control]**.

in the **[NETWORK&ACCESSORIES]** category. select **[Activate the ↴ button]**. follow the onscreen instructions

Note

■ An Internet connection is required to use Voice search.

■ The type of remote control supplied with the TV, and the availability of a remote control with a built-in microphone varies depending on your model/region/country. An optional remote control is available in some models/regions/countries.

Connecting a Bluetooth device

◆ **To pair the TV with a Bluetooth device**

Only for Bluetooth A2DP-supported models that can use Bluetooth audio devices such as headphones or speakers. Bluetooth A2DP-supported models that can use Bluetooth audio devices have **[A/V sync]** in **[Settings] — [Sound]**.

1. Turn the Bluetooth device on and put it in pairing mode.

To put your Bluetooth device in pairing mode, refer to the instruction manual of the device.

2. Press the **HOME button, then select **[Settings] — [Bluetooth settings] — [Add device]** to put the TV in pairing mode. A list of available Bluetooth devices will be displayed.**

3. Select the desired device from the list, then follow the on-screen instructions. If you are prompted to enter a passcode, refer to the instruction manual of the device. After pairing is completed, the device connects to the TV.

◆ **To connect to a paired Bluetooth device**

1. Press the **HOME button, then select **[Settings] — [Bluetooth settings]**.**

2. Select a paired but unconnected device from the list.

3. Select **[Connect].**

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.