

BH20

Instruction Manual


1、Packing List :

- BH20 Wireless headset
- Audio cable
- Type-C Charging cable
- Product instruction
- Color Packing box

2、Product parameters:

- Product model: BH20 Wireless Headset
- Wireless Version: V5.0
- Charging Port : Type-C
- Charging time: About 2 hours
- Playing time : About 16 hours
- Charging voltage: 5V == 0.3A
- Support Protocol: HSP /HFP /A2DP/ AVRCP
- Communication distance: 10 meters

3、One Click Control



4、New Smart Headset Series :

Compatible with IOS and Android, smart phone/ tablet and other electronic products with Blue tooth function.

5、Operating instructions:

1. Wireless Blue tooth connection

Press and hold the power button for 3~5 seconds, after the head set flashes red and blue lights alternately, turn on the phone's blue tooth,Search and find the device name "BH20" to connect. Set after successful connection , the blue light flashes slowly.

2. Switch on and off

·Press and hold the power button for 3 seconds, the blue light flashes, that is.
·The device will automatically pair and connect.
·Press and hold the power button for 3~5 seconds to shut down.

6、Charging

Use the Type-C charging cable to connect to the device. Charging process , the red light of the middle indicator light is always on, and the indicator light is off when the battery is fully charged.

7、Wired mode

To use the wired mode, turn off the Blue tooth mode and perform shutdown operations. Plug in and deliver the 3.5mm audio cable is ready for use, (The headset button and microphone cannot be used in this state.)

8、Buttons Description

Button name	Action	The Effect	In view of the equipment
Power Button	Press and hold for 3~5 seconds	Turn on	This Machine
Power Button	Press and hold for 3~5 seconds	Turn Off	This Machine
Function button	Short press (when music is playing)	Play/pause	Mobile phone
Function button	Short press (when a call comes in)	Answer/hang up	Mobile phone
Function button	Long press for 3 seconds (when a call comes in)	Reject the phone	Mobile phone
V+ key	Short press (when music is playing)	Volume increase	Mobile phone
V-key	Short press (when music is playing)	Volume down	Mobile phone
V+ key	Long press (when music is playing)	Next song	Mobile phone
V-key	Long press (when music is playing)	Previous song	Mobile phone

9、Common problems :

1. The device cannot be found

The phone cannot search for the device, try to turn off the head set and then turn it on again, And Also try to turn off the bluetooth of the mobile phone and then turn it on again.The dental equipment is cleared, and the search and pairing is performed again.

2. The device is connected but there is no sound

Adjust the volume of the headset , check if the volume on the headset is adjusted to the lowest.

3. There is no sound from the headset when the audio cable is plugged in

Plug the audio cable back into the headset and mobile phone.

10、Please pay attention to the following signals when using the headset:

① The distance between the headset and the mobile phone should not exceed 10~20 meters, and there should not be too many interfering obstacles (such as the cavity) to avoid the problem of broken link and stuck in the transmission of Blue tooth signal.

② In the process of daily use, it is normal to have occasional disconnection problems. After all, Blue tooth belongs to wireless signal transmission, just like with network, occasional instability is a normal phenomenon. The signal transmission may be interfered by some environment. Please wait for a moment or change the position.

③ It is very important to avoid the problem of sound insulation, sound leakage and wearing method of headset. To avoid the sponge part of earphone bag is not completely closed in the ear/head, you can timely adjust the wearing Angle and ear covering degree of earphone according to the comfort of actual use.

④ When you wear headphones, adjust the volume to the maximum, and some audio leakage is normal. If you want a more private soundproof environment, it is recommended to lower the volume to the normal condition and adjust the wearing Angle to the best condition.

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.