



## Our story

Innovation and technology are steadily making our lives easier and more enjoyable. Machines have already taken over 90% of the jobs that us humans used to do. So, we figured: why not blow jobs?

When we started, in our opinion, little innovation was happening in the sex toy market. Sure, toys may have become more compact and better looking, but at the end of the day, you still needed to do the job yourself. We were only a bunch of horny engineering students back then, but we just knew there had to be a better way.

We started Hismith to make ultimate pleasure available to anybody, anywhere, with the touch of a button. We take great pride in creating our premium sex machines. Experience harder, better, faster and longer sex than any human can ever offer you.

Our brand new Hismith APP offers you full control of your Hismith device(s) through your smartphone. The app adds another layer of features and functionalities such as: Giving control of your sex machine to someone else, easily designing and saving your own sex machine programs, a social section to find others to play with and much more.

HISMITH, ultimate pleasure

PRODUCT NAME CAPSULE				DEPARTMENT HISMITH
				TRODUCTION
				JLTS ONLY
Picture	Part /	A: Functio	n of th	ne button Function
Fictore	Multi-function Key	While the machine is running, top this button to power boost, increasing to a super high speed for a duration of 20 seconds. Tip: Use this when you're a bout to cum. While the machine is in standly mode, top this button to retract the connector to its original position, for convenient storage.		
	Thrusting Modes	When the machine is turned on, press this button to cycle the three thrusting modes. Hold for 1 second while using to go back to standby mode.		
	Power Button	Hold button for 1 second to start up. After starting up, the indicator light will be on and the motor will be in standby-mode When power is on, hold 1 second to shut down.		
	2.5MM	Charging Port Located on the back of the product.		
		Part B: 0	Chargi	ing
The	indicator light flash	es when cha	rging, a	nd stays on when fully charged
TH	ne charging time is ap	prox. 2 hou	s; A Full	charge lasts about 60 minutes
•	Material: ABS	Size		HxD=187.7x59MM
	PART C: WORK	(ING AN	D TEC	HNICAL PARAMETERS
BATTERY TYPE			MODEL:902830, 3.7V/1250mAh	
MOTOR SPECIFICATION			370 THRUSTING MOTOR	
WORKING VOLTAGE			3.7V	
CHARGING INPUT CURRENT			≤500mA	
CHARGING ADAPTER SPECIFICATION			5V/1A	
MAX NOISE LEVEL			≤63DB	







## Warnings and precautions

- 1. The machine and accessories are not waterproof, please do not use the machine in damp, moi or wet places. Do not touch the power plug with wet hands, this can cause an electric shock.
- Don't idle the machine in high speed to avoid accidental injury.
- 3. Please check if the thrust bar is connected tightly, before using heavy attachments, such as a ma
- masturbation cup or large dildos.
- 4. Please adjust the speed dial to zero before turning the machine on.
- 5. This product is not intended for use by minors. We advise against the use of this product by
- cardiac patients, such as those with high blood pressure.
- 6. Keep away from children.
- 7. The motor will gradually warm up with continuous use. We advise to use it no more than  $30\,$ minutes at a time, before letting the motor cool down 8. Use this product only for its intended use as described in this manual . Use only the original
- Hismith connectors to attach your toys to this product.
- 9. This sex machine is a personal device, intended for solo or couple use only. In case of sharing the device with others, pay close attention to personal hygiene to avoid risk of diseases or infections
- 10. Remove piercings or jewelry in the genital area before use.
- 11. Do not use the tay on irritated or damaged skin. Stop using the device if you experience pain o feel unwell during use.

  12. Do not use the device if it is:
- unusually hot, damaged or deformed
- discolored.

Disclaime Use at your own risk. Neither Hismith, nor its retailers take any responsibility or liability for the use of this product. Proper use also includes compliance with the Quick Start Guide and the warnings listed. Furthermore, Hismith reserves the right to revise this publication and make changes to the contents herein without obligation to notify any person of such revision. Applicable for all products. Models may be changed for improvements without prior notice.

Proper use also includes compliance with the Quick Start Guide and the warnings listed here

We grant a 1-year warranty on this product, commencing on the date of purchase. Within the guarantee period, we will restore any defects in the product resulting from faults in materials or workmanship, either by repair or replacing the complete appliance based on the defect. This guarantee extends to any country where this appliance is supplied by Hismith or its appointed distributors. This guarantee does not cover: Damage due to improper use, use with inauthentic connectors or cosmetic defects that do not hinder the operation of the appliance. The guarantee becomes void if repairs are undertaken by unauthorized personnel.

# Connectors









## Attachments







# HS06 HS08 HS12





Contact us: support@hismith.com

HSA08

HSA35

HSA40

# § 15.19 Labelling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

# § 15.21 Information to user.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

# § 15.105 Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -Consult the dealer or an experienced radio/TV technician for help.

# \* RF warning for Portable device:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.