

拼图组合投影灯说明书

折叠后尺寸：70*90mm

材质：105克书纸单黑印刷

正面

HY-01 | 拼图音乐投影灯

LAMP | PUZZLE MUSIC PROJECTION LAMP

产品使用说明书

拼图图案 投影灯/小夜灯 蓝牙音箱

旋转区 投影片放置区 喇叭孔

触摸开关

USB充电口

产品参数


| | |
|-------------------|----------------------|
| 产品名称：拼图音乐投影灯 | 电池容量：1200mAh |
| 产品型号：HY-01 | 充电时间：约5h |
| 产品材质：ABS+PC | 输入电压：DC5V/1A |
| 产品尺寸：115*115*65mm | 最大功率：5W |
| 产品重量：约215g | 使用时间：约5-12h（取决于功能模式） |

用户手册 User Manual

在使用您购买的产品之前，请将其充满电产品。请仔细阅读本手册并妥善保管。


1 充电 Charging

取出数据线，插入电源，按照图中所示的方向插入数据线。



2 放置图案 Replace The Pattern

提起固定圈，将整张图案平整安置于投影平面，放置后将固定圈放回原位。如果你想用的拼图图案，则不需要提起固定圈，只需要将拼图直接放置于投影平面即可。



3 按键功能 Button basic function

- 1) 在投影灯关闭状态下，长按开关5s，投影灯开机，灯光亮起，投影盘转动。
- 2) 当你听到声音时，代表蓝牙已经启动，你可以连接“PUZZLE LAMP”来连接设备，播放音乐。
- 3) 在启动状态下，长按开关5s，投影灯关闭。

4 灯光模式 The light pattern

在启动状态下，每短按开关一次，灯光切换模式

- 1) 白灯
- 2) 暖黄
- 3) 粉红
- 4) 三色混合齐亮
- 5) 随机跳变灯光
- 6) 三色循环渐变呼吸灯

在启动状态下，双击开关，小夜灯模式开启，暂停旋转，同时亮度降低至50%

5 注意事项 Matters Needing Attention

- 使用前请确认当前环境和适配器适合产品的工作，以及确保产品及其部件完好无损。
- 请勿私自拆解或替换花影灯的任一结构或组件。
- 投影灯在工作过程中会产生热量，请保持周围空气对流，以便散热。
- 严禁产品在高温、潮湿的条件下工作。
- 若产品进水，请立刻断开电源，停止使用

感谢您的购买！在使用前请务必阅读此说明书，避免误操作！
10岁以下的儿童请在监护人的指导下使用！
最终解释权归生产者所有！

FC CE RoHS

反面

Product Instruction

PUZZLE MUSIC PROJECTION LAMP

Replaceable jigsaw picture Projection lamp night light Built-in bluetooth speaker

Rotating area Slide show area

Touch switch Loudspeaker hole

USB charging port

Product Parameters


| | |
|-----------------------------------|---|
| Name：PUZZLE MUSIC PROJECTION LAMP | Battery capacity：1200mAh |
| Model：HY-01 | Charging time：About 5h |
| Material：ABS+PC | Voltage：DC5V/1A |
| Size：115*115*65mm | Power：5W |
| Weight：About 215g | Working time：About 5-12h (Depends on the functional pattern) |

用户手册 User Manual

Before using the product you have purchased, please fully charge the product. Please read this manual carefully and keep it properly.

1 Charging


Take out the charging cable and plug it in the power supply, then insert the charging cable to the lamp according to the direction as shown in the diagram below.



2 Replace The Pattern

Lift up the top retaining ring and place the entire piece of pattern flatly on the projection area then put the fixed ring back in place.

If you want to use the jigsaw puzzle, you don't need to take out the retaining ring and just place the puzzle into it.



3 Button basic function

- 1) When the projection lamp is off, long press the switch for 5 seconds to turn on the lamp. The light is up and the projection area begin to spin.
- 2) The Bluetooth mode is on automatically when you turn on the lamp and hear the sound. You can connect the Bluetooth named "Bl Speaker" to play music.
- 3) Long press the switch for 5 seconds to turn off the projection lamp.

4 The light pattern

In the starting state, press the switch every time to switch the light mode

- 1) Warm yellow
- 2) White light
- 3) Pink light
- 4) Random change of light
- 5) Three colors gradient breathing light
- 6) Three colors lights are all on

In the working condition, double-click the switch to turn on only night light mode, pause the rotation, and reduce the brightness to 50%

5 Matters Needing Attention

- Before use, please confirm that the current environment and adapters are suitable for using the product and ensure that the product and its components are in good condition.
- Do not disassemble or replace any structure or component of the projection lamp without permission.
- The projection lamp will generate few heat when working. Please keep the surrounding air convection in order to dissipate heat.
- It is strictly prohibited to work under the condition of high temperature and humidity.
- If the product is flooded, please disconnect the power supply immediately and stop using.

Thank you for your purchase! Please read this manual before use to avoid misoperation!
For children under 10 years of age, please use under the guidance of your guardian!
The final interpretation right belongs to the manufacturer!

FC CE RoHS

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
 - (2) this device must accept any interference received, including interference that may cause undesired operation.
- This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device shall be used with a minimum distance of 20cm from users.