

尺寸: 140X93mm
 材质: 128g双铜纸
 工艺: 折页, 双面4C印刷

料号: 028.21.1493.0038

Important Safety Notes

For the best viewing effect, please use the projector in dark room.

- Do not install this projector in the area which directly blown by the air conditioner, to prevent projector failed caused by water vapor condensation or excessive temperature.
- Ensure that the environment is ventilated to prevent overheating caused by heat build-up.
- Prevent foreign objects from falling into the machine. Never insert any metal objects into the machine. If foreign objects fall into the machine accidentally, please power off immediately and seek professional assistance.
- Do not place any liquid on the machine to avoid leakage.
- Avoid violent vibrations when transporting. Please protect the lens from wear.
- Do not touch the vents when using the projector to avoid burns due to excessive temperature.
- Do not look directly at the lens while the projector is running to prevent eye injury.
- Please clean the filter regularly to prevent malfunction caused by clogging.

Notice ⚠️
Do not open the case of projector to prevent electric shock. Please seek professional assistance for maintenance matters.

⚠️
Do not touch! The inside of the projector contains uninsulated voltage.

Warn ⚠️
Do not install the projector around flammable objects to prevent fire. Please use 3C-certified power adapter for charging.

Important Safety Notes

To ensure the performance and stability of the projector, please place it horizontally and leave a space of about 30cm between the projector and the wall.

Do not install in places with poor ventilation. Do not install in high temperature or humid places. Do not block the vents. Do not install in dust or smoky places.

Specifications

Item	Specification
Product	X1
Native Resolution	1920x1080
Video	Support 8K/4K Decoding
Audio	Support Dolby Decoding
System	Android 9.0 OS, OTA Upgrade Support
CPU+GPU	Amlogic T972 + AFM Mali-G31 MP2
WiFi	Dual Band WiFi 2.4/5GHz
BT	BT 5.0
Interface	HD IN*2 USB Earphone AV AV IN
Environment	
Power Input	AC 110-240V 50-60HZ
Operating Temperature	0 - 40°C
Storage Temperature	-20 - 65°C
Operating Humidity	0 - 90% Non-condensing

1 Package contents

- Projector X1
- Power adapter
- HD cable
- Voice remote
- Heightening screw
- User manual
- Carrying bag

Projector Introduction

AV port, HD Input, Ventilation holes, USB port, 3.5mm Audio port (Available for earphones), Dust filter, Remote sensor, Navigation key, DC port, Focusing ring.

1. Left 2. Right 3. Up 4. Down 5. OK(Enter)
 6. Return 7. Menu 8. Input Source 9. Power

After the Bluetooth pairing is successful, the voice key is available. Pairing method (Bluetooth connection):
 1. Press and hold the left & right direction buttons at the same time for 3-5 seconds until the red light flashes.
 2. Open "Settings"-"Bluetooth & Remotes", click the name of the remote to connect.

Bluetooth Remote

Infrared signal light, Power ON/OFF, Navigation key, Return, Home, Voice -, Setting, Voice Key, Input Source, Menu, Mouse mode, Voice +, Apps, Mute.

Projector Installation

1 Projection Methods
Depending on the installation method, select the appropriate option in the settings.

2 Choose Projection Methods

- Frontal projection
- Hanging projection
- Rear projection
- Rear hanging projection

Projection Size/Distance Reference

Our projector can support to the screen size from 40" to 200". Following show the Size and Distance reference for you to choose. The most best location shall be 80" /8.2feet. The screen size indication (Inch) is 200", 120", 80", 40". Distances are 18ft, 11ft, 8ft, 3.9ft. Unit: feet. Data for reference only.

Power-On/Off Operation

1 Power connection
Connect the power cord with projector.

2 Boot & Shutdown
Press the power button to boot up projector. Aim the remote control at the Remote sensor part of the projector.

Way1: Power on/off by the button on projector. Way2: Power on/off by remote control.

Screen Adjustment

Adjust the size and position of the picture by adjusting the projection angle (height of the image), tilting the image left and right, adjusting the focus, zoom out/zoom in the image size, adjusting the keystone correction.

1 Adjust the height screw
1. Raise the front of the projector. 2. Screw on the heightening screw to adjust the picture to the height you want.

2 Adjust the focus(Sharpness adjustment)
After the machine is placed horizontally, turn the focusing ring up and down to make the picture clearer.

Screen Adjustment

3 Four Point Keystone
If the machine installed tilted, please set the keystone correction to adjust. If unable to get the satisfactory sharpness, move the machine slightly forward or backward.

Four Point Keystone Correction: ±15°left and right, ±45° horizontal and vertical.

Screen Adjustment

4 Electronic Zoom

No more space constraints, no need to change the projector distance, just move the projector to fit the screen size, you can customize your projection screen size from 35% to 100%.

Digital Zoom 100%---->35%

Screen Adjustment

5 Bright Adjustment

When playing a video, you can set the picture mode.

1. Set picture mode:
When playing the video, press the setting button ⚙️ to enter the setting interface, click "picture"- "picture mode", select the picture mode you want.

2. Custom picture mode:
Click "Settings"-"Picture"-"Picture Mode", select a picture mode, then press the return key ↵, click "Custom Settings", adjust the parameters in this mode as needed.

Remember to take pictures and record the original values before adjusting.

System Initial Setup

1 Language Select

Press the "Set" ⚙️ key on the remote control to enter the set menu-"Device Preference"-"Language"- Choose your preferred language.

2 Wifi connection

- Open Settings, Network & WiFi to enter the WiFi settings page.
- Choose the Wifi option and enter passwords to connect.

System Initial Setup

3 Bluetooth connection

Press the "Set" ⚙️ key on the remote control to enter the set menu-"Bluetooth & Remotes"-"Add accessory"- Follow the prompts to pair your Bluetooth device.

4 FOTA Update online

Open "Apps"-"FOTA Update"-"Check Version", Click and Check for updates.

System Initial Setup

5 Application management

We have installed some basic application for you to using, like Netflix, Youtube, Chrome, Prime, WPS office, etc.

When open Netflix APP, there is notice pop up reminding customer to update, please click "CANCEL", do NOT update. The Netflix already installed in this projector is version 5.16.2 which is specially selected, and we've run a lot of testing and debugging for stable and smooth streaming experience. We strongly suggest to use this version of Netflix, do NOT make any updates.

1. Install other Android Apps
A: Play Store: Almost android apps can be installed to X1 projector via Play Store.
B: If you wanna install the application that can not find in google store, you can install the apk with AppInstaller as following steps

2. Uninstall App
Press "Settings" ⚙️ button on remote, "Apps"-"See all Apps"- Select the application to be uninstalled, and click "Uninstall"

Select the Input Source

1 HD/AV Connection

Open the "SignalSource" app on Homepage or press the "Switch" ⏪ button of remote. Select the source channel you need in the list on the right side of the Homepage

1. This device supports connections with various HDMI playback devices such as streaming media player, TV stick, TV box, DVD player, set-top box (STB), game machine or other devices(HD cable provided).
2. AV connected devices are also supported.

2 USB Connection

- Connect U disk or hard disk
- Open "FileBrowser", enter USB Storage Device, select the movie, photo you want to play.

When playing the video in the external storage, find the video file you want to play, long press the "OK" key to enter the menu page, click "Open with...", and then select "MoviePlayer" to open the video file. MoviePlayer's video decoding capability is stronger.

Screen Mirroring

1 For Android device

- Choose "Cast" icon as below picture (support Android 5.3 and above)
- Open "Miracast" App as below picture. Local device name is "Android-XXXX"
- Open the Wireless Cast on Android phone to search available devices, click the "Android-XXXX" option to connect.
- Click on the prompt box to accept the screen cast connection. If the screen is synchronized, means screen cast completed.
- Open the Screen Mirroring from the control center on iPhone.
- Search for available devices.
- Connect to "Bytefy-xxxxx" option to start mirroring screen.

DLNA
This X1 projector supports DLNA. When the projector connected to WiFi, smart devices in same network could play videos on the project which requires smart device APP supports DLNA.

Screen Mirroring

2 For iOS device

- Choose "Cast" icon as below picture.
- Please ensure the ios device and projector connected to the same network.
- Open the iOS App in projector.
- Open the Screen Mirroring from the control center on iPhone.
- Search for available devices.
- Connect to "Bytefy-xxxxx" option to start mirroring screen.

Maintenance Suggestion

Filter

Notice ⚠️
To make this projector work longer, we recommend you to follow the ideas.

- Before cleaning the projector, turn off the projector, then turn off the main power and unplug it from the outlet.
- Clean the filter regularly every month to prevent clogging.
- Make sure to close the projector off once you finished using it.
- Make sure not to use it continuously for more than 6 hours.

FAQ

1 Remote control is insensitive or unresponsive
 --- Please check if the batteries installed properly.
 --- Please replace with new batteries.
 --- Please aim the remote control to the projector to operate.

2 Unable to boot up
 --- Please check if the power cord is connected properly, and if the power light is on. Try to unplug and plug the power if the projector still cannot boot up.

3 Black screen or abnormal picture after booting for a while
 --- Please check if the vents are blocked.
 --- Please check if the cooling fan is working properly. If abnormal, please return for repair.
 --- Please try to reboot the projector.

4 No network connection
 --- Please check if WiFi connected properly, and if the WiFi signal is good.
 --- Please connect hotspot of smart phone to verify if router is working properly.

5 Blurry display
 --- Please check if the lens are clean.
 --- Please use the focusing ring to adjust the sharpness.
 --- Please check if the environment too bright.

6 Screen freeze
 --- Please reboot the projector to test again. If the screen still freeze, please turn off for 10 minutes and turn on again.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

USER MANUAL

For more details,
please consult online
customer service.



 **Notice** Please read this user manual carefully before use.

Warranty Card

Client Name: _____ Client ID: _____

Client Phone Number: _____

Purchase shop: _____

Return Address: _____

Fault description:
(For quick repair, please describe the problem in details.)

OVERSEAS USE ONLY

FC CE RoHS  

封面

封底