Product Overview LED Indicator ON/OFF Button Reset: Press and hold for 5 seconds.	Product Overview Product Size Model Color White Working Temp -20 ~ 50° C Wi-Fi Requirement 1.nput Voltage AC 125V Maximum Output 10A Compatibility Product Weight 52.6g	and Bluetooth connection. Connection. 1. Use your smart plug only in indoor environments Stead	Connection Steps **Iashing White** onnecting in progress. **Steady White** the device is working properly. **Index of the Nooie app and create an account. **Index of the Nooie app		Connection Steps 3. Open the app and select "Add Device". (a) AP Mode © EZ Mode (o) BT Mode 2.4GHz [only]	Connection Steps 4. Follow the steps below to complete the setup. Add Device	EZ Mode (Recommend) 1. Open the Nooie App, enter the Home interface, and select "Add Device"-"NOOIE SMART PLUG". 2. Press and hold the button for 5 seconds until the white light flashes quickly. 3. Please make sure that your Nooie Plug is within Wi-Fi range. Click "Light Flashing Rapidly" to proceed to the next step.	4. Enter your Wi-Fi account and password. (Nooie Smart Plug only supports 2.4G network). 5. Wait for the connection, the indicator will turn off after the connection is successful. 6. If the connection fails, please follow the prompts on the Connection Failde interface in the App to check and reconnect or try other connection methods.	BT Mode 1. Press and hold the button for 5 seconds until the device light flashes quickly. 2. Turn on the Bluetooth of your mobile phone and open the Nooie App. 3. Wait for the App interface to automatically search for Bluetooth devices and select the corresponding product model.	4. Enter your Wi-Fi account and password. 5. Wait for the connection, the indicator will turn off after the connection is successful. 6. If the connection fails, please follow the prompts on the Connection Failed interface in the App to check and reconnect.	AP Mode 1. Press and hold the on/off button until the white light flashes slowly to indicate engagement. 2. Connect your phone to the device's hotspot named "Smartlife_XXX" in your phone's settings. (Not your home Wi-Fi.) 3. Return to the App and continue to pair. 4. Wait for the connection, the indicator will turn off after the connection is successful.	Designed in USA Made in China
Note: If you encounter any problems, please email us (support@nooie.com) with the order nummber and the problem you encountered. Third-party Control 1. Make sure you first connect the plugs with the Nooie App. 2. Open the main interface of the device, click the setting button ② and find "Support Third-party Control". 3. Then you can learn about "How to connect with Alexa?" or "How to connect with Google Home?" Amazon Alexa Google Assistant	Remove (two setting methods) 1. Press and hold the button for 5 seconds until the device light flashes quickly, indicating the reset is successful. 2. If the device is sync'd to the App, open the App and go to the main interface. Click the "Setting" button and click "Remove". Note: After reset, the device enters the network configuration state, clears the data you set before, but retains the custom name of the device. Reset 1. If the device is sync'd to the App, open the App and go to the main interface. 2. Click the "Setting" button and click "Reset to Factory Setting" to restore device. Note: After restoring the factory settings, the device enters the network configuration state, clearing the data you set before and the original custom name.	FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. "Please note that changes or modifications of this product is not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment." B digital devi FCC Rules. T	determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: neering antenna. Increase the separation between the equipment and receiver. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.	transmitter(s)/receiver(s) that comply with Innovation, Scienceand Economic Development Canada's licenseex- emptRSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference. (2) This device must accept any interference, including interference that may cause undesired operation of the device. The device the transparence of the cetter	et Développementécono-mique Canada applicables aux appareils radioexempts de licence. L'exploitationestautorisée aux deux conditions suivantes : 1) L 'appareil ne doit pas produire de brouillage; 2) L 'appareildoit accepter tout brouillageradioélectriquesubi, mêmesi le brouillagestusceptible d'encompromettre le fonctionnement. This equipment complies with FCC's and IC's RF radiation exposure limits set forth for an uncontrolled environment. The antenna(s) used for this transmitter must	be installed and operated to provide a separation distance of at least 20 cm from all persons and must not be collocated or operating in conjunction with any other antenna or transmitter. Installers must ensure that 20cm separation distance will be maintained between the device (excluding its handset) and users. Cetappareilestconforme aux limitesd'exposition au rayonnement RF stipulées par la FCC et l'IC pour uneutilisation dans un environnement non contr?lé. Les antennesutilisées pour cetémetteur-doiventêtreinstallées et doiventfonctionner	à au moins 20 cm de distance des utilisateurs et ne doivent pas êtreplacéesprèsd'autresantennesouémet- teursoufonctionner avec ceux-ci. Les in-stallateursdoivents'assurerqu'une distance de 20 cm séparel'appareil (à l'exception du combiné) des utilisateurs.	Customer Care Have any questions? Check out the FAQ on our website: www.nooie.com/support Need more help? Contact us at support@nooie.com Want to give your feedback? Tag us #nooie on social media.	Social Media Scan to follow us on our Instagram! Output Nooie, always there	Social Media Scan to follow us on our Facebook! Nooie, always there	Warranty Terms 1. 12-month limited warranty. 2. Lifetime technical support provided by Nooie.	Works with amazon alexa Google Assistant

此部分不印刷, 仅供排版示意

封面								封底

Nooie Confidential - Do Not Disseminate Without Proper Authorization.

產品名稱	Nooie_Smart Plug_NSP01_U	ser Manual		完稿日期	2022-06-16				
設計師	Zoe			材质	100g 金太阳双胶(雾面)				
成品尺寸	48*58mm(风琴折)			工艺					
牙刀 切线 折线	均不需印刷	版本号	V1.0	颜色	 Pantone 4131C Pantone 4141C #E1E3E3 C14 M9 Y10 K0 C18 M15 Y12 K0 				