



User's Manual




E10
Electric Surround Shooting pan

Product presentation



- ① background plate ② USB-A output with 5V2A
③ 3/8 screw hole, 38MM quick-mounting plate ④ round serving tray
⑤ 1/4, 3/8 threaded hole ⑥ Magic arm ⑦ Background plate fixing slot
⑧ ON/OFF ⑨ Indicator light ⑩ type-c Power port: input 5V2A
⑪ 2.5mm shutter jack ⑫ NP-F battery mount: Suitable for FS50/750/970 batteries.

Installation Instruction




Specifications

Model	E10
Input	5-7.4V 2A
Output	5V 2A
Communication Interface	Bluetooth 5.0
carrying capacity	8kg
operating temperature	-10~60℃
operating humidity	40%-80%RH at 25℃
storage temperature	-20 to 60℃
Storage Humidity	<93%RH at 40℃

APP download and connection



Android, iOS




Google play

you can search "Xuando" in the IOS store to download it


1. Scan the QR code to download the APP.
2. Tap the "ZY-E10" name to connect to the APP.

For Android users, please ensure the phone's GPS function is activated prior to using the APP.



The Bluetooth connection is successful and the video mode screen is displayed

Reset A&B



Click the delete icon to reset the AB point after deleting the current AB point.

Click the reset icon to restore the default AB point.


Set point A

Press and hold the A button or B button to move, release to stop, and click the confirmation button to confirm point A.

Set point B

Press the B button or the B button to move, release to stop, click the confirmation button to confirm point B, and automatically enter the video mode after confirming B.

Video Mode




Open the Real time shot, enter the mobile phone shooting interface, click the arrow key to start, the mobile phone starts recording.

The recorded video is saved in a folder. Click on the video file to open and view it. Click on the upper right corner to share and save to the album.


Long press the video file to choose whether to delete it.

Timelapse



Open the mobile phone joint shooting, enter the mobile phone shooting interface, click the start button to start the mobile phone to start shooting. After the shooting is completed, the APP will automatically synthesize it, no complicated operations are required.

Stop motion



Open the mobile phone joint shooting, enter the mobile phone shooting interface, click the start button to start the mobile phone to start shooting. After the shooting is completed, the APP will automatically synthesize it, no complicated operations are required.

The recorded video is saved in a folder. Click on the video file to open and view it. Click on the upper right corner to share and save to the album.

Long press the video file to choose whether to delete it.

Shortcut key



Matters need attention

1. Please use output DCSV-7.4V2A.
2. Please do not put the product in the sunlight.
3. Please do not put the product in the fire source or close to the fire source area.
4. It is strictly prohibited to disassemble the product by yourself to avoid personal injury and property damage.
5. Please do not exceed the maximum load capacity of the product use.
6. This device contains small parts, please do not swallow, please ensure that young children away from these small parts.
7. The edges of the product may be sharp, please handle with care.

Warranty card

Product name: _____
Product model: _____
Dealers: _____
Purchase date: _____
Customer name: _____
Phone number: _____
Customer address: _____
Purchase way: _____
Fault descriptions: _____

Maintenance record

Inspection date	Fault descriptions	Result	Repairer

Warranty Regulations

1. The warranty period of this product is one year from the date of purchase.
 2. During the warranty period, a fault caused by the normal use of a product will be repair free charge.
 3. During the warranty period, if one of following situations occurs, it must be charge for maintenance:
 - 1) Unable to provide this guarantee and valid purchase voucher.
 - 2) Fault and damage caused by self-repair.
 - 3) Failure or damage caused by delivery, moving, or falling after receiving the product.
 - 4) Failure or damage caused by other unavoidable external factors.
 - 5) Failure or damage caused by leads to water or other liquid ingestion of equipment.
 - 6) Damage caused by using voltage other the specified.
 4. Accessories are not covered by the warranty.
- This warranty alone, without any other express or implied warranty, please take good care of the valid purchase voucher.


安装示意图



产品参数


产品型号	E10
输入	5-7.4V 2A
输出	5V 2A
通讯方式	蓝牙 5.0
产品承重	水平承重:8kg
工作温度	-10~60℃
储存湿度	40%-80%HR at 25℃
工作湿度	-20 to 60℃
储存湿度	<93%HR at 40℃

产品介绍



- ① 背景板 ② USB-A输出, 输出为5V2A ③ 3/8螺丝孔, 38MM快装
④ 置物盘 ⑤ 1/4, 3/8拓展螺丝孔 ⑥ 方向魔术手
⑦ 背景板固定夹 ⑧ 开关 ⑨ 指示灯 ⑩ type-c供电口: 输入为5V2A
⑪ 2.5mm快门口 ⑫ NP-F电池座: 支持FS50/F750/F970电池

APP下载与连接



iOS端可在商店搜索Xuando下载

1. 打开手机摄像头扫描二维码。
2. 根据手机系统点击下载。
3. 点击 ZY-E10 名称连接APP。

安卓手机需要打开位置方可使用。



如果没有弹出蓝牙名称, 点击“搜索蓝牙”, 点击蓝牙名称即可连接。连接成功后进入视频模式。

A B点设置



点击删除图标, 删除当前AB点后, 可重新设置AB点。

点击复位图标, 恢复默认的A点。

A点设置

长按反转或正转图标移动, 松开停止, 点击确认键确认A点。

B点设置

长按反转或正转图标移动, 松开停止, 点击确认键确认B点, 确认B点后自动进入视频模式。

视频模式



打开手机快门, 进入手机拍摄界面, 点击旋转按钮启动并手机开始录制。

录制好的视频在文件夾保存, 点击查看视频, 点击右上角分享保存到相册。

长按视频文件可以选择是否删除。

延时摄影



打开手机快门, 进入手机拍摄界面, 点击开始按钮启动手机开始拍摄, 拍摄完成APP会自动合成, 无需复杂操作。

拍摄好的延时摄影视频保存在文件夾, 点击查看视频, 点击右上角分享保存到相册。

长按视频文件可以选择是否删除。

定格动画



打开手机快门, 进入手机拍摄界面, 点击开始按钮启动手机开始拍摄, 拍摄完成APP会自动合成, 无需复杂操作。

拍摄好的定格动画视频保存在文件夾, 点击查看视频, 点击右上角分享保存到相册。

长按视频文件可以选择是否删除。

快捷键



点击回到蓝牙连接界面。

查看APP版本。

查看固件版本。

注意事项

1. 请使用输出为DC5V-7.4V 2A的适配器或电池供电。
2. 请不要把产品放在日光下暴晒。
3. 请不要把产品放于火源或接近火源区域。
4. 严禁自行拆卸, 以免造成人身伤害和财产损失。
5. 请勿超过本产品最大承重使用。
6. 此设备含有细小零件, 请勿吞食, 请确保幼童远离这些细小零件。
7. 产品边缘部分可能较为锋利, 请小心操作。

产品保修卡

产品名称: _____ 产品型号: _____
经销商: _____ 经销商电话: _____
购买日期: _____ 年 _____ 月 _____ 日
客户名称: _____ 联系电话: _____
客户地址: _____
购买途径: _____
故障描述: _____

维修记录

送修日期	故障描述	故障分析/结果	检修员

保修条例

1. 自购买之日起保修期为一年。
2. 在保修期间, 按照使用说明书正常使用状况下发生的故障 (由本公司正式工作人员判定), 予以免费维修。
3. 在保修期间, 如发生以下情况之一, 必须作为收费维修:
 - 1) 不能够提供本保证书及有效购货凭证;
 - 2) 错误使用、私自拆修所造成的故障及损坏;
 - 3) 收货后的运送、搬动、跌落造成的故障或损坏;
 - 4) 其它不可避免的外来因素造成的故障或损坏;
 - 5) 设备进水或其它溶液造成的故障或损坏;
 - 6) 使用指定以外的电源, 电压所造成的损坏;
4. 产品配件不在保修之内。

(仅作以上保证, 不作其它任何明示或默示的保证, 请妥善保管好有效购买凭证)

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.