


User Manual

APP & Remote Control Thrusting & Vibrating Anal Plug





Please fully charge before use for the first time
Read the manual carefully before using the product please!


RoHS
Made in China



Product View



Thrusting Mode Tail Vibrating Mode



How to Use and Button Description

Anal Plug		
	Switch on/off button & Tail vibration frequency button	Switch on/off by pressing 2 seconds. After power on, press  button to enter Tail Vibrating Mode. Enter next mode by pressing the button again, there are 3 speed modes & 6 frequency modes available.
	Thrusting frequency button	After power on, press  button to enter Thrusting Mode. Enter next mode by pressing the button again, there are 3 speed modes & 6 frequency mode available.
Indicator light		After turning on, the start-up button light is always on. The thrusting button and the tail vibration frequency button flicker with the change of frequency. The white light is always on when it is fully charged.
Remote		
	Switch on/off button	Switch on/off by pressing 2 seconds.
	Tail vibration frequency button	After power on, press  button to enter Tail Vibrating Mode. Enter next mode by pressing the button again, there are 3 speed modes & 6 frequency modes available.

Continued

	Thrusting frequency button	After power on, press  button to enter Thrusting Mode. Enter next mode by pressing the button again, there are 3 speed modes & 6 frequency mode available.
	Indicator light	After turning on, the start-up button light is always on. The thrusting button and the tail vibration frequency button follow the frequency to light up.

Recycling Guide

The raw materials of this product are in line with environmental requirements. The product has a built-in lithium battery, so it can not be thrown away anywhere when you are not using it anymore. Please return the products with lithium batteries to the professional recycling site, and then by a unified treatment. Pay attention to protect the environment.

How to Charge(LED Indicator)

Power on	Indicator on.	
Working	Indicator flashes when pressing button.	
Power off	Indicator off.	
State of charging	Low power	Indicator flashes slowly for 5 times and the vibrator off automatically.
	Charging	Flashing.
	Fully Charged	Indicator on.

Safety Instructions

1. Please check if there is any damage caused by transportation, if yes, please contact suppliers for replacement.
2. Please read and follow the user manual before using.
3. This product is for adults use only, can NOT be used as a contraceptive.
4. Please put the product in proper condition and out of the reach of the children.
5. Please do NOT exert excessive force when using to avoid injury.
6. Please do NOT share the product with others.
7. Please immediately stop if you feel any uncomfortable when using this product.
8. Please check the condition of the product regularly, please stop using if any damage is found.

Product Specification

Product Name: APP & Remote Control Thrusting
& Vibrating Anal Plug

Material: ABS & Food Grade Silicone

Product Size: 3.7 * 1.4 * 5.7 inches/1.5 * 2.4 * 0.6 inches

Accessories: USB Charging Cable

Battery Capacity: 500mAh

Rated Voltage: 3.7V

Power Supply: Built-in Lithium Battery

Noise: ≤ 55 db

Charging Time: 2 h

Using Time: 1h

How to Install

This product does not need to be installed. But please fully charge before use for the first time.

The remote control needs to remove the insulating piece of the button battery when it is used for the first time.

The APP installation method is as follows.

Download and install " Love Spouse" APP



Love Spouse APP



Scan the QR code to activate and extend your warranty



ISO System:

1. Search for " Love Spouse "  in App Store, download and install.
2. Scan the QR code with your mobile phone, and follow the prompts to download and install the " Love Spouse " APP.

Android System:

1. Search for "Love Spouse" in  Google Play, download and install.
2. Scan the QR code with your mobile phone, select the first or third one, and follow the prompts to download and install the " Love Spouse " APP.

Register and log in




1. Click the " Love Spouse " icon to enter the APP, please register for the first login.
2. Click "New User Registration" and complete the registration with your mobile phone number or email address. When the mobile phone cannot receive the verification code, please use the email to register instead.
3. After registration, enter the account and password to log in to the APP.

Device Binding



View 1




View 2




View Code

1. The customer needs to bind the device after logging in for the first time.
2. Click "+", the device binding scan box will appear (View 1), please scan the product ID QR code (View code)



View 3



View 4

3. Click the “enter device code”(View1) will appear (View 2) and you can enter this device code: **4175**. After entering, (View 3) will appear.


4. Long press the device icon to delete the device and modify the device name. (View 4)

5. After the device is deleted, if you want to restore it, you need to scan the device binding code or enter the code number again.

Device Connection



View 5




View 6


First turn on the switch of the device, and then click the device icon in the APP. If the Bluetooth of the mobile phone is not turned on at this time, a prompt to allow Bluetooth to be turned on will appear. (View 5)

After clicking Allow, the mobile phone will automatically turn on the Bluetooth (iPhone Manually turn on the Bluetooth switch). At this time, the device and the phone begin to establish a connection, and enter the device control interface after the connection is successful. (View 6)

Equipment connection




View 8




View 9

1. Classic mode: Click any icon in 18 mode on the APP, and the device will start the corresponding thrusting & vibrating frequency. At the same time, the icon on the APP will flash. Click this icon again, the device will stop vibrating and enter the standby state, and the APP icon will also stop flashing. (View 8)
2. Video mode: Click on the video mode or slide the operation interface of the APP to enter the video mode. You can click the "select local video" to choose any one you like, then you can enjoy those 18 modes with your own video part. (View 9)



View 10



View 11

3. Music mode: Click on the music mode or slide the operation interface of the APP to enter the music mode. The APP will automatically search for the music player in the mobile phone. If you click on a music player to play music, the device will vibrate as the music changes. If you want to stop the music mode, click or slide to other control interface. (View 10)


Note:

If the sound of the mobile phone playing music is too low, it may not be able to drive the device to vibrate.

Apple phones can only use the music player that comes with the system.




View 12




View 13

4. Draw something: Click on the draw something or slide the operation interface of the APP to enter the draw something. Click + under (View 11) and the (View 12) interface appears, draw a line at will on the screen, save and name it and enter the (View 13) interface, click the triangle symbol on the name to enter the mode of free stroke saving.



View 14




View 15

5. Shake mode: Click on the shake mode or slide the operation interface of the APP to enter the shake mode, and the device will vibrate according to the shaking rhythm and amplitude of your phone (View 14).


6. Interactive mode:

6.1 Tap the interactive mode or slide the operation interface of the APP to enter the interactive mode. (View 15)

6.2 Click the My device on the APP homepage to enter the interactive mode. (View 16)



View 16



View 17


6.3 Add friend

6.3.1 Click "+" to show the interactive interface.

(View 15), and you will enter the page (View 17), you can search friend by his personal ID (View 18) or email.




View 18




View 19

6.3.2 After the search results are displayed, click the add button on the right, and the system will send the friend request information to the target user. (View 19)




View 20




View 21

6.3.3 After the other party receives the message of the friend application, click the message button to enter the message center to View the message (the red dot is the unread message) (View 20), agree or reject the other party's friend application.

6.3.4 After the friend is successfully added (View 21), click the friend icon to send message, delete, black out, or report the friend.




View 22




View 23

6.3.5 Go back to the homepage and click my device to in the interactive mode, and select your friend which you want to interacted (View 22 & 23).

6.3.6 After the interactive connection is successful, the video is not turned on by default. You need to send invitation of video or voice (View 24) and the other party agrees to open the video function before opening both parties (View 25) .



View 24



View 25

Note

1. If the other party is not connected to the toy, your interactive interface has no control buttons at this time. The toy must be connected to the other party to have control buttons on your interactive interface. The device connection button on this interface is the Bluetooth icon in the upper right corner.
2. When interacting, the control button is to control the other party's device, not your own device.

FCC Caution

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.