

英日文

N09-A User Manual

Thanks for using our wireless electronic products. For a good user experience, please read the manual carefully before using the products. Notice: To avoid unnecessary troubles, please do not disassemble these products by yourself, and please use the standard charger to charge.

EN AD

Make sure that the ear caps face down and put the earbuds into the ear in the angle shown as the picture on the right.

After putting on the earbuds, gently rotating the earbuds to a comfortable and secure position shown as picture 3 on the right. Now the earbuds are put on correctly!

Error demonstration
Do not wear the earbuds like the way shown as the picture on the right

3. Take out from case, the indicator will turn to Red and Blue alternately.
Warm notice If the earbuds are not turned on or there is no sound come out, please put them back in the charging case again to make sure that they are in the charging state before taking them out for use.

Red & Blue Flash
Indicator of

4. The indicator of one earbud will go off and another will flash red and blue light alternately. (In pairing mode)

Button control

MFB Power Switch

Take-out from case OR press and hold for 5 seconds.

When back into case no connection for 5 minutes.

Siri and other Voice Assistant

iOS and part of the Android users can triple click the left or right power switch to turn on the voice assistant.

The voice assistant will be automatically activated depends in different OS in mobile system.

Earbuds indicator

Status	Light
Turn on	The blue light flashes for 1 second
Turn off	The red light flashes for 1 second
Search earbuds	Red and blue light flash alternately
The earbuds connect successfully	The Red and blue light of the main earbud flashes, voice earbud goes out
Connect with mobile phone successfully	No light
Music play	No light
Low battery	Red light of earbud flashes once every 5s
Charging	Red light on
Full battery	Red light off

Specifications

Version	V5.2+EDR
Support	HFP,HSP,A2DP,AVRCP
Transmission distance	10m
Frequency range	2,402GHz-2,480GHz
Speaker	Φ 10mm*2
Impedance	32 Ω
Standby time	70 hours
Talk time	5 hours
Playing time	6 hours
Earbud battery capacity	50mAh
Fully charged time	About 1.5 hour
Charging case battery capacity	480mAh
Charging time of charging case	About 1.5 hour
Weight (single earbud)	4.8 g

Notice:
1. If the charging case is out of power, it may cause the earbuds to fail to shut down and remain connected to the phone even when they are placed in the charging case. So please remember to charge the charging case in time.

2. If moisture remains at the audio output hole, the sound may become fuzzy or completely inaudible. This is completely normal. In this case, please remove the earplugs and shake the audio output hole down several times to allow water to flow out or let it air dry for 1-2 hours, then the sound quality will become normal.

Attentions

The Charging cable is not waterproof
The Charging case is not waterproof
Do not use hot water to disinfect the product

If there is water droplet on the surface, please wipe it with a dry cloth before putting them back into the charging case to avoid damaging the device.

Tip:
1. If the product is dry, please do not rinse it directly with water or use boiling water to soak and disinfect it. It is recommended to wipe the earbuds with an alcohol cloth or a wet paper towel.
2. If the product falls into the water accidentally, please pick it up in time and dry it with natural wind or dry it in the sun for two hours before using it. (Otherwise it will affect the sound quality, thus fail to give you a better using experience)

Product overview

1. Choose the ear cap that suits you.

First time using

1. Tear off the insulating film.

2. Put the earbuds into the charging case to charge.

5. Turn on the Bluetooth function on your phone and search for **【N09-A】** and connect it.

Warm notice
1. If indicators of both earbuds keep flashing red and blue. Click either earbud's power switch twice. Then the indicator of one earbud will flash red and blue alternately, another will go off. (in pairing mode)
2. If you want to switch the Bluetooth connection to another device, please disable the Bluetooth function in the previously connected device OR delete the pairing name of "N09-A" from the original device. Then the pairing name of "N09-A" can be searched in new device and connect successfully.

Restore factory setting

1. When the earbud is on with mobile phone unconnected, click the left and right power switch simultaneously four times quickly. The red and blue lights will be on for 2 seconds and then it will clear its memory and the earbuds will shut down.

2. Please delete all paired records on the phone and search again for "N09-A" on the bluetooth of mobile phone and reconnect.

Charging case indicator

Power display

10%	☼
25%	○
50%	○○
75%	○○○
100%	○○○○

Indicator

Charging for case	Indicator
White light flashes	White light flashes
Four lights on the charging case keep white	Four lights on the charging case keep white
Charging for earbuds	White light on
Low Battery	First light on the left flashes white

Note: Please put both earbuds in the charging case to fully charge them on first use.

Charging case
Please use a charger with an output voltage of DC5V/1A to charge the charging case. You can also use a computer USB or other USB interface charger to charge (Must choose a charger certified by a regular manufacturer).

Charge warning
While charging, do not press the earbud power button, which will cause pairing failure, then you need to reset.

Signal transmission distance as below:

1. Do not use corrosive liquid to clean this product.
2. If it comes into contact with chemicals, please rub it with a damp cloth wet with clean water.
3. Do not use this product under extreme circumstances for temperature below -10 degree Celsius or above 60 degree Celsius.
4. To avoid explosion, please do not touch this product into fire.
5. To avoid scratches, please do not touch the earbuds with sharp objects.
6. Do not insert objects into the earbuds, otherwise it would cause damage to the internal components.
7. Do not disassemble the earbud.
8. Please keep regular charge to earbuds, don't leave them become empty battery state to keep their lifetime.
9. Please do not charge products with power adapter over 2A current. Excessive current may cause the damage to battery.

Battery Warning!
There is a built-in Lithium battery in this product. To avoid explosion, do NOT expose the product to strong sunlight, fire or throw it into fire.

N09-A 取扱説明書

本社のワイヤレス製品をご購入いただき、誠にありがとうございます。より良い使用感を得るため、ご使用前にマニュアルをお読みください。事故を避けるため、本製品の解体はご遠慮ください。付属充電器で充電することを願います。

JP AD

耳のキャップを顔を下にし、右の画像として表示される角度で耳にイヤホンをはさむことを確認します。

イヤホンの上に置くことの後、種やかに、AvatarPic 3を示している状態で完全に位置に、イヤホンをはさみつけてください。今すぐイヤホンが正しく置かれます！

エラーデモ
イヤホンは右と左の耳が反対です。図に示すように、右の写真

3. 再度同時に両耳イヤホンを取り出しますとイヤホンが自動起動する上に左右ペアリングモードに入ります。(赤・青ランプが交互に点滅します)

溫馨提示:
イヤホンが起動していない場合や音声が聞こえない場合は、充電ケースを開きイヤホンを確認してから取り出して使用してください。

赤と青ランプ点滅
消灯

4. 左右ペアリング自動に完成後、右耳イヤホンは点滅が消えますが左耳イヤホンは赤・青ランプ交互に点滅します。

MFBボタン機能紹介

MFBタッチボタン

ケースから取り出されると電源オンしますまたは5秒押し続けます

ケースに隠されると電源オフしますまたは5秒押し続けます

Siri呼び出し

iOSシステム端末または一部のAndroidシステムと接続状態で左耳イヤホンor右耳イヤホンを3回連続タッチしますとSiri等の音声アシスト喚起可能です。使用完了後、または一回タッチしますとSiriを閉めることができます。

音声アシスタントは自動的にモバイルシステム内の別のOSに依存してアクティブになります。

イヤホンインジケータ

充電中	点灯表示
充電終了	青ランプが1秒点灯
イヤホン充電	赤ランプが1秒点灯
イヤホン充電	2つのイヤホンの赤と青ランプが交互に点滅
イヤホン充電	2つのイヤホンが接続成功
イヤホン充電	主耳赤青が交互に点滅し、副耳が消灯する
イヤホン充電	消灯
イヤホン充電	再生中
イヤホン充電	消灯
イヤホン充電	低電圧
イヤホン充電	イヤホンの赤いライトが6回に1回点滅します
イヤホン充電	充電中
イヤホン充電	赤ランプ点灯
イヤホン充電	充電終了
イヤホン充電	赤ランプ消灯

商品規格

バージョン	V5.2+EDR
プロファイル	HFP,HSP,A2DP,AVRCP
通信距離	10 m
使用周波数	2,402GHz-2,480GHz
スピーカー	Φ 10mm*2
電圧系統	32 Ω
待受時間	70時間
通話時間	5時間
音楽再生時間	6時間
イヤホンバッテリー容量	50mAh
イヤホン充電時間	約1.5時間
充電ケースバッテリー容量	480mAh
充電ケースの充電時間	約1.5時間
片耳イヤホンの重量	4.8g

注意:
1. 充電ケースは電量がない場合、イヤホンに充電ケースに入れたときにイヤホンはシャットダウンしません。またスマホとの接続を維持しています。そのときはすぐに充電ケースに充電してください。

2. イヤホンの中に水分が残っている場合、音声はぼんやりして、聞こえない場合があります。これは通常のことです。イヤホンを取り出して下に向けて何回振って水を流したり乾いた布で拭いて使えます。あるいは1〜2時間自然風乾した後、音質が正常に戻ります。

注意事項

充電ケーブルは防水ではありません
充電ケースは防水ではありません
お湯で洗わないでください

イヤホンに水がある時は布で拭いてから充電ケースに戻してください

ご注意:
1. 製品が汚れたら、直接水で洗わないでください。お湯に浸して消毒しないでください。アルコール入りの液体やウェットティッシュで耳栓を拭くのがオススメです。
2. 水に落ちたら、自然風で乾かしたり、日光の照らさ2時間後よりしていただく(音質に影響を与え、より良い体験ができるようになります)
3. イヤホンに水が入った場合は、イヤホンを取り出して、綿棒をイヤホンにきれいにしてください。

4. イヤホンは充電不良の場合で、綿棒で充電電柱の位置を綿棒できいに差し込んでから充電してください。

商品図面

1. 両耳イヤホンを取り出して充電接点に貼り付けている絶縁膜を剥がしてください。

2. 両耳イヤホンをケースに戻してください。(イヤホンは充電状態になります)

初めて使用する

5. スマホのBluetooth機能をお開きにして、デバイス一覧から【N09-A】というデバイスを選択して接続してください。

溫馨提示:
△ 左右の耳がペアリングできない場合、どちらかのイヤホンが音が出ない場合、先に両側のBluetooth機能をオフにして、2つのイヤホンの赤・青ランプが交互に点滅するまで、その中のイヤホンを3回連続タッチしてからペアリングを再開します(左右ペアリング自動に完成後、イヤホンは点滅が消えますがもう一方のイヤホンは赤・青ランプ交互に点滅します)
△ 別のデバイスに切り替える場合は、最初に以前に接続したデバイスのBluetooth機能をオフにするか、N09-Aペアリング名を削除する必要があります。そうすれば、新しいデバイスで接続ができます。

リセットしてください!

1. スマホに接続されていないときは、同時に左右のキーをすばやく4回押すと、赤と青のランプが2秒点灯し、その後、メモリーをクリアして、自動的に電源をオフします。

2. スマホのBluetoothから古いペアリング名を削除し、再度検索します。

充電ケースインジケータ

電量表示

充電ケース充電	白ランプ点滅
充電完成	4個白ランプが点灯
イヤホン充電	白ランプ点灯
ケースの電量が高い	左の1つ白ランプが点滅

ご注意: 初回の使用はイヤホンの電量を100%まで充電してください。

充電ケースの充電:
必ず出力DC5V/1Aの充電器をご使用ください。パソコンやUSBの集線口がある機器を利用できません。(ご注意: 認証済みの充電器をご利用ください。)

充電警告: 左右ペアリングできなくなるように、充電状態中のイヤホンボタンをタッチしないでください。万が一の場合は、イヤホンを初期化してください。

信号伝送距離のご注意(下の図参照)

1. 腐食性の溶剤で洗わないでください。
2. 化学製品に触れたら、水でぬれた布を拭いてください。
3. 本商品は-10〜60℃の環境でご使用ください。
4. 燃焼を防ぐため、本品を火から離れて置いてください。
5. 腐食を防ぐために本製品を酸利物とのへりつからなければに注意ください。
6. イヤホンの電子部品の損傷を防ぐため、小物をイヤホンの中に入れてください。
7. お客様自らの修理、ご解体などは絶対にやめてください。
8. 長時間使用する予定がない場合(1ヶ月以上)、本製品の性能を保護するために時折充電をしてください。
9. 2A以上の過大な電流はバッテリーに損傷を与える恐れがあります。2A以上の充電アダプターのご使用は絶対にやめてください。

バッテリーについて!
本製品はリチウム電池を内蔵しています。爆発を防ぐため、目当たりや火のもとなどから離れて置いてください。

材質: 128g銅版紙
 尺寸: 67x48mm
 装订: 风琴折再对折, 正反面 (英文在正面)
 注: 大货只做英日文

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.