


## PACKING LIST

A3 true wireless headphones	X1	A3 Charge warehouse	X1
Ear cap (small/medium/large)	X3	The instructions	X1
cable	X1		

## EAR CAP

The A3 headphones come in three sizes. Cap, please choose the right ear and the left ear Wear in full size (including the headphone book). The left earphone can only be worn by the left ear. The right earphone can only be worn by the right ear.



## CONNECTION MATCHING

1. Open the charging compartment, take out the left and right earphones, and the left and right earphones will automatically start up and pair.
2. Initial pairing, turn on the phone Settings, access Bluetooth and turn on Bluetooth switch.
3. Search the Bluetooth device bar (A3) and click it to connect automatically.

## THE HEADSET AUTOMATICALLY RECONNECTS AND PAIRS

After completing the first device pairing in accordance with the instructions, remove the headset from the charging bin and the headset will be self-loaded. Move back to the Bluetooth device.

Note: If the headset was previously paired with more than one device, the headset will automatically reconnect to the last one. The Bluetooth device used.

1. Open the top cover of the charging case and take out the earphone. The red and blue light of the left and right earphones flashes, followed by the blue light of the two earphones. Blink, left and right earphones pair successfully.
2. Open the charging compartment and take out the headset. The Red and blue lights of the left and right headphones flash alternately to show that the pair is not paired. double-click on the left and right earphone touch area twice (within 3 seconds of this action) and the paired pair will continue flashing.

## FACTORY DATA RESET

When the left and right headphones do not combine to connect, or when one of the headphones does not play music, please perform the following Operation:

1. Put the left and right headphones into the charging case (they will enter the charging state).
2. Open the charging bin, take out the left and right earphones, automatically boot and pair, and reset successfully.
3. Open the interface of Bluetooth device, search for (A3) and click Connect.
4. Double-click the left and right earphone touch area twice at the same time (complete this action in 3 seconds). The left and right earphone blue light flashes alternately.

## CHARGING

### EARPIECE

Put the left and right earphones back into the charging box, close the top cover of the charging box, and the left and right earphones will charge automatically.

### CHARGING CASE CHARGING

When the charging box is charged, the charge box display will show the power, and when the charging bin is full, the display will show 100% power.

## FREQUENTLY ASKED QUESTIONS

1. If the sound quality is not good, please try to change the size and model of the earplugs: small, medium and large.
2. When you are in the subway, the airport, and other places with strong electromagnetic interference, the Bluetooth signal will be random. There is a staccato in the concert. Because there are so many devices in the 2.4G wireless band, they tend to interfere with each other. Cause. For some playback devices, audio and video will appear out of sync, TV and other non-mobile device performance. This is mainly caused by the low Bluetooth version of these devices and their incompatibility.
3. If you encounter the following problems, please put the earphone into the charging box to turn it off, then take it out, the earphone will be heavy. New auto-boot pairing. If the problem still cannot be solved, please refer to the manual to restore the factory setting. The previously connected Bluetooth device (A3) has been deleted.
4. The left and right headphones don't match.
5. The headset cannot be connected to the Bluetooth device.
6. No sound from the left or right earphone.

## AFTER-SALE TECHNICAL SERVICE

If you have any further questions, please contact our online customer service.

## IMPORTANT SAFETY INFORMATION

Please handle the earphone with care. Containing highly sensitive electronic components and batteries, falling, burning, piercing, squeezing, disassembly or exposure to high temperature or liquid will cause damage or human injury. Do not use broken headphones and follow these tips:

Do not use this device near water sources.

Please use a dry cloth to clean.

Use only the accessories specified by the manufacturer.

Repair service should be provided by authorized professionals.



This product contains a built-in rechargeable lithium battery. Battery use safety warning: do not disassemble, impact, squeeze or throw into the fire; Do not place in high temperature environment; Do not use the battery after soaking in water.



Product model: Bluetooth headset

Bluetooth name: A3

Bluetooth version: Bluetooth 5.0

Transmission distance: barrier-free distance of 10-15 meters

Product loudspeaker: composite titanium film true copper ring loudspeaker

Working hours: about 6-7 hours

Standby time of charging bin: about 40-50 days

Headphone battery capacity: Button lithium ion battery 35 mAh.

Charging bin Battery capacity: 350 mA (with protective plate)

## FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.