

103.50±0.25mm

60.8±0.25mm

Portable Power Station

- Model:VP21
- Capacity: 25.6V 50Ah 1280Wh
- Anderson Input: 12-56V-12A Max, 400W Max
- AC Input: 120V-60Hz 10.5A
- AC Output (x4): 120V-60Hz 10A, Total 1200W (Surge 2400W)
- AC Parallel Interface (Being Connected): 120V-60Hz, 1200W
- DC5521 Output (x2): 12V-3A 30W Max per port, Total 72W
- Car Output: 12V-10A, 120W Max
- (2) DC5521 Output: Car Output: Total 120W
- USB-C Output (x2): 5V-3A, 9V-3A, 12V-3A, 15V-3A, 20V-5A 100W Max per port, Total 200W
- USB-A Output (x2): 5V-3A, 9V-2A, 12V-1.5A 18W Max per port, Total 36W
- Wireless Output: 10W Max
- Max. Output Power: 1320W
- Discharging Temperature: -10-40°C
- Charging Temperature: 0-40°C
- Date Code: 04-22-2022
- S/N

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

FCC ID: 2A55XVP21100



MADE IN CHINA

WARNING!


- Do not short-circuit the unit. To avoid short-circuiting, keep the unit away from all metal objects (e.g. coins, hair pins, keys, etc.).
- Do not heat the unit, or dispose of it in fire, water or other liquids. Keep away from high temperatures. Do not expose the unit to direct sunlight.
- Keep away from high humidity, dusty places.
- Do not drop and place heavy objects on, or allow strong impact to this unit.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- The unit may become hot when charging. This is normal. Be careful when handling.
- Use the unit properly to avoid electric shock.
- The product is only used for emergency power station, it can not replace the standard DC or AC power of household appliances or digital products.
- Do not overcharge the internal battery. See Instruction Manual.
- This device is intended to be used indoors only. Do not use outdoors.
- This device is not intended for use in a commercial repair facility.

AVERTISSEMENT!

- Ne court-circuisez pas l'appareil. Pour éviter tout court-circuit, éloignez l'appareil de tout objet métallique (par exemple, pièces de monnaie, épingles à cheveux, etc.).
- Ne chauffez pas l'appareil et ne le jetez pas dans le feu, l'eau ou d'autres liquides. Tenez à l'écart des températures élevées. N'exposez pas l'appareil à la lumière directe du soleil.
- Ne s'approche pas de l'appareil si vous n'avez pas l'expérience et les connaissances, à moins qu'elles n'aient reçu une supervision ou des instructions concernant.
- Ne démontez pas et ne réassemblez pas cet appareil.
- Ne laissez pas d'enfants se placer pas d'objets lourds dessus et ne laissez pas de chocs violents sur cet appareil.
- Cet appareil n'est pas destiné à être utilisé par des personnes âgées, handicapées, ou à moins qu'elles n'aient reçu une supervision ou des instructions concernant.
- L'utilisation de l'appareil par une personne responsable de leur sécurité.
- Les enfants doivent être surveillés pour s'assurer qu'ils ne jouent pas avec l'appareil.
- L'appareil peut devenir chaud pendant la charge. C'est normal. Soyez prudent lors de la manipulation.
- Utilisez l'appareil correctement pour éviter les chocs électrocutants. Le produit n'est utilisé que pour la centrale électrique de secours. Il ne peut pas remplacer l'alimentation CC ou CA standard des appareils ménagers ou des produits numériques.
- Ne pas surcharger la batterie interne. Consultez le manuel d'utilisation.
- Cet appareil est destiné à être utilisé à l'intérieur uniquement. Ne pas l'utiliser à l'extérieur.
- Cet appareil n'est pas destiné à être utilisé dans un atelier de réparation commerciale.

Label

Label Positions



Label Positions