

Model:RR114-4BT

P/N: RR114-H2T

REMOTE PROGRAMMING

Please make sure to read through the programming before attempting. All remotes that are expected to work for the vehicle will need to be with you in the vehicle before attempting the programming. Any remotes not present at the time of programming will cease to function until reprogrammed.

1. Enter the vehicle, close, and unlock all doors using the power lock switch on the driver's door.
2. Within 4 seconds, with a key that is cut and working for the vehicle currently, insert the key into the ignition cylinder and turn to the ON position as far as it will go without starting. Leave in the ON position.
3. Within four (4) seconds using any remote (continue using the same remote for the following steps), press and release the LOCK button once (We recommend using a working remote if you have one to activate the programming mode).
4. Within four (4) seconds switch the key to the OFF position.
5. Repeat Steps 2-4 two (2) more times then proceed to step 6.
6. Within four (4) seconds turn the key to the ON position as far as it will go without starting and leave in the ON position, then within four (4) seconds press the LOCK button on the same remote you have been using.

①

At this point the vehicle door locks should automatically lock and unlock, indicating that the programming mode has been activated.

(If the door locks do not cycle automatically then the programming procedure has failed and you need to restart the procedure from STEP 1)

7. Once the door locks stop cycling, within four (4) seconds press the LOCK button on the same remote you have been using. The door locks should automatically lock and unlock indicating that the remote programming has been accepted.

8. Repeat STEP 7 for all remaining remotes you wish to program (You can program up to 4 remotes total).

9. Once you have programmed all your remotes, exit the programming mode by turning the key off and removing it from the ignition.

10. Test all remotes to ensure they are functioning. If any do not function, restart the programming procedure from STEP 1 and switch the order in which you are programming the remotes (STEP 7).

KEY PROGRAMMING

Dealer / Locksmith programming only

Please take attention that changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

②