


# billboard

## Bluetooth speaker

**Bluetooth**



**Initial Production**

This device is designed to be used with a power source. It is not intended to be used with a power source that is not specified in the user manual.

**BBZ711**

1. Turn on the power source.

2. Press the power button to turn on the speaker.

3. Press the Bluetooth button to enter pairing mode.

4. Press the play/pause button to play music.

5. Press the volume up/down buttons to adjust the volume.

6. Press the power button to turn off the speaker.

7. Press the Bluetooth button to exit pairing mode.

8. Press the power button to turn off the power source.

Accessories and address	Accessories and address	Accessories and address	Accessories and address
Power source	Power source	Power source	Power source
Bluetooth module	Bluetooth module	Bluetooth module	Bluetooth module
Speaker terminals	Speaker terminals	Speaker terminals	Speaker terminals
Power source	Power source	Power source	Power source
Bluetooth module	Bluetooth module	Bluetooth module	Bluetooth module
Speaker terminals	Speaker terminals	Speaker terminals	Speaker terminals

**Battery Information**

The speaker has a lithium-ion battery. The battery life is approximately 10 hours. The battery should be recharged when the charge indicator shows a low level.

**Speaker Information**

The speaker has a maximum output power of 10W. The speaker should be used in a well-ventilated area. The speaker should not be used near flammable materials.

**Bluetooth Information**

The speaker supports Bluetooth 4.2. The speaker should be paired with a Bluetooth-enabled device. The speaker should be used within the range of the Bluetooth signal.

**LIMITED WARRANTY**

Billboard LLC warrants that the product will be free from defects in materials and workmanship for the period specified in the warranty card. This warranty does not cover damage caused by misuse, accident, or unauthorized repair.

**WARRANTY CARD**

Product Name: Billboard Bluetooth Speaker  
 Model: BBZ711  
 Date of Purchase: \_\_\_\_\_  
 Retailer: \_\_\_\_\_

**Return Information**

For more information, please contact our customer service department. Our contact information is provided on the back of the product packaging.

**Customer Service**

Phone: 1-800-123-4567  
 Email: support@billboard.com  
 Website: www.billboard.com

**FCC Information**

This device complies with Part 15 of the FCC rules. Operation is subject to the condition that this device does not cause harmful interference. This device must accept any interference received, including interference that may cause undesired operation.

**FCC ID: B2CZ-BBZ711**

**Warning:** Changes or modifications to this equipment may void the warranty and may affect the performance of the device. Do not attempt to disassemble or repair this device. For safety, do not use this device near flammable liquids or gases. Do not use this device near children. Do not use this device near medical equipment. Do not use this device near aircraft. Do not use this device near power lines. Do not use this device near fire. Do not use this device near water. Do not use this device near heat. Do not use this device near magnets. Do not use this device near strong electromagnetic fields. Do not use this device near radio towers. Do not use this device near cell towers. Do not use this device near power lines. Do not use this device near fire. Do not use this device near water. Do not use this device near heat. Do not use this device near magnets. Do not use this device near radio towers. Do not use this device near cell towers.