



10 50 30

07

0 5 0 70 80 90 10 10 20 30 40 50



Inside the red square is the soldering point of the coaxial cable between the antenna connector and the mainboard.



=====End======