
105G双铜,双面印刷,印单色,风琴折,成品尺寸:70*95MM





M:Long press for 3s to turn on/off the speaker
Three quick press for pair with another speaker/unpair the bluetoot
Press once to pause/release the music
Phone call: Press once to answer/hang up a call.Long press to
reject a call

+:Long press to switch to the previous track Ouick press for volume up

-:Long press to switch to the next track Quick press for volume down

Status and Notifications

Power on/off: Long press "M" button(on the back of the speaker)for 3s,you will hear a prompt tone. For turn on, the white light at the top of the speaker flashes after the prompt tone ends. For turn off, the white light will go off after the prompt tone ends.

Charging: While being charging, there is a red light on on the back of the speaker(next to the AUX input). When fully charged, the red light will go off and the white light will keep flashing, which also means the speaker is on.

Power Display: Please connect the speaker to your device, then swipe down the screen and you will see M11's power display is next to your device's battery status.

3 Playback Modes and Operations

1.Bluetooth Mode:Turn on the speaker, you will hear a prompt tone, and the white light flashes. Then activate the bluetooth on your device, find and choose "M11" to connect, the white light will stop flashing and keep on when they connected successfully.
2.AUX input Mode: The Aux cord is included with the package, just use it connect with you device to play music.

3.TF Card: Supports up to 32GB TF card(not included in package

How to use TWS function? Situation 1:

If you purchase two M11 speakers and never paired with your device Please operate as the steps below:

Step 1: Turn both of them on, and you will see the white lights keep flashing, which means the speakers are on and ready to work

Step 2: Pick any one of them and press the "M" button two times quickly and wait for few seconds. The pairing between two speakers is done when you see one white light keeps flashing and the other one stops flashing and keeps on.

Step 3: Activate the bluetooth on your device, find and choose "M11" to connect and it will be done within 2 seconds, then you can enjoy TWS.

Situation 2:

If one or both of them have paired with your device, then you need to unpair it/them with this device before you use TWS function.

Step 1: Turn on the speaker and it will connect to your device automatically. Then click "disconnect" on your bluetooth settings, you will hear a prompt tone and the white light keeps flashing, means they have disconnected successfully.

(Notice: If all the speakers have paired with your device before, you need unpair them with your device one by one,don't turn them on at the same time)

Step2: Repeat "step 2 and step 3" of Situation 1 and you can enjoy the music.(if that not works, please turn them off manually and try again by the steps mentioned above)

How to unpair between two speakers? Click the "M" button 2 :imes quickly of any one of them, then you can play the music through a single speaker.

Auto-Reconnection Function

The last paired device will connect to M11 speaker automatically by default after the first connection. So you just need to turn it on and activate the bluetooth of your device next time.

Specifications

Bluetooth version: 5.3
Battery capacity: 1200mAh
Charging voltage: 5V == 1A
Loudspeaker output: 4Ω 5W
Frequency response: 50Hz-20kHz
STN: ≥85±2db
Distortion: < 1%
SIze: 87*95mm
Working distance: 10M
Weight: 0.348KG

Troubleshooting

1.Speaker can't be turn on?

Long press "M" button for 3s and still not working, please charge it for 10-20mins and try again, meanwhile, please check if the charging indicator lights up or not, if not, the battery may be defective. Please contact us for help.

(Email address: pk9990@163.com)

2.Speaker can't be connected to your device?Please turn off the speaker, forget "M11" on your bluetooth

search list. Then turn on the speaker and activate bluetooth to try again. Still not working, please contact us for help.

3.What if my speaker broke and the warranty has passed?

We aim to offer the best service to our customers, for this case, we offer 30-50% discount for those consumers who truly love Sanag to get a brand new product.

Precautions

Please fully charge the product before the first use.

Do not disassemble or repair this product for any reason, otherwise it may cause fire electronic breakdown or even completely damag

Do not soak the product in liquid for long time even it is

waterproof. If the charging is finished, please disconnect the charger from the device and unplug the charger. For continuous charging time, please no more than 12 hours.

Please do not dispose of the battery in the old household garbage. Improper disposal may lead to battery failure. In case of fire or explosion, please comply with local regulations to handle this product, battery and other accessories.

It is forbidden to disassemble,impact,squeeze or put the battery into the fire.In case of serious expansion,please do not continue to use it.

Do not repair this product by yourself.

Warranty Service

You are ensured to have our best after-sales service.

Any quality problems of the products within 12 months from the date of purchase. Please email(pk9990@163.com) Sanag CustomerService Team and we will provide a solution within 24 hours.

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- •Reorient or relocate the receiving antenna.
- •Increase the separation between the equipment and receiver.
- •Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- •Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.