

Wireless speaker Instruction Manual

8 inch LED Party Speaker

User Manual

AUX Cable

Adapter

1 x Wired Microphone

Carefully read instruction manual to operate this unit properly, and keep this manual for further reference.

Common issues and solutions:

phenomenon	reason	solution
No power	Power switch is not turned on	Turn on the power switch
	Built-in battery runs out	Charge the product via adapter or
	The plug is not plugged in properly or the power cable is	Reinsert or replace the power cable
	Power outlet is not electric field	Replace the power outlet
	Other reason	Contact after-sales dept.
No sounds	Volume is turn off or mute mode	Adjust the volume or turn off Mute mode
	Source media/input	Select the correct audio media/
	Audio media/input connection selected audio file	Reinsert media with supported format
	Other reason	Contact after-sales service
Microphone no sounds	Microphone volume is off or too	Adjust microphone volume
	Poor contact	Reinsert o replace the Microphone jack
	Other reason	Contact after-sales service
Distortion of sounds	Poor audio signal or volume too	Adjust audio files/signals or
	Battery running low	Full charged before using
Squeal from Microphone	The microphone volume is too loud or too close to the	Adjust microphone volume and keep properly distance from speakers

Tips: To protect your hearing from damage and avoid affecting others, recommends that do not use product at high volume for long time.

In order bring better using experience, please keep the accessories of this product.

Dear customer,

Thank you for selecting.


The series of this Rechargeable trolley speaker with good sounds performance , more function for selecting and easy operating . This product supports a variety of audio input and switching , such as USB SD / TF card built in decoder supports MP3/ WMA and other formats Bluetooth , FM radio , wireless microphone , Line -in , AUX input , microphone / guitar input Etc Some models may only support some of the functions listed above , the specific functions must be subject to the actual product) Meet all various demand of user , will be a good choice or entertainment , For more safety and full use of this product , please read this Manual careful before using.


Please keep this manual for reference, in order to bring better using experience , please keep the accessories of this product

Safety Warning

1. Please use within the specified power range (refer to the back plate), otherwise the product could be damaged.
2. Avoid tread, press, drag, fold the power cable and other cables
3. There are high - voltage parts inside , please do not disassemble the product without authorization, to avoid the risk of electric shock.
4. Pay more attention to the environment, do not use your Speaker in high temperature.high voltage or moist dusty environment.
5. Do not use during thunderstorms, unplug from the power socket and disconnect from other products.
6. Avoid the crash with tough objects, avoid falls from high places and rollovers.
7. Do not touch the back plate and other heat dissipation parts when the speaker is in use.
8. Use your speaker in the well ventilated areas, do not cover or put other items on top of it, and keep proper distance for the product to dissipate heat.
9. Forbidden to place liquid on the product to prevent the product from being tilted /leaked or the risk of electric shock.
10. This product is not safe for children to operate, please keep out of the reach of children.
11. This product has a built-in battery. Do not charge it for a long time.
12. Even if your Speaker is used infrequently, please charge it regularly to maintain the built-in battery performance and working life.

Warning Mark :

 high-voltage inside beware of electric shock

 Warning Mark: This product uses a power plug as a disconnection device. Must be easily accessible during use.

2. Storage media

This product supports storage media such as U disk/ SD card /TF card



USB



SD



TF

3. External input/output

(3.5mm)line-in audio input jack / RCA lotus input jack (L is left, R is right, corresponding to the white and red of the RCA line)(6mm)Audio input jack for microphone or guitar



Line-in Aux /Audio output





L

R



Mic/Guitar input



4. Function List

1.LIGHT ON/OFF

4.DISPLAY

7.POWER ON/OFF

10.LED MODE

13.PLAY/PAUSE

16.MODE

2.AUXIN

5.DC 7.4VIN

8.BLUETOOTH

11.TWS

14.REPEAT

3.USB/TF CARD


6.MIC IN

9.POWER

12.VOLUME (functions adjust)
Press"VOLUME Adjust
bass/treble/mic echo/mic
volume)

15.NEXT

Function of remote



1. **POWER:** Press POWER key to turn off system , press this key again to turn on

system.

2. **MODE(INPUT)**:press MODE key to select USB/FM/AUX audio signal input mode.
3. **1,2,3...0**:Press "1,2,3...9"to select Mp3 song directly; This system support intelligent select song,for example,you press number key 2+9 to select NO.29 song.
4. **MUTE**:press MUTE to turn ON/OFF mute mode.
5. **EQ**:Press "EQ"to select different sound effect for Mp3 song EQ function only use for USB mode.
6. **REP**: Press REP key to recycle playing present music and represent the button to play all the music programme.
7. **▶▶(CH+)**: Press ▶▶ to select next MP3 song (under USB playing mode).Or search FM afterward programme. 20channels FM program could be saved in this machine.
8. **◀◀(CH-)**: Press ◀◀ to select previous MP3 song(under USB playing mode).Or search FM forward programme. 20 channels FM programme could be saved in this machine.
9. **9/10 VOL+/VOL-**: Press VOL+/VOL- key to adjust master volume .
10. **▶||**: Play or Pause button under USB playing mode.
12. Automatic search of FM programme under FM playing mode. 20 searched programme will be stored and choose by CH-/CH+ button

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC warning:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of

the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.