

# PLAUD 认证说明书\_多语言



## 说明书

### 英文

#### **ChatGPT Empowered AI Voice Recorder**

PLAUD NOTE

AI Voice Recorder

User Guide

## Thank You Letter

Thank you for purchasing the PLAUD NOTE.

We are dedicated to making this product the best AI voice recorder for your daily and professional note space experience. Your satisfaction is our highest priority!

For the most straightforward instructions on using this product, we strongly recommend you visit our website at [www.plaud.ai](http://www.plaud.ai).

Cheers,

PLAUD Team 🙌

**PLAUD**

[www.plaud.ai](http://www.plaud.ai) | [hi@plaud.ai](mailto:hi@plaud.ai)

## Product Package

- PLAUD NOTE
- MagSafe Case
- MagSafe Ring
- Charging Cable
- Quick Guide
- User Guide

## Product Specification

- **Size:** 3.37\*2.13\*0.117 inch
- **Weight:** 30g
- **Charging Type:** Magnetic Charging Cable
- **Storage Capacity:** 64GB
- **Battery:** 3.8V/400mAh
- **Maximum Continuous Recording Time:** Up to 30 hours
- **Maximum Standby Time:** Up to 60 Days
- **File Format:** WAV

## Product Elements

- **One-Press Record Button:** The magic button for you to achieve the one-press recording.
  - Short Press:
    - Battery status
  - Long Press:
    - 1 Time Vibration: Start recording
    - 2 Times Vibration: Stop recording
- **Dual Engine Switch:** Toggle up the Switch to turn on Phone Call Recording Mode.
- **Indicator Light:** The light that indicates the battery of PLAUD NOTE, and recording status.
  - App Binding Status:
    - White Light ON & Flashing: Waiting to Bind PLAUD App
    - White Light ON: PLAUD App Bind Successfully

- Recording Status:
  - Red Light ON: Recording ON
  - Red Light OFF: Recording OFF
  - Red Light ON & Flashing: VAR Mode ON
- Battery Status:
  - White Light ON for 5 seconds: Battery > 10%
  - Purple Light ON & Flashing for 5 seconds: Battery < 10%
- Charging Status
  - Green Light ON: Battery = 100%
  - Purple Light ON: Battery Charging
- Storage
  - Yellow Light Flashing: Out of Storage

## PLAUD NOTE Set Up

To customize your recording preferences, we have developed the PLAUD App that can control the device in Bluetooth range, and you can access and manage the recorded files through the PLAUD App.

- Search for PLAUD in the App Store or Google Play

## Registration and Sign in

Please register and sign into the PLAUD App. Then bind the device through Bluetooth. Then you can customize the settings through the PLAUD App.

## Start Recording

To start recording on PLAUD NOTE, simply press and hold the button for 1 second and wait for the 1 quick vibration. You will also see the red light on for recording status.

## Stop Recording

During recording, press the button for 1 second again and wait for the 2 quick vibrations, and it will stop recording. The red light will be off.

## Check Battery Situation

The light indicates the battery situation:

- Green Light ON: Battery = 100% (While charging)
- White Light ON: Battery > 10%
- Purple Light ON: Battery < 10%

## Playback Recording

- Method 1: Playback recordings through the App. You can allow fast sync of the recordings by enabling a Wi-Fi connection on the App for long recordings; the speed of Wi-Fi transfer is 20 times faster than that of Bluetooth.
- Method 2: Connect to Mac or Windows computer via cable and wait for a few seconds before the U Disk is identified. The recordings are in the folders according to your scene setting of PLAUD NOTE.
- Method 3: Use a USB adapter to connect with phones via its OTG function.

## Out of Storage

When you see yellow light flashing, the PLAUD NOTE storage is full. Please either sync your file to the PLAUD app and delete your files in the recorder or connect your PLAUD NOTE to compute to delete your file in U Disk.

## Out of Battery

When your product is out of battery, please recharge it and connect it to your PLAUD app to sync the accurate time zone.

## Product Warranty

### **12 Months Worry-Free Warranty**

Customers of the PLAUD NOTE Voice Recorder enjoy 12 months of warranty service as of the date of purchase. Customers shall show valid invoices to enjoy the warranty service.

The warranty service applies if

- The Recorder is not dismantled, repaired, maintained, or modified without permission;
- The Recorder is not operated in an abnormal environment;
- The Recorder is not damaged due to a violation of the user's manual;
- The Recorder has not experienced a collision, falling, or bending due to improper storage or faults and significant deformations due to liquid leakage in humid places.

If you encounter problems using this device, please get in touch with us through our customer support email at [support@plaud.ai](mailto:support@plaud.ai) or directly reach out to us over the customer service menu in the PLAUD App. Please provide your order ID, SN Number, and the App version for a more effective reply.

## Privacy Policy

We care about your privacy. For more details, please visit [www.plaud.ai/privacy](http://www.plaud.ai/privacy) for more information.

## Privacy Protection

All data is only stored on the device or phone if you do not use our cloud services. Additionally, the recordings that you upload to the cloud are encrypted and safely protected.

## Product Disclaimer

- Legal Restrictions

Please strictly abide by the relevant laws and do not use this product illegally. The company does not make any commitments or take any responsibility for the consequences of illegal acts.

- Data Safety

The company is not responsible for the loss or damage of personal data caused by the mishandling of hardware, software, product maintenance, battery replacement, or other unexpected situations. It does not take liability for other indirect losses caused by this.

- Product Settings

The actual settings and usage of this product may be inconsistent with this manual due to the upgrade of the firmware program. Please understand that changes may occur due to the performance and function of this product without prior notice.

## Important Notice

- Safety

Keep the device and the accessories away from children, as they may lead to suffocation or other injuries.

Do not expose the batteries (battery pack or batteries installed) to fire or excessive heat, such as sunshine and the like, for a long time.

- Maintenance

Do not clean the Recorder with chemicals or reagents, as they will damage the surface of the Recorder and corrode it.

- Recording Backup

Back up your recordings regularly, and the manufacturer is not held accountable for any data loss.

- Battery

If the product is not used for a long time, please charge and discharge the product once every three months to prevent battery damage.

- Storage Capacity

The system software will occupy a small portion of the storage space. The actual usable capacity will be slightly smaller than the capacity indicated in the specifications.

## FCC Regulatory Conformance

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device under part 15 of the FCC Rules. These limits are designed to protect reasonably against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used under the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.

- Connect the equipment to an outlet on a circuit different from the receivers.
- Consult the dealer or an experienced radio/TV technician for help.

If you cannot eliminate the interference, the FCC requires that you stop using your product. Changes or Modifications not expressly by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such changes could void the user's authority to operate the equipment.

RF Exposure: The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

### **IC Statement: CAN ICES-3(B)/NMB-3(B)**

- This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### **FCC/IC Radiation Exposure Statement**

- This equipment complies with FCC/IC RSS-102 radiation exposure limits set forth for an uncontrolled environment.

### **EU Compliance**

Nicebuild LLC hereby declares that this wireless device is in compliance with Directive 2014/53/EU and Radio Equipment Regulations 2017.



### **WEEE Notice**



- **PLAUD Statement:**

*The symbol above indicates that this product and/or battery should not be disposed of with household waste. When you decide to dispose of this product and/or its battery, do so in accordance with local environmental laws and guidelines.*

- **Competitor Statement:**

*The Directive on Waste Electrical and Electronic Equipment (WEEE), which entered into force as European law on 14/02/2014, resulted in a major change in the treatment of electrical equipment at end-of-life.*

*The purpose of this Directive is, as a first priority, the prevention of WEEE, and in addition, to promote the reuse, recycling and other forms of recovery of such wastes so as to reduce disposal. The WEEE logo on the product or on its box indicating collection for electrical and electronic equipment consists of the crossed-out wheel bin, as shown below.*

*This product must not be disposed of or dumped with your other household waste. You are liable to dispose of all your electronic or electrical waste equipment by relocating over to the specified collection point for recycling of such hazardous waste. Isolated collection and proper recovery of your electronic and electrical waste equipment at the time of disposal will allow us to help conserving natural resources. Moreover, proper recycling of the electronic and electrical waste equipment will ensure safety of human health and environment. For more information about electronic and electrical waste equipment disposal, recovery, and collection points, please contact your local city center, household waste disposal service, shop from where you purchased the equipment, or manufacturer of the equipment.*



## **RoHS Compliance**

- This product is in compliance with Directive 2011/65/EU and 2015/863/EU of the European Parliament and of the Council of 8 June 2011 on the restriction of the use of certain hazardous substances in electrical and electronic equipment.

## **REACH**



- REACH (Regulation No 1907/2006) address the production and use of chemical substances and their potential impacts on human health and the environment. Article 33(1) of REACH Regulation requires suppliers to inform the recipients if an article contains more than 0.1% (per weight per article) of any substance(s) on the Substances of Very High Concern (SVHC) Candidate List ('REACH candidate list'). This product contains the substance ...

## For Products that Include Batteries

PLAUD Statement:

- **Battery Caution & Disposal Information**
  - Please take care of your battery. Do not; disassemble, burn, puncture, crush or bend your battery. Improper operation of the battery may produce smoke. In such an event, ventilate the area. Extinguish any flames with carbon dioxide, dry-powder fire extinguisher, or cover with sand or mud. Take care to avoid conditions of excessive moisture for prolonged periods and do not immerse. Do not expose to temperatures above 50°C/122°F. Charge the battery fully before storage or if stored for longer than three months. The operating temperature of this product is 0°C (32°F) to 35°C(95°F). Ambient temperature should not exceed 45 C (113 F).

## Disposal

- At the end of its life, please take care to dispose of this product responsibly. Electronic products and batteries contain materials that can be harmful to the environment. Please do not dispose to unsorted waste. Take your electronic waste to a designated collection or recycling facility to be recycled properly. Your local council authority will be able to tell you where your nearest facilities are. There may be one at your local supermarket.

Competitor Statement:

- **EU Batteries Directive 2013/56/EU**
  - A new battery directive 2013/56/EU on Battery and Accumulator replacement directive entered into force on 01/07/2015. The directive applies to all types of batteries and accumulators (AA, AAA, button cells, lead acid, rechargeable packs) including those incorporated into appliances except for military, medical, and power tool applications. The directive sets out rules for the collection, treatment, recycling, and disposal of batteries, and aims to prohibit certain hazardous substances and to improve the environmental performance of batteries and all operators in the supply chain.
- **Instructions for Users on Removal, Recycling, and Disposal of Used Batteries**

- To remove the batteries from your equipment or remote control, reverse the procedure described in the owner's manual for inserting batteries. For products with a built-in battery that lasts for the lifetime of the product, removal may not be possible for the user. In this case, recycling or recovery centers handle the dismantling of the product and the removal of the battery. If, for any reason, it becomes necessary to replace such a battery, this procedure must be performed by authorized service centers. In the European Union and other locations, it is illegal to dispose of any battery with household trash. All batteries must be disposed of in an environmentally sound manner. Contact your local waste-management officials for information regarding the environmentally sound collection, recycling, and disposal of used batteries.



**WARNING:** Danger of explosion if the battery is incorrectly replaced. To reduce the risk of fire or burns, don't disassemble, crush, puncture, short external contacts, expose to temperatures above 60°C (140°F), or dispose of in fire or water. Replace only with specified batteries. The symbol indicating 'separate collection' for all batteries and accumulators shall be the crossed-out wheeled bin shown below:

### **Simplified EU Declaration of Conformity (For all products with Wireless Operation)**

- Hereby, Nicebuild LLC, PLAUD declares that the radio equipment type [designation of the type of radio equipment] is in compliance with Directive 2014/53/EU.

### **Simplified EU Declaration of Conformity (For all products except those with Wireless operation)**

- Hereby, Nicebuild LLC, PLAUD declares that this equipment is in compliance with the LVD 2014/35/EU Directive.

2023 Nicebuild LLC. All rights reserved.

繁体中文

ChatGPT 強化 AI 聲音錄音器

## PLAUD NOTE

### AI 聲音錄音器

### 使用指南

### 感謝信

感謝您購買 PLAUD NOTE。

我們致力於使這款產品成為您日常和專業筆記空間體驗的最佳 AI 聲音錄音器。您的滿意是我們的最高優先事項！

有關使用該產品的最直接指南，我們強烈建議您訪問我們的網站 [www.plaud.ai](http://www.plaud.ai)。

祝您使用愉快，

PLAUD 團隊 🙌

# PLAUD

[www.plaud.ai](http://www.plaud.ai) | [hi@plaud.ai](mailto:hi@plaud.ai)

## 產品包裝

- PLAUD NOTE
- MagSafe 套
- MagSafe 環
- 充電線
- 快速指南
- 使用指南

## 產品規格

- 尺寸：3.37\*2.13\*0.117 英寸
- 重量：30 克
- 充電類型：磁性充電線

- 儲存容量：64GB
- 電池：3.8V/400mAh
- 最大連續錄音時間：長達 30 小時
- 最大待機時間：長達 60 天
- 文件格式：WAV

## 產品元件

- 單按錄音按鈕：讓您實現一鍵錄音的神奇按鈕。
  - 短按：電池狀態
  - 長按：
    - 1次振動：開始錄音
    - 2次振動：停止錄音
- 雙引擎開關：向上切換開關以啟動通話錄音模式。
- 狀態燈：指示 PLAUD NOTE 的電池和錄音狀態。
  - 應用程式綁定狀態：
    - 白燈開啟並閃爍：等待綁定 PLAUD App
    - 白燈開啟：PLAUD App 綁定成功
  - 錄音狀態：
    - 紅燈開啟：錄音中
    - 紅燈關閉：錄音停止
    - 紅燈開啟並閃爍：VAR 模式開啟
  - 電池狀態：
    - 白燈 5 秒開啟：電池 > 10%
    - 紫燈開啟並閃爍 5 秒：電池 < 10%
  - 充電狀態：
    - 綠燈開啟：電池 = 100%
    - 紫燈開啟：正在充電
  - 儲存空間：
    - 黃燈閃爍：儲存空間不足

## PLAUD NOTE 設定

為了自定義您的錄音偏好，我們開發了 PLAUD App，可在藍牙範圍內控制設備，您可以通過 PLAUD App 訪問和管理錄音文件。

- 在Apple應用商店或 Google Play中搜索 PLAUD

## 註冊和登錄

請註冊並登錄 PLAUD App。然後通過藍牙綁定設備。然後，您可以通過 PLAUD App 自定義設置。

## 開始錄音

要在 PLAUD NOTE 上開始錄音，只需按住按鈕 1 秒鐘，等待 1 次快速振動。您還會看到紅燈亮起表示錄音狀態。

## 停止錄音

在錄音過程中，再次按住按鈕 1 秒鐘，等待 2 次快速振動，錄音將停止，紅燈將關閉。

## 檢查電池狀況

燈號指示電池狀況：

- 綠燈開啟：電池 = 100%（充電中）
- 白燈開啟：電池 > 10%
- 紫燈開啟：電池 < 10%

## 回放錄音

- 方法 1：通過 App 回放錄音。您可以啟用 App 上的 Wi-Fi 連接，以便對長時間錄音進行快速同步；Wi-Fi 傳輸的速度比藍牙快 20 倍。
- 方法 2：通過傳輸線連接到 Mac 或 Windows 電腦，等待幾秒鐘，直到識別出 U 盤。錄音文件將根據您 PLAUD NOTE 的場景設置存儲在對應文件夾中。
- 方法 3：使用 USB 轉接器通過其 OTG 功能與手機連接。

## 高級功能

## 語音激活錄音 (VAR)

當連接到設備時，您可以通過 PLAUD App 啟用 VAR 功能。PLAUD NOTE 將進入連續檢測模式，當偵測到聲音時，它會自動錄音。

- 在此模式下，狀態燈將閃爍紅燈。

建議在重要錄音時關閉此功能。當聲音分貝較低時，設備可能不會啟動錄音，從而造成信息的丟失。

## 儲存空間不足

當您看到黃燈閃爍時，PLAUD NOTE 儲存空間已滿。請將文件同步到 PLAUD App 並在錄音機中刪除文件，或連接 PLAUD NOTE 到電腦並在 U 盤中刪除文件。

## 電池耗盡

當您的產品電池耗盡時，請充電並連接到 PLAUD App 以同步準確的時區。

## 產品保修

### 12 個月無憂保修

PLAUD NOTE 聲音錄音器的客戶享有自購買之日起 12 個月的保修服務。客戶應出示有效的發票以享受保修服務。

以下情況不享有產品保修：

- 未經許可拆解、修理、保養或修改錄音器；
- 在異常環境下操作錄音器；
- 因違反用戶手冊而損壞錄音器；
- 因不正常存放或在潮濕地方液體泄漏導致碰撞、摔落或彎曲而損壞錄音器。

若您在使用此設備時遇到問題，請通過我們的客戶支援電子郵件 [support@plaud.ai](mailto:support@plaud.ai) 與我們聯繫，或直接在 PLAUD App 中的客戶服務選單中與我們聯繫。請提供您的訂單編號、SN 編號和 App 版本，以便更有效地回復。

## 隱私政策

我們關心您的隱私。欲了解更多詳情，請訪問[www.plaud.ai/privacy](http://www.plaud.ai/privacy)以獲取更多信息。

## 隱私保護

所有數據僅在您不使用我們的雲服務的情況下存儲在設備或手機上。此外，您上傳到雲端的錄音已被加密並安全保護。

## 產品免責聲明

- 法律限制

請嚴格遵守相關法律，不要非法使用該產品。公司不對非法行為的後果做任何承諾或負任何責任。

- 數據安全

公司對因硬件、軟件、產品維護、電池更換或其他意外情況不當操作造成的個人數據損失或損壞不負責任。不對由此引起的其他間接損失承擔責任。

- 產品設置

由於固件程序的升級，實際設置和使用可能與本手冊不一致。請理解，由於該產品的性能和功能，變更可能會在事先通知的情況下發生。

## 重要注意事項

- 安全

請將設備和配件遠離兒童，以免造成窒息或其他傷害。

不要將電池（電池包或安裝的電池）長時間暴露在火源或過熱的環境中，例如陽光等。

- 維護

不要使用化學品或試劑清潔錄音機，因為它們會損壞錄音機表面並腐蝕它。

- 錄音備份

定期備份您的錄音，製造商不對任何數據損失負責。

- 電池

如果該產品長時間不使用，請每三個月充電並放電一次，以防止電池損壞。

- 儲存容量

系統軟件將佔用一小部分存儲空間。實際可用容量將稍小於規格中所示的容量。

## FCC 法規符合性

該設備符合FCC法規第15部分。操作受以下兩個條件限制：

1. 該設備不得造成有害干擾。
2. 該設備必須接受任何收到的干擾，包括可能引起不希望的操作的干擾。

注意：該設備已通過測試，符合FCC法規第15部分中B類數字設備的限制。這些限制旨在合理保護居民安裝中免受有害干擾的影響。該設備可以生成並發射無線頻率能量，如果未按照指示安裝和使用，可能對無線通信產生有害干擾。然而，無法保證在特定安裝中不會發生干擾。如果該設備確實對無線電或電視接收產生了有害干擾，可以通過打開和關閉設備，嘗試通過以下一種或多種措施來消除干擾：

- 重新調整或移動接收天線。
- 增加設備與接收器之間的距離。
- 將設備連接到與接收器不同的電路插座上。
- 諮詢經銷商或經驗豐富的無線電/電視技術人員尋求幫助。

如果無法消除干擾，FCC要求您停止使用產品。未經負責符合性的一方明確批准的更改或修改可能會使用戶的操作許可權無效。

注意：製造商不對由未經授權對該設備進行的任何無線電或電視干擾負責。此類變更可能會使用戶的操作權無效。

RF暴露：該設備已經經過評估，符合一般RF暴露要求。在便攜暴露條件下可以使用該設備，無限制。

## IC聲明：CAN ICES-3(B)/NMB-3(B)

- 該設備符合加拿大工業部豁免許可RSS標準。操作受以下兩個條件限制：（1）該設備不得造成有害干擾，（2）該設備必須接受任何收到的干擾，包括可能引起不希望的操作的干擾。

## FCC/IC輻射暴露聲明

- 該設備符合FCC/IC RSS-102輻射暴露限值，適用於無受控環境。

## 歐盟合規性

Nicebuild LLC特此聲明，該無線設備符合2014/53/EU指令和2017年無線電設備法規。



## WEEE注意事項





- **PLAUD聲明：**

上方的符號表示該產品和/或電池不應與家庭垃圾一起處置。當您決定處理該產品和/或其電池時，請遵循當地環境法規和指南。

- **競爭對手聲明：**

電子和電氣設備廢棄物指令（WEEE）于2014年2月14日成為歐洲法律，從根本上改變了生命終結時電氣設備的處理方式。該指令的首要目標是防止WEEE的產生，此外，還促進對這些廢物的重複使用、回收和其他形式的回收，以減少處置。產品或其盒子上的WEEE標誌指示了收集電子和電氣設備的過程，如下所示：劃掉的垃圾箱。該產品不得與其他家庭垃圾一起丟棄或倒掉。您有義務將所有電子或電氣廢棄設備運送到指定的收集或回收設施進行適當的回收。您當地的市政當局將能夠告訴您最近的設施在哪裡。您當地的超市可能會有一個收集點。



## RoHS合規性

- 本產品符合2011/65/EU指令和2015/863/EU指令，該指令是2011年6月8日歐洲議會和理事會關於限制電氣和電子設備中某些有害物質使用的指令。

## REACH

- REACH（法規號1907/2006）涉及化學物質的生產和使用，以及其對人類健康和環境的潛在影響。REACH法規第33(1)條要求供應商通知接收方，如果一個產品含有超過0.1%（重量百分比每個產品）的任何“非常高關注物質候選名單”上的物質。本產品包含的物質...

## 對於包含電池的產品

### PLAUD聲明：

- **電池注意事項和處置信息**

請注意您的電池。不要拆卸、燃燒、刺穿、壓碎或彎曲電池。電池的不當操作可能產生煙霧。在這種情況下，通風。用二氧化碳、干粉滅火器或用沙子或泥土覆蓋來撲滅任何火焰。要小心避免長時間過度潮濕的條件，不要浸泡。不要暴露於50°C/122°F以上的溫度。在儲存或存儲超過三個月的時間內，將電池充電充分。該產品的操作溫度為0°C（32°F）至35°C（95°F）。環境溫度不應超過45°C（113°F）。

## 處置

- 在其壽命結束時，請注意負責負責地處理該產品。電子產品和電池含有對環境有害的材料。請不要處理未分類的廢棄物。將您的電子廢棄物運送到指定的收集或回收設施進行適當回收。您當地的市政機構將能夠告訴您最近的設施在哪裡。您當地的超市可能會有一個。

## 競爭對手聲明：

- 歐盟電池指令2013/56/EU

2013/56/EU關於電池和蓄電池替代指令的新電池指令於2015年7月1日生效。該指令適用於所有類型的電池和蓄電池（AA、AAA、按鈕電池、鉛酸、可充電包），包括那些內置於裝置中的電池，除了軍事、醫療和電動工具應用。該指令規定了電池的收集、處理、回收和處置規則，旨在禁止某些有害物質，並改善電池和供應鏈中的所有操作者的環境性能。

- 有關用戶有關已用電池的去除、回收和處置的說明

要從您的設備或遙控器中取出電池，請反轉擁有者手冊中插入電池的過程的描述。對於內置電池的產品，其電池壽命可能持續到產品的壽命，對於用戶來說，可能無法進行去除。在這種情況下，拆解產品和去除電池的工作將由授權的服務中心進行。在歐洲聯盟和其他地方，將任何電池與家庭垃圾一起丟棄是非法的。所有電池必須以環保的方式進行處理。聯繫當地的廢物管理官員，以獲取有關環保的收集、回收和處理已用電池的信息。



警告：如果電池更換不正確，可能會發生爆炸危險。為了減少火災或燒傷的風險，請勿拆卸、壓碎、刺穿、短接外部接觸點，不要將電池暴露在60°C（140°F）以上的溫度，也不要將其丟入火中或水中。僅使用指定的電池進行更換。所有電池和蓄電池的“分離收集”標誌如下所示：

## 簡化的歐盟合規性聲明（適用於所有具有無線操作的產品）

- 特此，Nicebuild LLC，PLAUD聲明，無線電設備類型[無線電設備類型的指定]符合2014/53/EU指令。

## 簡化的歐盟合規性聲明（適用於所有非無線操作的產品）

- 特此，Nicebuild LLC，PLAUD聲明，該設備符合2014/35/EU指令。

2023年Nicebuild LLC。保留所有權利。