NO 22040165

FUNCTION INSTRUCTION OF EMITTER

- 1 Fan OFF
- ② Natural wind
- (3) Fan Speed
- (4) Forward/Reverse
- (5) Timer
- (6) Light ON/OFF
- 7 Change Colour
- 8 Reduce Brightness
- Increase Brightness
- 1.5V AAA battery X 2pcs (not included)



KINDLY REMINDERS:

- 1. If the emiter can not control the fan, learning code matching mode is used between emiter and receiver. Turn "ON" the supply power within 5 seconds and press the emitter's " (" buton for 5 seconds, it can load normally after hearing a long sound "bee", which means learning successfully and it can works normally. (PS: Learning mode is not accepted after turn "ON" the supply power for 5 seconds).
- 2. When the emiter cannot control the receiver, please check the battery switch touching normally or not, correction of the positive and negative, full or empty of the power.
- 3. When the emitter cannot control the receiver, please check is there any existence of similar remote controlled products nearby, then check whether they works, because remote controlled product with the same frequency will-disturb each other.
- 4.Please take out the battery from the emitter when leaving unused for long time.
- 5. When installing the fan,the fan ceiling cover don't press the antenna(or other wire),it is easy to breakdown the wire and short-circuited.



Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions
- (1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.