Wireless Keyboard

User Guide

PACKAGE CONTENTS

1. Wireless Keyboard

2.Micro-USB charging cable

3.User Guide

SPECIFICATIONS

Bluetooth Specification	Broadcom 3.0		
Dimensions	247x150x6.5mm		
Operating Range	Up to 10 meters		
Stand-by time	90 days		
Charge time	< 2 hours		
Uninterrupted Work Time	90 hours		
Lithium Battery Capacity	180 mAh		
Key Life	3 million clicks		
Stand-by time	90 days		

LED DISPLAY

ELD DISTERN					
CAPS	The Caps Lock indicator may not light, but will still function normally.				
*	Will flash blue(3min.long) after pressing the "Connect" button until a BT connection is established. It disappears when connected.				
Charge	Lights red when the keyboard is charging. Turns off when the battery is fully charged. Flashes red, when the battery is weak and should be charged.				
Power	Lights up blue for about 4 sec when being turned on.				

KEYS AND FUNCTIONS

Press Fn key and hot key together to activate action.

	Home	.o.	Brightness down	Ò.	Brightness up
Q	Search for	U	Back	44	Previous track
►II	Play /pause	>>	Next track	4)	Volume down
◄)))	Volume up		Lock screen	10	Screenshot
Ø	Web Browser	\bowtie	Email		

PAIRING STEP

Step 1. Turn on the keyboard's power button.

The blue status light will be on for 4 seconds and then be off.

- Step 2. Press the connect button, the Bluetooth indicator will be blinking blue.
- Step 3. Go to your tablet's "Settings" "Bluetooth", flip the switch to the "on" position.

It will automatically search available Bluetooth devices in the vicinity.

Step 4. When you find the device "Bluetooth 3.0 Keyboard", click Pair.

SPECIAL NOTE

- 1. Only one device can be actively paired at one time.
- 2. For other Bluetooth enabled device, please verify the bluetooth Standard&compatibility before attempting to connectto the keyboard.
- 2. After pairing for the first time, your device will connect to the keyboard automatically when opening the keyboard.
- In case of connect failure, delete the pairing record from your device, and try the above procedures again.

POWER SAVING MODE

The keyboard will enter sleep mode after being idle for 30 minutes.

To activate it, press any key and wait for 3 seconds.

HOW TO CHARGE IT

- 1. Use the included USB cable for charging. Connect one end to a USB charger, and the other to the keyboard.
- 2. In charging, the power indicator will turn red. Generally, it takes approximately

2 hours for a full charge.(Charging adapter is not included)

TROUBLESHOOTING

If you are unable to connect the keyboard to your tablet, please try the following:

- 1. Starting with a full charge on both devices ensures that process won't be interrupted by a low battery.
- 2. Check your tablet's Bluetooth is on.
- 3. Make sure that the keyboard is within the effective operation distance of 33 feet (10 M).

SAFETY INSTRUCTIONS

- 1. Keep the keyboard away from sharp objects that could damage it.
- 2. Do not put heavy objects on the keyboard.
- 3. Do not stretch, twist or apply force to the keyboard.
- 4. To clean the keyboard, gently wipe it by using a moist cotton cloth.
- 5. Please do not spill coffee, tea or other liquids on the keyboard.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.