


MW35:说明书尺寸：90×60mm

材质：80g书纸

工艺：对折

封面内页

封底内页




EN Notes : Please note that electronic devices are not waterproof and need to be removed from the butt masturbator before cleaning.

Data:
 Product name: Renee
 Length: 255mm
 Width: 168mm
 Height: 252mm
 Weight: 5.2kg
 Materials: Silicone, ABS, PC

Selling points:
Suction and Vibration Masturbator
 • APP control, supporting Bluetooth
 • Enjoy joy with your partner whenever and wherever you want
 • Suction + Vibration – Dual Joy, to give you an unprecedented new experience
 • Exclusive suction and vibration technology bring surreal joyful experience
 • Subtle internal texture imitates energetic stimulation
 • Suitable for any size
 • Removable and easy to clean

Buttons Display:



1. S button
 2. DC charging port/Earphone jack

On/Off:
 Press the "○" button for 1.5s to turn the device power On/Off, the device will enter the default Mode 1.

Mode Switching (5):
 Press the S button to switch between 5 modes.

Mode 1 Suction&Vibration 1
 Mode 2 Suction&Vibration 2
 Mode 3 Suction&Vibration 3
 Mode 4 Suction only
 Mode 5 Vibration only

Status Display:

Activating status	Lasting light
Low battery	Light flashes
While charging	Light flashes
Fully charged	Permanent light

Tips Before Use:
 Before using a new ZEMALIA device, please fully charge the device, then clean the butt masturbator with clean water before using it on your body.
 To better your user experience, apply the water based lubricant inside the toy tunnel to smooth your joy adventure. (Attention: silicone lubricant is forbidden, it might damage the toy by its chemical traits.)

Accessories Introduction:
 Vacuum Cleaning Tool (Enema&Vagina Cleaner)
 Drying Stick
 Vibration&Suction Controller
 Butt Masturbator

Precautions:
 This product is only for adults, please store it away in a place out of the reach of children.
 Remember to keep the toy in a dry place avoiding sunlight.


Toy Cleaning Tips:
 Fill the enema bag with clean water and non-silicone disinfects. Hang it on a towel rack, shelf, or cabinet above you.
 Take out the Vibration & Suction Controller from the butt masturbator. (ATTENTION: the Vibration & Suction Controller contains electric parts, the water may cause short-circuits and damage to it, so make sure it's out before applying the cleaning operations.)
 Gently insert the vacuum cleaning tool tube up to 2-3 inches into the butt masturbator cap.
 Once the tube is secure, gently squeeze the contents of the enema bag or allow it to flow into the butt masturbator with gravity's help.
 When the vacuum bag is empty, slowly remove the tube and then wash and rinse the vacuum tool in clean water then pump fresh water into the tool bag to empty the pre-occupied residuals in the tool bag.

Drying Tips:
 After cleaning the toy and shaking out most of the water, insert the drying stick into the toy. Massage the toy around the stick very gently to make sure that the stick can get into all the crevices. After 15 - 30 seconds gently remove the stick from the toy.
 When fully dry, if not use in a long time, sprinkle cornstarch to keep masturbator toy from becoming sticky.

After-sales service:
 This is belong personal items, once the product is opened, it cannot be returned. If your toy has manufacturer defects or product quality problems after receiving the goods, please contact: customer-service@zemalia.com
 We will try our best to solve your problems.

APP Connection:
 Keep your phone's Bluetooth on, and turn on the device, open the app and connect the device to the app.

How to download?



Download SVAKOM APP on <https://www.svakom.net/download.html>


APP is available on:

Available on
Google Play

Available on
App Store

How to connect?

1. Keep your Bluetooth on and open the app, you will see this picture.
2. Long press the S button on the product to turn it on.
3. Click CONNECT on SVAKOM app.
4. Wait for it to connect, the app will go to the home page automatically.
5. Click"PLAY",you will see there are have two options : Set modes&Remote modes.
 Set modes : you can switch 5 different suction/vibration modes.
 Remote modes: you can create a room,then share to your partner.



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction