

FCC ID:2A77Z-ADVANCE1500





⚠ WARNINGS!

- ⊗ Do not short-circuit POWER STATION. To avoid short-circuiting, keep POWER STATION away from all metal objects (eg. coins, hair-pins, keys, etc.)
- ⊗ Do not heat POWER STATION, or dispose of it in fire, water or other liquids. Keep away from high temperatures. Do not expose POWER STATION to direct sunlight.
- ⊗ Keep away from high humidity, dusty places.
- ⊗ Do not disassemble or reassemble POWER STATION.
- ⊗ Do not drop, place heavy objects on, or allow strong impact to POWER STATION.
- ⊗ POWER STATION is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of POWER STATION by a person responsible for their safety.
- ⊗ Children should be supervised to ensure that they do not play with POWER STATION.
- ⊗ Do not cover POWER STATION with towels, clothing and other items.
- ⊗ POWER STATION may become hot when charging. This is normal. Use caution when handling.
- ⊗ Use POWER STATION properly to avoid electronic shock.
- ⊗ POWER STATION is only used for emergency power station. It can not replace the standard DC or AC power of household appliances or digital products.

