



Band5-5MHz-QPSK-20625-25RB#0









Band5-5MHz-16QAM-20525-25RB#0









Band5-10MHz-QPSK-20450-50RB#0







## Band5-10MHz-QPSK-20525-50RB#0



Band5-10MHz-QPSK-20600-50RB#0








Band5-10MHz-16QAM-20525-50RB#0

LTE Signaling

ON





0

Connection Established

Show Remote Screen

PS:

Go To Local