



Band41-10MHz-16QAM-39700-50RB#0




Band41-10MHz-16QAM-40620-50RB#0






Band41-10MHz-16QAM-41540-50RB#0



Band41-15MHz-QPSK-39725-75RB#0

ON





Band41-15MHz-QPSK-41515-75RB#0

PS:


Go To Local

Connection Established


Show Remote Screen

Connected






Band41-15MHz-16QAM-39725-75RB#0




Band41-15MHz-16QAM-40620-75RB#0







Band41-15MHz-16QAM-41515-75RB#0



Band41-20MHz-QPSK-39750-100RB#0









Band41-20MHz-QPSK-41490-100RB#0





Band41-20MHz-16QAM-39750-100RB#0



Band41-20MHz-16QAM-40620-100RB#0



