

User Manual

Thank you for purchasing the U20 Wireless Sport Headphones. Please review this manual thoroughly before operating your device. In order to avoid unnecessary injuries, please do not disassemble this product by yourself. For your better consumer experience, We provide you with warranty. Please scan the following OR code:




Package Content



Headphones

 \ominus

Line Buckle















Product Overview

- 1 + Button
- ② Button ③ Multi-function Button (R)
- ④ Microphone
- ⑤ Charging Indicator
- ⑥ Type-C Charging Port



PAIRING

It is recommended that you make sure the product is fully charged before using it.

- 1. Hold the Multi-function button for 3s to turn on.
- 2. Once paired automatically, the LED indicator of the headphones will flash red and blue alternately; A voice prompt will say "Pairing". 3. Select "U20" on your phone to connect from the Bluetooth
- list, Once connected, the indicators will be off. A voice prompt will say "your headset is connected". Note: Headphones will turn off automatically after 5

minutes if they have not been paired with any device.

1. Search & click "U20" to connect with the first device.

3. Search & click "U20" to connect with the second device.

DUAL CONNECTIONS

the music on device B.

Allows to connect with 2 devices.

2. Disconnect "U20" from the first device.

"U20" will re-enter pairing mode.





RESET



1. Delete "U20" in the Bluetooth list and turn off the Bluetooth function of your phone.






- Take out the headphone (right side in right hand, left side in left hand).
- 2. Put the headphone cable around your head on your neck, and hang the headphone from top to 3. Choose the right earmuffs and adjust the angle of the headphones for a better comfort and
- sound quality experience
 4. The line buckle can shorten the the line, and the clip can help to clamp the lin on your clothes.
- 5. When wearing headphones on one side, please wear the right ear first, because the call
- microphone hole is on the right. 6. Dust, earwax or other debris will accumulate in the earplugs. In order to maintain the best sound quality, please gently clean the earplugs with a cotton swab regularly.

- CHARGING
- 1. Fully dry off the USB-C charging port before charging. Connect the charging case to a power supply by using 2. the provided USB-C charging cable.





LED INDICATORS

Power on	Blue light flashes 2 times
Power off	Red light flashes 3 times
Pairing	Blue and red flash alternately
Connected	The indicator turnes off
Low battery	The red light flashes every 5S when in low power
Charging	The red light stays on
Fully charged	The blue light stays on

Specifications

Model	U20
Wireless Version	5.3
Profile	HFP/HSP/AVRCP/A2DP
Range	Up to 10 meters / 33 feet
Frequency Range	20-20KHz
Playtime	Up to 16 Hours of Playtime (Varied by volume level & audio content)
Battery capacity	100 mAh
Charging time	2 Hours

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

•Reorient or relocate the receiving antenna.

•Increase the separation between the equipment and receiver.

•Connect the equipment into an outlet on a circuit different from that to which the receiver is

 $\hbox{\bf •} Consult the dealer or an experienced radio/TV technician for help. \\$

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

4. Switch between device A & B, click to pause the music playing on device A and click to play

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

> MODEL: U20 FCC ID: 2A7GB-U20 MADE IN CHINA



CHARGING

- 1. Fully dry off the USB-C charging port before charging.
- Connect the charging case to a power supply by using the provided USB-C charging cable.



CONTROL

	ON/0FF
Power on	Press Multi-function Button for 3 seconds
Power off	Press Multi-function Button for 5 seconds
	50
Volume -	Click -
Volume +	Click+
Play/Pause	Click Multi-function Button
Previous/Next	Press + /- for 1 seconds
Answer/End a phone call	Click Multi-function Button
Reject a phone call	Press for 1 seconds
	P
Activate Voice Assistant	Double-click Multi-function Button

LED INDICATORS

Power on	Blue light flashes 2 times	
Power off	Red light flashes 3 times	
Pairing	Blue and red flash alternately	
Connected	The indicator turnes off	
Low battery	The red light flashes every 5S when in low power	
Charging	The red light stays on	
Fully charged	The blue light stays on	

Specifications

Model	U20
Bluetooth Version	5.3
Bluetooth Profile	HFP/HSP/AVRCP/A2DP
Bluetooth Range	Up to 10 meters / 33 feet
Frequency Range	20-20KHz
Playtime	Up to 16 Hours of Playtime (Varied by volume level & audio content)
Battery capacity	100 mAh
Charging time	2 Hours

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

•Reorient or relocate the receiving antenna.

•Increase the separation between the equipment and receiver.

•Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

 $\hbox{\bf \bullet Consult the dealer or an experienced radio/TV technician for help.} \\$

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

认证Certificate

