

WIRELESS STEREO EARPHONE

真无线蓝牙耳机

TWS Bluetooth headset

Model: A2pro



使用本产品前请仔细阅读说明书，妥善保存以备参考

Please read the manual carefully before using this product, and keep it for reference

产品介绍

Product description



多功能触摸区

Multifunctional touch area

主控

Master voice control

MIC

耳机参数

Headphone parameters

蓝牙版本: 5.3

Bluetooth version: 5.3

电池容量: 30mAh/3.7v

Battery capacity: 30mAh/3.7v

有效距离: 10米

Effective distance: 10 meters

播放时间: 2-3小时

Play time: 8 hours

通话时间: 2小时

Talk time: about 5 hours

充电时间: 约1.5小时

Charging time: about 1.5 hours

输入参数: 5V/100mA

Input parameters: 5V/100mA

充电仓参数

Charging bin parameters

电池容量: 250mAh/3.7v

Battery capacity: 250mAh/3.7v

充电盒输入: 5V/1A

Charging box parameters: 5V/1A

充电时间: 约1.5小时

Charging time: about 1.5 hours

充电盒给耳机充电次数: 约3次

The number of times the headset is charged by the charging box: about 3 times

包装清单

Packing list

1. 充电盒\*1

1. Charging box\*1

4. 精美礼品盒

4. Exquisite gift box

2. 左右耳机\*1

2. Left and right earphones\*1

5. Type-C充电线\*1

5. Type-C charging cable\*1

3. 说明书

3. Instructions

佩戴方式

Wearing method

打开充电仓盖，取出右耳机，将耳机喇叭端轻轻放入右耳耳道，再轻轻摆动耳机不晃动为宜。用同样方法佩戴左耳耳机。

Open the charging compartment cover, take out the right ear headphone, gently put the headphone speaker end into the right ear canal, and then gently swing the headphone without shaking. Wear the left ear headset in the same way.

操作方式

Operation method

开机:

两只耳机从充电仓取出开机

关机:

1. 将耳机放回充电仓并关上盖子, 耳机关机充电

2. 耳机在开机状态下, 触摸耳机触控板5秒关机。

Power on:

Take out the two earphones from the charging compartment and turn them on

Power off:

1. Put the earphones back into the charging compartment and close the lid, the earphones are turned off and charged

2. When the headset is turned on, touch the headset touchpad for 5 seconds to shut down.

注意事项

Precautions

1. 请使用正规来源有安全认证的充电器进行充电

2. 使用耳机时适量的调节音量大小以免损伤听觉

3. 正确使用产品避免高空掉落或重度挤压

4. 儿童请在成人陪同下使用避免误食

5. 远离高温或潮湿等极端环境

6. 请勿拆卸本产品。

1. Please use a charger with safety certification from a regular source for charging

2. Adjust the volume appropriately when using headphones to avoid hearing damage

3. Use the product correctly to avoid falling or heavy squeezing

4. Children please use with an adult to avoid accidental ingestion

5. Keep away from extreme environments such as high temperature or humidity

6. Do not disassemble this product.

双耳配对连接

Binaural pairing connection

1. 打开充电仓，取出左右耳机后等待5秒配对成功。

2. 打开设备蓝牙列表点击扫描，搜索“TWS”，点击即可连接

如果连接失败，将耳机放回充电仓并置上盖子，然后重复上面操作步骤。

双耳同时离开与设备正常连接距离后，耳机进入回连状态，3分钟内未连成功，双耳将自动关机。

1. Open the charging compartment, take out the left and right earphones and wait for 5 seconds for successful pairing.

2. Open the device Bluetooth list, click scan, search for "TWS", click to connect

If the connection fails, put the headset back into the charging compartment and close the lid, and then repeat the above steps. After both ears leave the normal connection distance with the device at the same time, the headset enters the reconnecting state. If the connection is not successful within 3 minutes, both ears will automatically shut down.

保修卡

Warranty Card

本保修卡是申请保修的凭证，请配合销售商填写并妥善保管备用！

This warranty card is a certificate for applying for a warranty, please fill it out in cooperation with the seller and keep it properly for future use!

用户姓名	用户姓名	用户姓名
用户信息	通信地址	通信地址
用户信息	联系电话	联系电话
产品信息	产品名称	产品名称
产品信息	产品型号	产品型号
产品信息	条码/编号	条码/编号
备注	备注	备注

注：此表应由销售商盖章确认；维修记录以授权服务机构维修凭证为准，申请售后服务，请妥善保管

Note: This form should be stamped and confirmed by the seller; the repair record is subject to the repair certificate of the authorized service organization. After applying for the service, please keep it properly

充电盒工作灯

Charging box work light



耳机充电: 耳机放入充电盒, 关闭充电盖, 充电指示灯亮蓝灯, 充满后蓝灯熄灭

充电盒低电: 灯光闪烁

充电盒充电: 灯光闪烁, 充满灯灭

Working light: open the cover of the charging box, the working light turns green, close the charging box, the working light goes out

Earphone charging: put the earphone into the charging box, close the charging cover, the charging indicator will turn on blue, and the blue light will go out after full

Charging box low battery: light flashes

Charging box charging: the light flashes, the light is off when it is full

双耳触控操作

Binaural touch operation



播放/暂停音乐

音乐状态下, 按压L/R耳机1下

Play/pause music

In the music state, Squeeze the L/R earphone 1 time

播放上一曲

音乐状态下, 按压L耳机2下

Play the previous song

In the music state, Squeeze the L earphone 2 times

播放下一曲

音乐状态下, 按压R耳机2下

Play the next song

In the music state, Squeeze the R headset 2 times

接听/挂断电话

来电时/通话中, 按压L/R耳机1下

Answer/hang up a call

When an incoming call/in a call, Squeeze the L/R headset 1 time

拒接电话

来电时, 长按2秒L或R耳机

Refused to answer the call

When a call comes in, Long press 2 seconds L or R headphones

语音助手

连接状态下, 长按2秒L或R耳机

voice assistant

When connected, Long press 2 seconds L or R headphones

F&Q

1. 问: 手机无法连接耳机?

答: 将手机上配对的TWS删除, 再进行配对连接即可。

2. 问: 怎么听歌/通话没有声音?

答: 安卓手机在手机连接记录的右边有一个设置图标, 点击进入, 将两个音频选项取消勾选再重新选择, 苹果手机在设置通用辅助功能进入音频通话方式, 选择自动, 如果本来就是自动, 就更为其他选项, 然后在更改为自动, 如未恢复, 删除配对记录重新连接尝试。

1. Q: Can't connect the headset to the mobile phone?

Answer: Delete the paired TWS on the phone, and then perform pairing connection.

2. Q: Why is there no sound when listening to songs/calls?

Answer: Android phones have a setting icon on the right side of the phone connection record. Click to enter, uncheck the two audio options and select again. When setting the general auxiliary function of the Apple phone, enter the audio call mode and select automatic. If it is automatic, There are more other options, and then change to automatic. If not restored, delete the pairing record and try to connect again.

注意事项

Precautions

1. 请使用正规来源有安全认证的充电器进行充电

2. 使用耳机时适量的调节音量大小以免损伤听觉

3. 正确使用产品避免高空掉落或重度挤压

4. 儿童请在成人陪同下使用避免误食

5. 远离高温或潮湿等极端环境

6. 请勿拆卸本产品。

1. Please use a charger with safety certification from a regular source for charging

2. Adjust the volume appropriately when using headphones to avoid hearing damage

3. Use the product correctly to avoid falling or heavy squeezing

4. Children please use with an adult to avoid accidental ingestion

5. Keep away from extreme environments such as high temperature or humidity

6. Do not disassemble this product.

保修卡

Warranty Card

本保修卡是申请保修的凭证，请配合销售商填写并妥善保管备用！

This warranty card is a certificate for applying for a warranty, please fill it out in cooperation with the seller and keep it properly for future use!

用户姓名	用户姓名	用户姓名
用户信息	通信地址	通信地址
用户信息	联系电话	联系电话
产品信息	产品名称	产品名称
产品信息	产品型号	产品型号
产品信息	条码/编号	条码/编号
备注	备注	备注

注：此表应由销售商盖章确认；维修记录以授权服务机构维修凭证为准，申请售后服务，请妥善保管

Note: This form should be stamped and confirmed by the seller; the repair record is subject to the repair certificate of the authorized service organization. After applying for the service, please keep it properly

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.