
Quick Guide

TP20 Wireless Earphones



Battery Level of Charging Case
Charging Port of Charging Case
MFB of Earphone
Charging Pin of Earphone
Microphone
Microphone

Bluetooth: V5.3

Frequency Range: 2402 - 2480 MHz Sensitivity: 103±3dB Impedance: 32 ohm ±15% Input: DC 5V / 500mA Earphones Battery Capacity: 30 mAh x 2

Charging Pod Battery Capacity: 320 mAh

Charge Time: 1.5 hours **Charging for Earphones:**

Product Specification

Fully charge the battery for 2-3 hours before using the earphones for the first time, or when they have been unused for extended periods.

Put the earphones into the charging case, they will charge automatically. The indicator of earphones will stay on light. Once the earphones are fully charged, the indicators will be light

Charging for Charnging Case:

When the charging case is connected with charger (not included) or USB port of your computer by included charging cable, the indicator will keep flashing. When the charging case is fully charged, the three indicators will keep on light.

When the charging case is out of battery, the earphones will not turn on/off automatically when removed from or placed back into the charging case. In this case, turn the earphones on/off manually.



Manual Power-On & Pairing



one earphones will flash into white and green, and the rest will not flash when earphones are connected.



your device will show "connected"



Touch the MFB for 10 secs on both earphones to power off the earphones.
The earphones will automatically turn off when without paring for 5mins.

Insert the earphones directed towards your ear canal. Twist gently until the earphones fit comfortably and get better sound experience.





If you have problem to connect the earphones with your device, don't worry about it, please follow the step as below: $\frac{1}{2} \int_{-\infty}^{\infty} \frac{1}{2} \int_{-\infty}^{\infty} \frac{1}{2$

1. Make sure all devices have turned off Bluetooth Function.Clean all the paring records if need.

2. Take the earphones out of the charging case, tap either earphones by 5 times quickly, prompt sound will be actived, and the indicators of both earphones will flash 5 times quickly.

3. Follow the pairing step as instruction.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment

off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is

-- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.