
FCC Statement


Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Description:





Content:

TS6 TWS Earphones Type-C USB Charging Cable Silicon Gel Tips (S/M/L) Quick Guide



Product Specification

Bluetooth: V5.3 Frequency Range: 2402 - 2480 MHz Sensitivity: 103 ± 3dB Impedance: 32 ohm ±15% Input: DC 5V / 300mA Earphones Battery Capacity: 30 mAh x 2 Charging Pod Battery Capacity: 250 mAh Charge Time: 1.5 hours

Charging for Earphones:

Fully charge the battery for 2-3 hours before using the earphones for the first time, or when they have been unused for extended periods.

Put the earbuds into the charging case, they will charge automatically. The indicators of earbuds will stay on light. Once the earbuds are fully charged, the indicators will be off.

When earbuds are fully charged, the indicators of earbuds and charging case will be both off.

Charging for Charging Case:

When the charging case is connected with charger (or computer USB port) by included charging cable, the indicator will flash slowly. When the charging case is fully charged, the light will be lit-on.

NOTE:

When the charging case is out of battery, the earphones will not turn on/o \mathbb{I} automatically when removed from or placed back into the charging case. In this case, turn the earphones on/off manually

First Use & Pairing



Auto Power-On & Pairing

Open the lid and take out earphones from the case, and they will automatically power on and enter into pairing mode.

Manual Power-On & Pairing

Touch the MFB for 2 secs on both earphones to turn on the earphones. (You will hear the prompt tone). The earphones will automatically enter pairing mode.





Connect



Flash

LED flash in white

and orange



LED flash and off

Pairing Mode
When earphones

When earphones are into pairing mode, one earphones will flash in white and orange, and the rest will be off when earphones are connected.

BLUETOOTH Bluetooth T388 Connected

Connect

Turn on the device's Bluetooth setting . Search for and choose **TS6** to pair, your device will show "connected" .

Power-Off



Auto Power-Off

Put L&R earphones into charging pod and close the lid , the earphones will automatically power off.

Manual Power-Off

- 1. Touch the MFB for 5 secs on both earphones to power off the earphones.
- 2. The earphones will automatically turn off when without paring for 5 mins.






Wearing



Insert the earphones directed towards your ear canal. Twist gently until the earphones fit comfortably and get better sound experience.

Control




Reset

If you have problem to connect the earphones with your device, don't worry about it, please follow the step as below:

- 1. Make sure all devices have turned off Bluetooth Function.Clean all the paring records if need.
- Take the earphones out of the case, tap either earphones by 6 times quickly, prompt sound will be actived, then follow the pairing step as instruction.

Wireless Earphones



Quick Guide